

Instruction and Reference Guide



Model BLSO



FOR THE LOVE OF SEWING

Baby Lock Consumer Helpline: 800-313-4110 www.babylock.com

Trademarks

FlashFX[®] is a registered trademark of Datalight, Inc.

FlashFX[®] Copyright 1998-2007 Datalight, Inc.

U.S.Patent Office 5,860,082/6,260,156

FlashFX[®] Pro[™] is a trademark of Datalight, Inc.

Datalight[®] is a registered trademark of Datalight, Inc.

Copyright 1989-2007 Datalight, Inc., All Rights Reserved

Video powered by Mobiclip™ encoding and playback technology.

"Adobe" and "Adobe Reader" are either registered trademarks or trademarks of Adobe Systems Incorporated in the United States and/or other countries.

IMPORTANT:

READ BEFORE DOWNLOADING, COPYING, INSTALLING OR USING.

By downloading, copying, installing or using the software you agree to this license. If you do not agree to this license, do not download, install, copy or use the software.

Intel License Agreement For Open Source Computer Vision Library

Copyright © 2000, Intel Corporation, all rights reserved. Third party copyrights are property of their respective owners.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- Redistribution's of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- Redistribution's in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- The name of Intel Corporation may not be used to endorse or promote products derived from this software without specific prior written permission.

This software is provided by the copyright holders and contributors "as is" and any express or implied warranties, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose are disclaimed. In no event shall Intel or contributors be liable for any direct, indirect, incidental, special, exemplary, or consequential damages (including, but not limited to, procurement of substitute goods or services; loss of use, data, or profits; or business interruption) however caused and on any theory of liability, whether in contract, strict liability, or tort (including negligence or otherwise) arising in any way out of the use of this software, even if advised of the possibility of such damage.

All information provided related to future Intel products and plans is preliminary and subject to change at any time, without notice.

INTRODUCTION

Thank you for purchasing this embroidery and sewing machine. Before using this machine, carefully read the "Important Safety Instructions", and then study this manual for the correct operation of the various functions.

In addition, after you have finished reading this manual, store it where it can quickly be accessed for future reference.

IMPORTANT SAFETY INSTRUCTIONS

Please read these safety instructions before attempting to use the machine. This machine is intended for household use.

DANGER - To reduce the risk of electric shock

1 Always unplug the machine from the electrical outlet immediately after using, when cleaning, when making any user servicing adjustments mentioned in this manual, or if you are leaving the machine unattended.

WARNING - To reduce the risk of burns, fire, electric shock, or injury to persons.

2 Always unplug the machine from the electrical outlet when removing covers, lubricating, or when making any adjustments mentioned in the instruction manual.

- To unplug the machine, switch the machine to the symbol "O" position to turn it off, then grasp the plug and pull it out of the electrical outlet. **Do not** pull on the cord.
- Plug the machine directly into the electrical outlet. Do not use an extension cord.
- Always unplug your machine if the power is cut.

3 Never operate this machine if it has a damaged cord or plug, if it is not working properly, if it has been dropped or damaged, or water is spilled on the unit. Return the machine to the nearest authorized retailer for examination, repair, electrical or mechanical adjustment.

- While the machine is stored or in use if you notice anything unusual, such as an odor, heat, discoloration or deformation, stop using the machine immediately and unplug the power cord.
- When transporting the sewing machine, be sure to carry it by its handle. Lifting the sewing machine by any other part may damage the machine or result in the machine falling, which could cause injuries.
- When lifting the sewing machine, be careful not to make any sudden or careless movements, otherwise you may injure your back or knees.

4 Always keep your work area clear:

- Never operate the machine with any air openings blocked. Keep ventilation openings of the sewing machine and foot control free from the build up of lint, dust, and loose cloth.
- **Do not** store objects on the foot controller.
- **Do not** use extension cords. Plug the machine directly into the electrical outlet.
- Never drop or insert any object into any opening.
- **Do not** operate where aerosol (spray) products are being used or where oxygen is being administered.
- **Do not** use the machine near a heat source, such as a stove or iron; otherwise, the machine, power cord or garment being sewn may ignite, resulting in fire or an electric shock.
- **Do not** place this sewing machine on an unstable surface, such as an unsteady or slanted table, otherwise the sewing machine may fall, resulting in injuries.

5 Special care is required when sewing:

- Always pay close attention to the needle. Do not use bent or damaged needles.
- Keep fingers away from all moving parts. Special care is required around the machine needle.
- Switch the sewing machine to the symbol "O" position to turn it off when making any adjustments in the needle area.
- **Do not** use a damaged or incorrect needle plate, as it could cause the needle to break.
- **Do not** push or pull the fabric when sewing, and follow careful instruction when free motion stitching so that you do not deflect the needle and cause it to break.

6 This machine is **not** a toy:

- Your close attention is necessary when the machine is used by or near children.
- The plastic bag that this sewing machine was supplied in should be kept out of the reach of children or disposed of. Never allow children to play with the bag due to the danger of suffocation.
- Do not use outdoors.

7 For a longer service life:

- When storing this machine, avoid direct sunlight and high humidity locations. Do not use or store the machine near a space heater, iron, halogen lamp, or other hot objects.
- Use only neutral soaps or detergents to clean the case. Benzene, thinner, and scouring powders can damage the case and machine, and should never be used.
- Always consult the operation manual when replacing or installing any assemblies, the presser feet, needle, or other parts to assure correct installation.

${f 8}$ For repair or adjustment:

- If the light unit is damaged, it must be replaced by an authorized retailer.
- In the event a malfunction occurs or adjustment is required, first follow the troubleshooting table in the back of the operation manual to inspect and adjust the machine yourself. If the problem persists, please consult your local authorized Baby Lock retailer.

Use this machine only for its intended use as described in the manual.

Use accessories recommended by the manufacturer as contained in this manual.

Use only the interface cable (USB cable) included with this machine.

Use only the USB mouse included with this machine.

The contents of this manual and specifications of this product are subject to change without notice.

For additional product information and updates, visit our website at www.babylock.com

SAVE THESE INSTRUCTIONS

Federal Communications Commission (FCC) Declaration of Conformity (For USA Only)

Responsible Party: Tacony Corporation 1760 Gilsinn Lane, Fenton, Missouri 63026 USA

declares that the product

Product Name:	Baby Lock Sewing Machine
Model Number:	BLSO


This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:


- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the retailer or an experienced radio/TV technician for help.
- The included interface cable should be used in order to ensure compliance with the limits for a Class B digital device.
- Changes or modifications not expressly approved by Tacony Corporation could void the user's authority to operate the equipment.

WARNING LABEL

The following warning label is on the included side cutter. Be sure to observe the precaution.




Label location



OUTSTANDING FEATURES


Checking the Needle Location in the Screen



You can check the needle drop position on the screen of your machine, even if the needle has not actually been lowered. Also, you can view the location of the needle within the sewing area in the screen.


See "Checking the Needle Location in the Screen" on page 75.

Edge Sewing



Using the built-in camera, the width of the area from the edge of the fabric to the stitching line can be measured and set for edge sewing. See "Edge Sewing" on page 138.

Using the Built-In Camera to Align the Embroidering Position



The embroidering position can easily be aligned by using the machine's built-in camera and the enclosed embroidery positioning sticker. See "Using the Built-In Camera to Align the Embroidering Position" on page 205 and 300.

Uninterrupted Embroidering (Using a Single Color)


You can embroider a multi-color pattern with a single color without stopping the machine while embroidering.

See "Uninterrupted Embroidering (Using a Single Color)" on page 293.

Duplicating a Pattern

You can duplicate a desired pattern with one touch. See "Duplicating a Pattern" on page 288.

Print and Stitch (Combining the Embroidery and Printing)



Completed embroidery patterns can be combined with printed backgrounds that are built into this machine.

Beautiful three-dimensional embroidered designs can be created by ironing a background onto fabric or printing it onto printable fabric, and then embroider a design to compliment the background.

See "PRINT AND STITCH (COMBINING EMBROIDERY PATTERNS AND PRINTED DESIGNS)" on page 215 and 304.

Vote

• Print the background and embroidery position sheet in their original dimensions. If an image is printed in a different size, the sizes of the embroidery pattern and background may not match. In addition, the built-in camera cannot detect the embroidery position mark. Make sure that the print settings are correctly specified.

WHAT YOU CAN DO WITH THIS MACHINE

Getting Ready

To learn the operation of the principal parts and the screens



Utility Stitches

Pre-programmed with more than 100 frequently used stitches



Embroidery

Maximum 30 cm × 20 cm (approx. 12 × 8 inches) for large embroidery designs

Chapter 5 Page 181

Appendix

Caring for your machine and dealing with errors and malfunctions

Chapter 7 Page 311

Sewing Basics

To learn how to prepare for sewing and basic sewing operations



Character/Decorative Stitches

The variety of stitches widen your creativity

Chapter **4** Page 145

Embroidery Edit

Designs can be combined, rotated or enlarged


Chapter **6** Page 259

HOW TO USE THIS MANUAL

Chapter 1 and Chapter 2 explain your sewing machine's basic operation procedures for someone who is using the sewing machine for the first time. If you want to sew utility stitches or character/ decorative stitches, read Chapter 1 and Chapter 2, then go on to Chapter 3 (Utility Stitches) or Chapter 4 (Character/ Decorative Stitches).

When you are ready to begin using the embroidery function after reading Chapter 1 and Chapter 2, proceed to Chapter 5 (Embroidery). Once you understand the steps explained in Chapter 5, go on to Chapter 6 (Embroidery Edit) for an explanation about the embroidery edit functions. In the screens appearing in the step-by-step instructions, the parts referred to in the operations are marked

with _____. Compare the screen in the directions with the actual screen, and carry out the operation. If, while using the machine, you experience something you do not understand, or there is a function you would like to know more about, refer to the index at the back of the operation manual in conjunction with the table of contents to find the section of the manual you should refer to.



CONTENTS

INTRODUCTION	i
IMPORTANT SAFETY INSTRUCTIONS	i
OUTSTANDING FEATURES	vi
WHAT YOU CAN DO WITH THIS MACHINE	viii
HOW TO USE THIS MANUAL	ix
NAMES OF MACHINE PARTS AND THEIR	
FUNCTIONS	1
Machine	1
Needle and Presser Foot Section	2
Embroidery Unit	3
Operation Buttons	3
Using the Flat Bed Attachment	4
Using the Accessory Case	
Using the Embroidery Unit Carrying Case	5
Included Accessories	5
Options	8
Using the Spool Stand	

Chapter 1 Getting Ready

TURNING THE MACHINE ON/OFF	12
LCD SCREEN	14
USB Connectivity	
Using the Machine Setting Mode Key	22
Using the Sewing Machine Help Key	
Using the Operation Guide Function	
Using the Sewing Guide Function	
Using the Pattern Explanation Function	35
LOWER THREADING	37
Winding the Bobbin	
Setting the Bobbin	
Pulling Up the Bobbin Thread	
UPPER THREADING	46
Upper Threading	
Using the Twin Needle Mode	
Using the Spool Stand	52
Using Threads that Unwind Quickly	53
CHANGING THE PRESSER FOOT	54
Removing the Presser Foot	54
Attaching the Presser Foot	
Attaching the Walking Foot	
CHANGING THE NEEDLE	
About the Needle	
Fabric/Thread/Needle Combinations	

Chapter 2 Sewing Basics

11

SEWING	60
Sewing a Stitch	60
Sewing Reinforcement Stitches	62
Sewing Curves	
Changing Sewing Direction	63
Sewing Heavyweight Fabrics	63
Sewing Hook-and-Loop Fastener	64
Sewing Lightweight Fabrics	64
Sewing Stretch Fabrics	
STITCH SETTINGS	66
Setting the Stitch Width	66
Setting the Stitch Length	67
Setting the Thread Tension	
USEFUL FUNCTIONS	69
Automatic Reinforcement Stitching	69
Automatic Thread Cutting	
Using the Knee Lifter	71
Pivoting	72
Automatic Fabric Sensor System	
(Automatic Presser Foot Pressure)	73
Needle Position – Stitch Placement	74

Locking the Screen	
Checking the Needle Location in the Screen	75
Character D. 114114 (Chitabara	
Chapter 3 Utility Stitches	77
SELECTING UTILITY STITCHES	78
Selecting a Stitch	79
Saving Your Stitch Settings	81
SEWING THE STITCHES	83
Straight Stitches	
Dart Seam	
Gathering	88
Flat Fell Seam	
Pintuck	
Zigzag Stitches	91
Elastic Zigzag Stitches	
Overcasting	94
Quilting	99
Blind Hem Stitches	111
Appliqué	113
Shelltuck Stitches	
Scallop Stitches	
Crazy Quilting	
Smocking Stitches	
Fagoting	
Tape or Elastic Attaching	
Heirloom	
One-step Buttonholes	
Four-step Buttonholes	
Bar Tacks	
Button Sewing	
Eyelet	
Multi-directional Sewing (Straight Stitch and Zigzag Stitch)	
Zipper Insertion	
Edge Sewing	138

Chapter 4 Character/Decorative Stitches 145

SELECTING STITCH PATTERNS	146
Selecting Decorative Stitch Patterns/7mm Decorative Sti	tch
Patterns/Satin Stitch Patterns/7mm Satin Stitch Patterns/	
Cross Stitch/Utility Decorative Stitch Patterns	148
Alphabet Characters	
SEWING STITCH PATTERNS	152
Sewing Attractive Finishes	152
Basic Sewing	
Making Adjustments	153
EDITING STITCH PATTERNS	155
Changing the Size	157
Changing the Length	
(for 7mm Satin Stitch Patterns Only)	
Creating a Vertical Mirror Image	
Creating a Horizontal Mirror Image	
Sewing a Pattern Continuously	
Changing Thread Density (for Satin Stitch Patterns Only)	
Returning to the Beginning of the Pattern	
Checking the Image	
COMBINING STITCH PATTERNS	
Before Combining	
Combining Various Stitch Patterns	
Combining Large and Small Stitch Patterns	
Combining Horizontal Mirror Image Stitch Patterns	
Combining Stitch Patterns of Different Length	165
Making Step Stitch Patterns	1.00
(for 7mm Satin Stitch Patterns Only)	
USING THE MEMORY FUNCTION	
Stitch Data Precautions	
Saving Stitch Patterns in the Machine's Memory	171
Saving Stitch Patterns to USB Media	
Saving Stitch Patterns in the Computer	1/5

]

2

3

4

5

6

7

Retrieving Stitch Patterns from the Machine's Memory	176
Recalling from USB Media	177
Recalling from the Computer	178

BEFORE EMBROIDERING	
Embroidery Step by Step	182
Attaching Embroidery Foot "W"	
Attaching the Embroidery Unit	
SELECTING PATTERNS	
Selecting Embroidery Patterns/Baby Lock "Exclusives"/C	
Alphabet Patterns/Floral Alphabet Patterns/Utility Embro	
Patterns	
Selecting Alphabet Character Patterns Selecting Frame Patterns	
Selecting Patterns from Embroidery Cards	
Selecting Patterns from USB Media/Computer	194
VIEWING THE SEWING SCREEN	
PREPARING THE FABRIC	
Attaching Iron-on Stabilizers (Backing) to the Fabric	
Hooping the Fabric in the Embroidery Frame	
Embroidering Small Fabrics or Fabric Edges	202
ATTACHING THE EMBROIDERY FRAME	
CONFIRMING THE PATTERN POSITION	
Using the Built-In Camera	
to Align the Embroidering Position	205
Checking the Pattern Position	
Previewing the Completed Pattern	
SEWING AN EMBROIDERY PATTERN	
Sewing Attractive Finishes	
Using Prewound Bobbins	
Sewing Embroidery Patterns	212
Sewing Embroidery Patterns Which Use Appliqué	213
PRINT AND STITCH (COMBINING EMBROI	
PATTERNS AND PRINTED DESIGNS)	
Selecting a Pattern	
Outputting the Background Image and Positioning Image .	
Printing the Background and Embroidery Position Sheet	
	219
Sewing Embroidery Patterns	220
Sewing Embroidery Patterns	220
Sewing Embroidery Patterns ADJUSTMENTS DURING THE EMBROIDERY PROCESS	220 221
Sewing Embroidery Patterns ADJUSTMENTS DURING THE EMBROIDERY PROCESS If the Bobbin Runs Out of Thread	220 221
Sewing Embroidery Patterns ADJUSTMENTS DURING THE EMBROIDERY PROCESS If the Bobbin Runs Out of Thread If the Thread Breaks During Sewing	220 221 221 222
Sewing Embroidery Patterns ADJUSTMENTS DURING THE EMBROIDERY PROCESS	220 221 221 222 223
Sewing Embroidery Patterns ADJUSTMENTS DURING THE EMBROIDERY PROCESS If the Bobbin Runs Out of Thread If the Thread Breaks During Sewing Restarting from the Beginning Resuming Embroidery After Turning Off the Power	220 221 222 223 223
Sewing Embroidery Patterns ADJUSTMENTS DURING THE EMBROIDERY PROCESS If the Bobbin Runs Out of Thread If the Thread Breaks During Sewing Restarting from the Beginning Resuming Embroidery After Turning Off the Power MAKING EMBROIDERY ADJUSTMENTS	220 221 221 222 223 223 225
Sewing Embroidery Patterns ADJUSTMENTS DURING THE EMBROIDERY PROCESS If the Bobbin Runs Out of Thread If the Thread Breaks During Sewing Restarting from the Beginning Resuming Embroidery After Turning Off the Power MAKING EMBROIDERY ADJUSTMENTS Adjusting Thread Tension	220 221 221 222 223 225 225
Sewing Embroidery Patterns ADJUSTMENTS DURING THE EMBROIDERY PROCESS If the Bobbin Runs Out of Thread If the Thread Breaks During Sewing Restarting from the Beginning Resuming Embroidery After Turning Off the Power MAKING EMBROIDERY ADJUSTMENTS Adjusting Thread Tension Adjusting the Alternate Bobbin Case	220 221 221 222 223 223 225
Sewing Embroidery Patterns	220 221 222 223 223 225 226
Sewing Embroidery Patterns	220 221 222 223 223 225 226
Sewing Embroidery Patterns	220 221 221 223 223 225 226 227
Sewing Embroidery Patterns	220 221 221 222 223 225 226 227 228
Sewing Embroidery Patterns	220 221 221 222 223 225 226 227 228 228 228
Sewing Embroidery Patterns	220 221 221 223 223 225 226 227 227 228 229 229 229
Sewing Embroidery Patterns	220 221 221 223 223 225 226 227 227 228 229 229 229 229 229 229
Sewing Embroidery Patterns	220 221 221 223 223 225 225 226 226 227 228 228 229 229 230 232
Sewing Embroidery Patterns	220 221 221 223 223 225 225 226 227 228 227 228 229 229 232 232
Sewing Embroidery Patterns	220 221 221 222 223 225 225 226 226 227 228 228 229 229 230 232 232
Sewing Embroidery Patterns	220 221 221 223 223 225 225 226 227 226 227 228 227 228 229 233 234
Sewing Embroidery Patterns	220 221 221 223 225 225 226 227 228 227 228 229 229 233 232 232
Sewing Embroidery Patterns	220 221 221 223 225 225 226 227 228 227 228 229 229 233 232 232
Sewing Embroidery Patterns	220 221 221 223 225 225 226 227 228 229 229 233 232 232 234 236 237
Sewing Embroidery Patterns	220 221 221 223 225 225 226 227 228 229 229 233 232 233 234 235 237 237 238
Sewing Embroidery Patterns	
Sewing Embroidery Patterns	
Sewing Embroidery Patterns	220 221 221 223 225 225 226 227 228 227 228 229 233 232 233 234 237 238 237 238 237 238 237 238 237 238 237 238 237 238 237 238 237 238 238 237 238 237 238 237 238 237 238 237 238 238 238 238 238 238 238 238 238 238 238 238 238 238 238
Sewing Embroidery Patterns	
Sewing Embroidery Patterns	


Saving Embroidery Patterns in the Computer	
Recalling from the Computer252 EMBROIDERY APPLICATIONS	
Using a Frame Pattern to Make an Appliqué (1)254	
Using a Frame Pattern to Make an Appliqué (2)255 Sewing Split Embroidery Patterns257	
Chapter 6 Embroidery Edit 259	
EXPLANATION OF FUNCTIONS	
SELECTING PATTERNS TO EDIT	
Selecting Embroidery Patterns/Baby Lock "Exclusives"/Greek Alphabet Patterns/Floral Alphabet Patterns/Utility Embroidery Patterns/Frame Patterns	
Selecting Alphabet Character Patterns262	
EDITING PATTERNS265	
Moving the Pattern	
Rotating the Pattern	
Deleting the Pattern	
Changing the Configuration of	
Alphabet Character Patterns	
Reducing Character Spacing	
Separating Combined Character Patterns	
Changing the Color of Each Alphabet Character	
in a Pattern	
Embroidering Linked Characters	
Creating a Custom Thread Table277	
Choosing a Color from the Custom Thread Table281	
Designing Repeated Patterns	
Duplicating a Pattern	
COMBINING PATTERNS	
COMDINING FATTERING	
Editing Combined Patterns289	
Editing Combined Patterns	
Editing Combined Patterns 289 Sewing Combined Patterns 292 VARIOUS EMBROIDERING FUNCTIONS 293 Uninterrupted Embroidering (Using a Single Color) 293 Basting Embroidery 293 Creating an Appliqué Piece 294 Using the Built-In Camera to 300 USING THE MEMORY FUNCTION 303	
Editing Combined Patterns	· · · · · · · · · · · · · · · · · · ·
Editing Combined Patterns 289 Sewing Combined Patterns 292 VARIOUS EMBROIDERING FUNCTIONS 293 Uninterrupted Embroidering (Using a Single Color) 293 Basting Embroidery 293 Creating an Appliqué Piece 294 Using the Built-In Camera to 300 USING THE MEMORY FUNCTION 303 PRINT AND STITCH (COMBINING EMBROIDERY PATTERNS AND PRINTED DESIGNS) 304)
Editing Combined Patterns 289 Sewing Combined Patterns 292 VARIOUS EMBROIDERING FUNCTIONS 293 Uninterrupted Embroidering (Using a Single Color) 293 Basting Embroidery 293 Creating an Appliqué Piece 294 Using the Built-In Camera to 300 USING THE MEMORY FUNCTION 303 PRINT AND STITCH (COMBINING EMBROIDERY PATTERNS AND PRINTED DESIGNS) 304 Selecting a Pattern 305	
Editing Combined Patterns 289 Sewing Combined Patterns 292 VARIOUS EMBROIDERING FUNCTIONS 293 Uninterrupted Embroidering (Using a Single Color) 293 Basting Embroidery 293 Creating an Appliqué Piece 294 Using the Built-In Camera to 300 USING THE MEMORY FUNCTION 303 PRINT AND STITCH (COMBINING EMBROIDERY PATTERNS AND PRINTED DESIGNS) 304	
Editing Combined Patterns 289 Sewing Combined Patterns 292 VARIOUS EMBROIDERING FUNCTIONS 293 Uninterrupted Embroidering (Using a Single Color) 293 Basting Embroidery 293 Creating an Appliqué Piece 294 Using the Built-In Camera to 300 USING THE MEMORY FUNCTION 303 PRINT AND STITCH (COMBINING EMBROIDERY PATTERNS AND PRINTED DESIGNS) 304 Selecting a Pattern 305 Outputting the Background Image and Position Sheet	
Editing Combined Patterns289Sewing Combined Patterns292VARIOUS EMBROIDERING FUNCTIONS293Uninterrupted Embroidering (Using a Single Color)293Basting Embroidery293Creating an Appliqué Piece294Using the Built-In Camera to303Align the Embroidering Position303PRINT AND STITCH (COMBINING EMBROIDERY304Selecting a Pattern305Outputting the Background Image and Positioning Image305Printing the Background and Embroidery Position Sheet308Sewing Embroidery Patterns309Chapter 7 Appendix311	
Editing Combined Patterns 289 Sewing Combined Patterns 292 VARIOUS EMBROIDERING FUNCTIONS 293 Uninterrupted Embroidering (Using a Single Color) 293 Basting Embroidery 293 Creating an Appliqué Piece 294 Using the Built-In Camera to 303 Align the Embroidering Position 303 PRINT AND STITCH (COMBINING EMBROIDERY PATTERNS AND PRINTED DESIGNS) 304 Selecting a Pattern 305 Outputting the Background Image and Positioning Image 303 Printing the Background and Embroidery Position Sheet 308 Sewing Embroidery Patterns 309 Chapter 7 Appendix 311 CARE AND MAINTENANCE 312	
Editing Combined Patterns 289 Sewing Combined Patterns 292 VARIOUS EMBROIDERING FUNCTIONS 293 Uninterrupted Embroidering (Using a Single Color) 293 Basting Embroidery 293 Creating an Appliqué Piece 294 Using the Built-In Camera to 303 Align the Embroidering Position 303 PRINT AND STITCH (COMBINING EMBROIDERY PATTERNS AND PRINTED DESIGNS) 304 Selecting a Pattern 305 Outputting the Background Image and Positioning Image 305 Printing the Background and Embroidery Position Sheet 308 Sewing Embroidery Patterns 309 Chapter 7 Appendix 311 CARE AND MAINTENANCE 312 Cleaning the LCD Screen 312 Cleaning the Machine Casing 312	
Editing Combined Patterns 289 Sewing Combined Patterns 292 VARIOUS EMBROIDERING FUNCTIONS 293 Uninterrupted Embroidering (Using a Single Color) 293 Basting Embroidery 293 Creating an Appliqué Piece 294 Using the Built-In Camera to 303 Align the Embroidering Position 303 PRINT AND STITCH (COMBINING EMBROIDERY PATTERNS AND PRINTED DESIGNS) 304 Selecting a Pattern 305 Outputting the Background Image and Positioning Image 305 Printing the Background and Embroidery Position Sheet 308 Sewing Embroidery Patterns 309 Chapter 7 Appendix 311 Cleaning the LCD Screen 312 Cleaning the Race 312	
Editing Combined Patterns 289 Sewing Combined Patterns 292 VARIOUS EMBROIDERING FUNCTIONS 293 Uninterrupted Embroidering (Using a Single Color) 293 Basting Embroidery 293 Creating an Appliqué Piece 294 Using the Built-In Camera to 303 Align the Embroidering Position 303 PRINT AND STITCH (COMBINING EMBROIDERY PATTERNS AND PRINTED DESIGNS) 304 Selecting a Pattern 305 Outputting the Background Image and Positioning Image 305 Printing the Background and Embroidery Position Sheet 308 Sewing Embroidery Patterns 309 Chapter 7 Appendix 311 CARE AND MAINTENANCE 312 Cleaning the LCD Screen 312 Cleaning the Race 312 Cleaning the Race 312 Cleaning the Bobbin Case 313	
Editing Combined Patterns 289 Sewing Combined Patterns 292 VARIOUS EMBROIDERING FUNCTIONS 293 Uninterrupted Embroidering (Using a Single Color) 293 Basting Embroidery 293 Creating an Appliqué Piece 294 Using the Built-In Camera to 303 Align the Embroidering Position 303 PRINT AND STITCH (COMBINING EMBROIDERY PATTERNS AND PRINTED DESIGNS) 304 Selecting a Pattern 305 Outputting the Background Image and Positioning Image 305 Printing the Background and Embroidery Position Sheet 308 Sewing Embroidery Patterns 309 Chapter 7 Appendix 311 Cleaning the LCD Screen 312 Cleaning the Race 312	
Editing Combined Patterns289Sewing Combined Patterns292VARIOUS EMBROIDERING FUNCTIONS293Uninterrupted Embroidering (Using a Single Color)293Basting Embroidery293Creating an Appliqué Piece294Using the Built-In Camera to303Align the Embroidering Position303PRINT AND STITCH (COMBINING EMBROIDERYPATTERNS AND PRINTED DESIGNS)304Selecting a Pattern305Outputting the Background Image and Positioning Image305Printing the Background and Embroidery Position Sheet308Sewing Embroidery Patterns309Chapter 7 Appendix311Cleaning the LCD Screen312Cleaning the Race313Cleaning the Bobbin Case313Cleaning the Bobbin Case313Cleaning the Bobbin Case314About the Maintenance Message315ADJUSTING THE SCREEN316	
Editing Combined Patterns289Sewing Combined Patterns292VARIOUS EMBROIDERING FUNCTIONS293Uninterrupted Embroidering (Using a Single Color)293Basting Embroidery293Creating an Appliqué Piece294Using the Built-In Camera to303Align the Embroidering Position303PRINT AND STITCH (COMBINING EMBROIDERYPATTERNS AND PRINTED DESIGNS)304Selecting a Pattern305Outputting the Background Image and Positioning Image306Printing the Background and Embroidery Position Sheet308Sewing Embroidery Patterns309Chapter 7 Appendix311Cleaning the LCD Screen312Cleaning the Race313Cleaning the Bobbin Case313Cleaning the Bobbin Case313Cleaning the Soreen314About the Maintenance Message315ADJUSTING THE SCREEN316Touch Panel is Malfunctioning316	
Editing Combined Patterns289Sewing Combined Patterns292VARIOUS EMBROIDERING FUNCTIONS293Uninterrupted Embroidering (Using a Single Color)293Basting Embroidery293Creating an Appliqué Piece294Using the Built-In Camera to303Align the Embroidering Position303PRINT AND STITCH (COMBINING EMBROIDERYPATTERNS AND PRINTED DESIGNS)304Selecting a Pattern305Outputting the Background Image and Positioning Image306Printing the Background and Embroidery Position Sheet308Sewing Embroidery Patterns309Chapter 7 Appendix311Cleaning the LCD Screen312Cleaning the Race313Cleaning the Bobbin Case313Cleaning the Bobbin Case313Cleaning the Source314About the Maintenance Message315ADJUSTING THE SCREEN316TOUCH Panel is Malfunctioning316TROUBLESHOOTING317	
Editing Combined Patterns289Sewing Combined Patterns292VARIOUS EMBROIDERING FUNCTIONS293Uninterrupted Embroidering (Using a Single Color)293Basting Embroidery293Creating an Appliqué Piece294Using the Built-In Camera to303Align the Embroidering Position303PRINT AND STITCH (COMBINING EMBROIDERYPATTERNS AND PRINTED DESIGNS)304Selecting a Pattern305Outputting the Background Image and Positioning Image306Sewing Embroidery Patterns309Chapter 7 Appendix311CARE AND MAINTENANCE312Cleaning the LCD Screen312Cleaning the Backing312Cleaning the Backer313Cleaning the Bobbin Case313Cleaning the Subtor Case314About the Maintenance Message315ADJUSTING THE SCREEN316TROUBLESHOOTING317ERROR MESSAGES322	
Editing Combined Patterns289Sewing Combined Patterns292VARIOUS EMBROIDERING FUNCTIONS293Uninterrupted Embroidering (Using a Single Color)293Basting Embroidery293Creating an Appliqué Piece294Using the Built-In Camera to303Align the Embroidering Position303PRINT AND STITCH (COMBINING EMBROIDERYPATTERNS AND PRINTED DESIGNS)304Selecting a Pattern305Outputting the Background Image and Positioning Image305Printing the Background and Embroidery Position Sheet308Sewing Embroidery Patterns309Chapter 7 Appendix311Cleaning the LCD Screen312Cleaning the Machine Casing312Cleaning the Bobbin Case313Cleaning the Kace314About the Maintenance Message315ADJUSTING THE SCREEN316TROUBLESHOOTING317ERROR MESSAGES322SPECIFICATIONS330	
Editing Combined Patterns289Sewing Combined Patterns292VARIOUS EMBROIDERING FUNCTIONS293Uninterrupted Embroidering (Using a Single Color)293Basting Embroidery293Creating an Appliqué Piece294Using the Built-In Camera to303Align the Embroidering Position303PRINT AND STITCH (COMBINING EMBROIDERYPATTERNS AND PRINTED DESIGNS)304Selecting a Pattern305Outputting the Background Image and Positioning Image306Sewing Embroidery Patterns309Chapter 7 Appendix311CARE AND MAINTENANCE312Cleaning the LCD Screen312Cleaning the Backing312Cleaning the Backer313Cleaning the Backing314About the Maintenance Message315ADJUSTING THE SCREEN316TROUBLESHOOTING317ERROR MESSAGES322	

NAMES OF MACHINE PARTS AND THEIR FUNCTIONS

The names of the various parts of the sewing machine and their functions are described below. Before using the sewing machine, carefully read these descriptions to learn the names of the machine parts.

Machine

Front View



- ① Top cover
- Open the top cover to thread the machine and wind the bobbin. ② **Pre-tension disk**

Pass the thread around the pre-tension disk when winding the bobbin thread. (page 37)

- ③ Thread guide for bobbin winding Pass the thread through this thread guide when winding the bobbin thread. (page 37)
- (4) Spool pin
- Place a spool of thread on the spool pin. (page 46)
- ⑤ Spool cap
- Use the spool cap to hold the spool of thread in place. (page 46) (6) Supplemental spool pin
- Use this spool pin to wind the bobbin thread, or to sew with the twin needle. (page 37, 49)
- ⑦ Bobbin winder
- Use the bobbin winder when winding the bobbin. (page 37) (8) LCD (liquid crystal display)
- Settings for the selected stitch and error messages appear in the LCD. (page 14)
- ③ Knee lifter
- Use the knee lifter to raise and lower the presser foot. (page 71) (1) Knee lifter slot
- Insert the knee lifter into the slot. (page 71)
- ① Operation buttons (6 buttons) and sewing speed controller

Use these buttons and the slide to operate the sewing machine. (page 3)

Plat bed attachment with accessory compartment Store presser feet and bobbins in the accessory compartment of the flat bed attachment. When sewing cylindrical pieces, remove the flat bed attachment. (page 4)


(13) Thread cutter

Pass the threads through the thread cutter to cut them. (page 48)

(1) Thread guide plate

Pass the thread around the thread guide plate when threading upper thread. (page 46)

■ Right-side/Rear View



1 Handle

Carry the sewing machine by its handle when transporting the machine.

- Presser foot lever Raise and lower the presser foot lever to raise and lower the presser foot. (page 54)
- 3 Main power switch Use the main power switch to turn the sewing machine ON and OFF. (page 12)
- Foot controller with retractable cord Depress the foot controller to control the speed of the machine. (page 61)
 Power cord record record
- **(5)** Power cord receptacle

Insert the power cord into the machine receptacle. (page 12) (6) Air vent

The air vent allows the air surrounding the motor to circulate. Do not cover the air vent while the sewing machine is being used.

⑦ Foot controller jack

Insert the foot controller plug into its jack on the machine. (page 61)

③ Speaker

③ USB port for computer

In order to import/export patterns between a computer and the machine, plug the USB cable into the USB port. (page 18, 175, 248)


- 1 USB port for mouse (page 18)
- (f) Primary (top) USB port for media In order to send patterns from/to USB media, plug the USB media directly into the USB port. (page 173, 247)

Touch pen holder

Use the touch pen holder to hold the touch pen when not in use. (3) Handwheel

Rotate the handwheel toward you (counterclockwise) to raise and lower the needle. The wheel should be turned toward the front of the machine.

Needle and Presser Foot Section



① Buttonhole lever

The buttonhole lever is used with the one-step buttonhole foot to create buttonholes. (page 121)

② Presser foot holder

The presser foot is attached to the presser foot holder. (page 54)

③ Presser foot holder screw

Use the presser foot holder screw to hold the presser foot in place. (page 55) $\,$

④ Presser foot

The presser foot consistently applies pressure to the fabric as sewing takes place. Attach the appropriate presser foot for the selected stitch. (page 54)

5 Feed dogs

The feed dogs feed the fabric in the sewing direction.

6 Bobbin cover

Open the bobbin cover to set the bobbin. (page 43, 92)

⑦ Needle plate cover

Remove the needle plate cover to clean the race. (page 86, 211)

(8) Needle plate

The needle plate is marked with guides to help sew straight seams. (page 85)

In the second second


Pass the upper thread through the needle bar thread guide. (page 46)

 $\textcircled{0} \quad \text{Needle clamp screw}$

Use the needle clamp screw to hold the needle in place. (page 55)


Measurements on the needle plate, bobbin cover (with mark) and needle plate cover

The measurements on the bobbin cover are references for patterns with a middle (center) needle position. The measurements on the needle plate and the needle plate cover are references for stitches with a left needle position.



- ① For stitches with a middle (center) needle position
- ② For stitches with a left needle position
- ③ Left needle position on the needle plate <inch>
- ④ Left needle position on the needle plate <cm>
- 5 Middle (center) needle position on the bobbin cover (with mark) <inch>
- ⑥ Left needle position on the needle plate cover <inch>

Embroidery Unit




- ① Carriage
 - The carriage moves the embroidery frame automatically when embroidering. (page 184)
- ② Release button (located under the embroidery unit) Press the release button to remove the embroidery unit. (page 185)
- (3) Embroidery frame holder Insert the embroidery frame into the embroidery frame holder to hold the frame in place. (page 203)
 (4) Frame-securing lever
- Press the frame-securing lever down to secure the embroidery frame. (page 203)
- (5) Embroidery unit connection Insert the embroidery unit connection into the connection port when attaching the embroidery unit. (page 184)

A CAUTION


• After the embroidery frame is set in the frame holder, be sure the frame-securing lever is correctly lowered.

Operation Buttons



Using the Flat Bed Attachment


Pull the top of the flat bed attachment to open the accessory compartment.



Using the Accessory Case

Opening the Accessory Case


Fully slide the bar on each side of the accessory case, and then lift off the lid to open the case. The case can only be opened or locked correctly if both bars are slid in the same direction.




① Bars

Closing the Accessory Case

Fully slide the bar on each side of the accessory case lid to align the notches in the lid with the notches in the bars.




Place the lid on top of the case so that the notches in the lid align with the tabs on the case, and then slide the bar on each side back to the center of the accessory case.



① Bars


Using the Accessory Trays

Two presser foot storage trays are stored in the included accessory case. One is for presser feet for utility sewing, and the other is for presser feet for embroidery and machine quilting.



- ① For presser feet for utility sewing
- ② For presser feet for embroidery and machine quilting


For your convenience, a presser foot storage tray can be stored in the accessory compartment of the flat bed attachment.



- ① Storage space of the flat bed attachment
- ② Presser foot storage space of the flat bed attachment
- ③ Presser foot storage trays

Using the Embroidery Unit Carrying Case


Included accessories 46-49 are contained in the embroidery unit carrying case. To open the embroidery unit carrying case, raise each lock and move the latches out of position. To re-hook the latches and securely close the case, position the latch on the catch of the unit lid and lower the lock till it snaps.




1 Latches

Included Accessories

See table on the next page about included accessories.



NAMES OF MACHINE PARTS AND THEIR FUNCTIONS



No.	Part Name	Part Code
1	Zigzag foot "J" (on machine)	XC3021-051
2	Monogramming foot "N"	X53840-351
3	Overcasting foot "G"	XC3098-051
4	Zipper foot "I"	X59370-051
5	Buttonhole foot "A"	X57789-151
6	Blind stitch foot "R"	X56409-051
7	Button fitting foot "M"	130489-001
8	Walking foot	XE1986-001
9	Side cutter foot	XC3198-001
10	Straight stitch foot	XD0826-051
11	Free motion quilting foot "C"	XE0765-001
12	Free motion echo quilting foot	
· -	"E"	XE0766-001
13	Free motion open toe quilting foot "O"	XE0767-001
14	Embroidery foot "W"	XC8156-651
15	Vertical stitch alignment foot "V"	XE0005-001
16	Blind stitch foot (with guide)*	XA0059-001
17	Narrow hemmer foot*	XE0754-001
18	Cording foot (3 cord guide)*	XA6871-001
19	Needle set	XE4962-001
20	Twin needle	XE4963-001
21	Ball point needle set	XD0705-051
22	Bobbin × 10 (One is on machine.)	X52860-150
23	Seam ripper	X54243-001
24	Scissors	184783-051
25	Cleaning brush	X59476-051
26	Eyelet punch	135793-001
27	Screwdriver (small)	X55468-051
28	Screwdriver (large)	X55467-051
29	Disc-shaped screwdriver	XC1074-051
30	Spool cap (small)	130013-154
31	Spool cap (medium) × 2 (One is on machine.)	X55260-153
32	Spool cap (large)	130012-054
33	Spool stand	See page 9
34	Spool felt	X57045-051
35	Spool net × 2	XA5523-050
36	Embroidery needle plate cover	XA9939-051
37	Touch pen (stylus)	XA9940-051
38	Knee lifter	X4713-001
39	USB cable	XD0745-051


No.	Part Name	Part Code
40	Alternate bobbin case (no color)	XC8167-451
41	Straight stitch needle plate	XE4908-001
42	Cord guide bobbin cover (with single hole)	XC8449-051
43	Bobbin cover (with mark)	XE0756-001
44	Bobbin center pin and user manual	XD0836-051
45	Foot controller	XC8028-051
46	Embroidery frame set (small) H 2 cm × W 6 cm (H 1 inch × W 2-1/2 inches)	EF73:Frame EF77:Embroidery sheet
47	Embroidery frame set (medium) H 10 cm × W 10 cm (H 4 inches × W 4 inches)	EF74:Frame EF78:Embroidery sheet
48	Embroidery frame set (quilt) H 20 cm × W 20 cm (H 8 inches × W 8 inches)	EF91:Frame EF93:Embroidery sheet
49	Embroidery frame set (extra large) H 30 cm × W 20 cm (H 12 inches × W 8 inches)	EF92:Frame EF94:Embroidery sheet
50	Embroidery bobbin thread	BBT-W
51	Embroidery positioning stickers × 3	XE4912-001
52	Edge sewing sheet × 6	XE5500-001
53	Stabilizer material	BM3:XE0806-001
54	Chalk pencil	184944-001
55	USB mouse	XE4904-001
56	LCD cleaning cloth	XE5023-001
57	Soft cover	XE5112-001
58	Embroidery unit carrying case	XE3803-001
59	Accessory case	XE5073-001
60	Power cord	XC6052-051
61	Instruction and reference guide	XE5021-001
62	Quick reference guide	XE5022-001
63	Additional accessories guide	XE5470-001

Memo A


Foot controller: Model S This foot controller can be used on the machine model:BLSO.

🏹 Memo

- Always use accessories recommended for this machine.
- The screw for the presser foot holder is available through your authorized retailer (Part code XA4813-051).
- Included accessories 39, 45, 61, 62 and 63 can be stored in the machine's soft cover case.



Options



No.	Part Name	Part Code	
1	Border embroidery frame H 18 cm × W 10 cm (H 7 inches × W 4 inches)	BLSO-BF	
2	10 spool stand	BLSO-TS	
3	Embroidery frame set (large) H 18 cm × W 13 cm (H 7 inches × W 5 inches)	EF75:Frame EF79:Embroidery sheet	
4	Embroidery card Reader	BLECR	
5	Extension Table and free motion grip	BLSO-ET	
6	Embroidery bobbin thread(white)	BBT-W	
	Embroidery bobbin thread(black)	BBT-B	
7	Seam guide	BLG-SG	
8	1/4 inch piecing foot with guide	ESG-QGF	
9	Edge sewing sheet × 5	BLSO-ESS	
10	Embroidery positioning stickers × 6	BLSO-EPS	

🏹 Memo


 All specifications are correct at the time of printing. Please be aware that some specifications may change without notice.

🗸 Note

- Embroidery cards purchased in foreign countries may not work with your machine.
- Visit your nearest authorized retailer for a complete listing of optional accessories.

Using the Spool Stand

The included spool stand is useful when using thread spools with a large diameter (cross-wound thread). The spool stand can hold two spools of thread.




No.	Part Name	Part Code
1	Telescopic thread guide	XE0766-001
2	Spool support	XE4958-001
3	Spool pin × 2	XA6313-051
4	Screw and washer	XC7568-051
5	Spool cap (XL) × 2	XE0779-001
6	Spool holders × 2	XA0679-050
7	Spool cap base × 2	XE0780-001
8	Spool felt × 2	XC7134-051

CAUTION


- Do not lift the handle of the machine while the spool stand is installed.
- Do not push or pull the telescopic thread guide or spool pins with extreme force, otherwise damage may result.
- Do not place any object other than spools of thread on the spool support.
- Do not try to wind thread on the bobbin while sewing using the spool stand.

How to assemble the spool stand


Fully extend the telescopic thread guide shaft, and then rotate the shaft until the two internal stoppers click into place.





Insert the telescopic thread guide into the round hole at the center of the spool support, and then use a screwdriver to securely tighten the screw (①) from the reverse side.













Open the upper cover of the machine. From the back of the machine, press in the upper cover latches (one on each side), and then pull the upper cover up to remove it from the machine.






Insert the spool stand onto the notches of the machine.




How to remove

From the back of the machine, press in the spool stand latches (one on each side), and then pull the spool stand up to remove it from the machine.





Attach the upper cover to the machine.



Memo

- See page 41 about the bobbin winding using the spool stand.
 - See page 52 about the upper threading using the spool stand.



TURNING THE MACHINE ON/OFF......12

LCD SCREEN14
 Home Page Screen
USB Connectivity 18
 Using USB Media or Embroidery Card Reader/ USB Card Writer Module*18
Connecting the Machine to the Computer
Using a USB Mouse19
Clicking a Key
 Changing Pages
■ Changing the Pointer Shape When a USB Mouse Is Used
Changing the Screen Saver Image
Selecting the Initial Screen Display
 Choosing the Display Language
Using the Sewing Machine Help Key
Using the Operation Guide Function
Using the Sewing Guide Function
Using the Pattern Explanation Function
LOWER THREADING
Winding the Bobbin
 Using the Supplemental Spool Pin
Using the Spool Stand
■ Untangling Thread from Beneath the Bobbin Winder Seat 42
Setting the Bobbin 43
Pulling Up the Bobbin Thread45
UPPER THREADING46
Upper Threading 46
Using the Twin Needle Mode 49
Using the Spool Stand 52
Using the Spool Stand
Using Threads that Unwind Quickly 53
Using the Spool Net
CHANGING THE PRESSER FOOT54
Removing the Presser Foot54
Attaching the Presser Foot 54
Attaching the Walking Foot 55
CHANGING THE NEEDLE56
About the Needle58
Fabric/Thread/Needle Combinations

TURNING THE MACHINE ON/OFF

- Use only regular household electricity for the power source. Using other power sources may result in fire, electric shock, or damage to the machine.
- Make sure that the plugs on the power cord are firmly inserted into the electrical outlet and the power cord receptacle on the machine.
- Do not insert the plug on the power cord into an electrical outlet that is in poor condition.
- Turn the main power to OFF and remove the plug in the following circumstances: When you are away from the machine After using the machine When the power fails during use When the machine does not operate correctly due to a bad connection or a disconnection During electrical storms


- Use only the power cord included with this machine.
- Do not use extension cords or multi-plug adapters with many other appliances plugged in to them. Fire or electric shock may result.
- Do not touch the plug with wet hands. Electric shock may result.
- When unplugging the machine, always turn the main power to OFF first. Always grasp the plug to remove it from the outlet. Pulling on the cord may damage the cord, or lead to fire or electric shock.
- Do not allow the power cord to be cut, damaged, modified, forcefully bent, pulled, twisted, or bundled. Do not place heavy objects on the cord. Do not subject the cord to heat. These things may damage the cord, or cause fire or electric shock. If the cord or plug is damaged, take the machine to your authorized retailer for repairs before continuing use.
- Unplug the power cord if the machine is not to be used for a long period of time. Otherwise, a fire may result.
- When leaving the machine unattended, either the main switch of the machine should be turned to OFF or the plug must be removed from the socket-outlet.
- When servicing the machine or when removing covers, the machine must be unplugged.
- For U.S.A only

This appliance has a polarized plug (one blade wider than the other). To reduce the risk of electrical shock, this plug is intended to fit in a polarized outlet only one way.

If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician to install the proper outlet. Do not modify the plug in any way.



Insert the power supply cord into the power cord receptacle, then insert the plug into a wall outlet.



LCD SCREEN

When the machine is turned on, the opening movie is played. Touch anywhere on the screen for the home page screen to be displayed. Touch the LCD screen or a key with your finger or the included touch pen to select a machine function.


ப் Note

• When the straight stitch needle plate is on the machine, the needle will automatically move to the middle position.

Memo

• Only touch the screen with your finger or the included touch pen. Do not use a sharp pencil, screwdriver, or other hard or sharp object. It is not necessary to press hard on the screen. Pressing too hard or using a sharp object may damage the screen.


Home Page Screen




No.	Display	Key Name	Explanation	Page
1		Sewing key	Press this key to sew utility stitches or character or decorative stitch patterns.	See the "Key Functions" table. 16
2		Embroidery key	Attach the embroidery unit and press this key to embroider patterns.	182
3			Press this key to combine embroidery patterns. With the embroidery edit functions, you can also create original embroidery patterns or frame patterns.	260


Utility Stitch LCD Screen

Press a key with your finger to select the stitch pattern, to select a machine function, or to select an operation indicated on the key.



Shows single or twin needle mode setting, and the needle stop position.








* VV

Twin needle/up position

Twin needle/down position

- ② Shows the name and code number of the selected stitch.
- ③ Shows the presser foot code. Attach the presser foot indicated in this display before sewing.
- ④ Shows a preview of the selected stitch.
- When shown at 100%, the stitch appears in the screen at nearly its actual size.
- $\ensuremath{\textcircled{}}$ 5) Shows the stitch patterns.
- ⑥ Shows additional pages that can be displayed (Illustration shows page 1 of 2.).
- * All key functions of the LCD are explained in the "Key Functions" table on the following page.

Key Functions




No.	Display	Key Name	Explanation	Page
1	Utility Stitch	Utility stitch key	Press this key to select a straight stitch, zigzag stitch, buttonhole, blind hem stitch, or other stitches commonly used in garment construction.	79
2	Character Decorative Stitch	Character/Decorative stitch key	Press this key to select character or decorative stitch patterns.	146
3	Ē	Screen lock key	Press this key to lock the screen.When the screen is locked, the various settings, such as the stitch width and stitch length, are locked and cannot be changed. Press this key again to unlock the settings.	74
4		Image key	Press this key to display an enlarged image of the selected stitch pattern.	80
5	Â	Home page screen key	Press this key anytime it is displayed to return to the home page screen and select a different category - "Utility and Decorative Stitches", "Embroidery" or "Embroidery edit".	14
6		Stitch selection display	Press the key for the pattern you want to sew. Use 🗰 🔊 🗰 💷	79
7		Edge sewing key	Using the built-in camera, press this key to measure the width of the area from the edge of the fabric to the stitch and set the camera for edge sewing.	138
8		Needle mode selection key (single/ double)	Press this key to select twin needle sewing mode. The sewing mode changes between single needle mode and twin needle mode each time you press the key. If the key display is light gray, the selected stitch pattern cannot be sewn in the twin needle mode.	49
9	RETRIEVE	Retrieve key	Press this key to retrieve a saved pattern.	82
10	MEMORY	Manual memory key	Change the stitch pattern settings (zigzag width and stitch length, thread tension, automatic thread cutting or automatic reinforcement stitching, etc.), then save them by pressing this key. Five sets of settings can be saved for a single stitch pattern.	81

No.	Display	Key Name	Explanation	Page
1	RESET	Reset key	Press this key to return the selected stitch pattern saved settings to the default settings.	66-67
12	₩j0	Presser foot/Needle exchange key	Press this key before changing the needle, the presser foot, etc. This key locks all key and button functions to prevent operation of the machine.	54-57
13	?	Sewing machine help key	Press this key to see explanations on how to use the machine.	32
14	10	Camera view key	Touch this key to check the needle location as it is shown on the screen through the built in camera.	75
15	Ē	Machine setting mode key	Press this key to change the needle stop position, change the volume of operation beep, adjust the pattern or screen, and change other machine settings.	22
16	WIDTH LENGTH	Stitch width and stitch length key	Shows the zigzag width and stitch length settings of the currently selected stitch pattern. You can use the plus and minus keys to adjust the zigzag width and stitch length settings.	66
1		Thread tension key	Shows the automatic thread tension setting of the currently selected stitch pattern. You can use the plus and minus keys to change the thread tension settings.	67
18		Mirror image key	Press this key to create a mirror image of the selected stitch pattern. If the key display is light gray, a mirror image of the selected stitch pattern cannot be sewn.	79
19	×	Automatic thread cutting key	Press this key to set the automatic thread cutting function. Set the automatic thread cutting function before sewing to have the machine automatically sew reinforcement stitches at the beginning and end of sewing (depending on the pattern, the machine may sew reverse stitches) and trim the threads after sewing.	69
20		Automatic reinforcement stitch key	Press this key to use the automatic reinforcement stitching (reverse stitching) setting. If you select this setting before sewing, the machine will automatically sew reinforcement stitches at the beginning and end of sewing (depending on the pattern, the machine may sew reverse stitches).	69
2)	6	Free motion mode key	Press this key to enter free motion sewing mode. The presser foot is raised to an appropriate height and the feed dog is lowered for free motion quilting.	105
2	4	Pivot key	 Press this key to select the pivot setting. When the pivot setting is selected, stopping the machine lowers the needle and slightly raises the presser foot automatically. In addition, when sewing is restarted, the presser foot is automatically lowered. If this key appears as , the pivot function cannot be used. Be sure the needle position on page 23 of Machine Settings is set to the down position. 	72
8	100%	Pattern display size	 Shows the approximate size of the pattern selected. 100% : Nearly the same size as the sewn pattern 50% : 1/2 the size of the sewn pattern 25% : 1/4 the size of the sewn pattern * The actual size of the sewn pattern may differ depending on the type of fabric and thread that is used. 	79
2		Scroll key	Press or 💌, to move one page at a time, or touch anywhere on the bar to jump ahead for additional pages of stitches.	

USB Connectivity

You can perform many functions using the USB ports on the machine. Connect the appropriate devices according to the feature of each ports.



- Primary (top) USB port for media or card Reader/ USB card writer module* (USB2.0)
- * If you have purchased the Palette Ver5 or later, Palette Petite or Palette PTS, you can plug the included USB card writer module into the machine as an embroidery card reader, and recall patterns.
- ② USB port for mouse (USB1.1)
- ③ USB port for computer

Note


- The processing speed may vary by port selection and quantity of data.
- Do not insert anything other than USB media into the USB media port. Otherwise, the USB media drive may be damaged.

Using USB Media or Embroidery Card Reader/USB Card Writer Module*

When sending or reading patterns using the USB media or the embroidery card Reader/USB card writer module*, connect the device to the primary (top) USB port.

The primary (top) USB port processes the data faster than the other ports.

* If you have purchased the Palette Ver5 or later, Palette Petite or Palette PTS, you can plug the included USB card writer module into the machine as an embroidery card reader, and recall patterns.




- ① Primary (top) USB port
- ② Embroidery card Reader/USB card writer module*

🗤 Note

- Two USB media cannot be used with this machine at the same time. If two USB media are inserted, only the USB media inserted first is detected.
 - Use only an embroidery card reader designed for this machine. Using an unauthorized embroidery card reader may cause your machine to operate incorrectly.
 - Embroidery patterns cannot be saved from the machine to an embroidery card inserted into a connected USB card writer module.

n Memo


- USB media is widely used, however some USB media may not be usable with this machine. Please visit our website for more details.
- Depending on the type of USB media being used, either directly plug the USB device into the machine's USB port or plug the USB media Reader/Writer into the machine's USB port.
- You can plug the optional embroidery card Reader/USB card writer module* into the primary (top) or center port, when the mouse is not connected.
- You can plug a USB media into the center port, but the primary (top) USB port processes the data faster. It is recommended to use the primary (top) USB port.



① Primary (top) USB port

Connecting the Machine to the Computer

Using the included USB cable, the sewing machine can be connected to your computer.



- ① USB port for computer
- ② USB cable connector

🟒 Note


- The connectors on the USB cable can only be inserted into a port in one direction. If it is difficult to insert the connector, do not insert it with force. Check the orientation of the connector.
- For details on the position of the USB port on the computer (or USB hub), refer to the instruction manual for the corresponding equipment.

Using a USB Mouse

The USB mouse, connected to the sewing machine, can be used to perform a variety of operations in the screens.

Connect a USB mouse to the USB 1.1 port marked

with \bigcirc . You can also connect a USB mouse to the other USB port (USB 2.0).



- ① USB port for mouse
- ② USB mouse

🗤 Note


- Do not perform operations with the mouse at the same time that you are touching the screen with your finger or the included touch pen.
- A USB mouse can be connected or disconnected at any time.
- Only the left mouse button and its wheel can be used to perform operations. No other buttons can be used.
- The mouse pointer does not appear in the camera view window, the screen saver or the home page screen.

Clicking a Key


When the mouse is connected, the pointer appears on the screen. Move the mouse to position the pointer over the desired key, and then click the left mouse button.

n Memo

• Double-clicking has no effect.



① Pointer




Changing Pages

Rotate the mouse wheel to switch through the tabs of the pattern selection screens.

Memo


• If page numbers and a vertical scroll bar for additional pages are displayed, rotate the mouse wheel or click the left mouse button


with the pointer on \blacksquare / \blacktriangleright or \frown / \bigtriangledown to display the previous or next page.



]

Cetting Ready





Gi O

621


?

21

Using the Machine Setting Mode Key Press to change the default machine settings (needle stop position, embroidery speed, opening display, etc.). To display the different settings screens, press for "Sewing settings", for "General settings" or for "Embroidery settings".

Memo Press < or b to display a different settings screen.


Sewing settings



- ① Select whether to use the sewing speed controller to determine the zigzag width (see page 104).
- ② Make adjustments to character or decorative stitch patterns (see page 153).
- ③ Adjust the presser foot height. (Select the height of the presser foot when the presser foot is raised.)
- ④ Adjust the presser foot pressure. (The higher the number, the greater the pressure will be. Set the pressure at "3" for normal sewing.)
- ⑤ Select whether "1-01 Straight stitch (Left)" or "1-03 Straight stitch (Middle)" is the utility stitch that is automatically selected when the machine is turned on.
- 6 Change the height of the presser foot when sewing is stopped when the pivot setting is selected (see page 72). Adjust the presser foot to one of the three heights (3.2 mm, 5.0 mm and 7.5 mm).
- ⑦ Change the height of the presser foot when the machine is set to free motion sewing mode (see page 105).
- ⑧ When set to "ON", the thickness of the fabric is automatically detected by an internal sensor while sewing. This enables the fabric to be fed smoothly (see pages 64 and 73).

General settings

•



- ① Select the needle stop position (the needle position when the machine is not operating) to be up or down. Select the down position when using the pivot key.
- ② Select the operation of the "Needle Position Stitch Placement" button from the following two sequences (see page 74).

Each press of the "Needle Position - Stitch Placement" button:

- "ON" raises the needle, stops it at a nearly lowered position, then lowers it
- "OFF" raises the needle, then lowers it
- ③ Change the brightness of the Needle Area and Work Area Lights.
- ④ Change the speaker volume.
- (5) Change the shape of the pointer when a USB mouse is used (see page 25).
- ⑥ Turn both the upper and bobbin thread sensor "ON" or "OFF". If it is turned "OFF", the machine can be used without thread.
- Select the length of time until the screen saver appears. A setting between "OFF" (0) and "60" minutes can be set in 1-minute increments.
- (8) Change the image of the screen saver (see page 25).
- ③ Select the initial screen that is displayed when the machine is turned on (see page 28).
- 1 Use when running an application.
- (1) Change the display language (see page 29).
- Display the total number of stitches sewn on this machine, which is a reminder to take your machine in for regular servicing. (Contact your authorized retailer for details.)
- ③ The "No." is the number for the embroidery and sewing machine.
- Display the program version. "Version 1" shows the program version of the LCD panel, "Version 2" shows the program version of the machine.

河 Memo

• The latest version of software is installed in your machine. Check with your local authorized Baby Lock retailer or at "www.babylock.com" for available updates (see page 331).


Embroidery settings

Embroidery Frame Display	Initial Mode
1 30cm × 1 20cm ◀ ► (1)	SELECT 9
ABC Name of Color (2)	+ Embroidery Background Color
Madeira Poly (3)	SELECT 10
Max Embroidery Speed spm - + 4	Thumbnail Background Color
Embroidery Tension	Embroidery Basting Distance
Embroidery Foot Height	Embroidery Appliqué E - + 12
	CLOSE 7/7 ►
	🗎 🍠 🔮 🖓

- ① Select from among 14 embroidery frame displays (see page 230).
- ② Change the thread color display on the embroidery screen; thread number, color name (see page 229).
- ③ When the thread number "#123" is selected, select from six thread brands (see page 229).
- ④ Adjust the maximum embroidery speed setting (see page 229).
- 5 Adjust the upper thread tension for embroidering (see page 225).
- (6) Select the height of the embroidery foot "W" during embroidering (see page 197).
- ⑦ Change the display units (mm/inch).
- (8) Change the initial mode of the display (embroidery/embroidery edit).
- (9) Change the color of the background for the embroidery display area (see page 30).
- 0 Change the color of the background for the thumbnail area (see page 30).
- 1 Adjust the distance between the pattern and the basting stitching (see page 293).
- 0 Adjust the distance between the appliqué pattern and the outline (see page 294).

ŝ

Getting Ready 👺




settings screen.

 File dimension
 480 × 800 pixels or less, (If the width is more than 480 pixels, the image imported will be reduced to a width of 480 pixels.)


 Number allowed
 5 or less

🟒 Note

- When using USB media, make sure that it contains only your own personal images to be selected for the screen saver.
- Folders are recognized. Open the folder that holds your personal images.



Cetting Ready



Selecting the Initial Screen Display The Initial screen that appears on the machine can be changed. Press Ē. \rightarrow The Sewing settings screen appears. Press 🔤 . -----

Width Control

Fine Adjust Verti.

ĊŒĎ

1

ON

010

00


Fine Adjust Horiz. *··· + Presser Foot Height 1g 7.5 Presser Foot Pressure 1. 8 Initial Position < 1/7 F CLOSE O i 0=1 ?

- \rightarrow The General settings screen appears.
- Display 4/7 (page 4 of 7) of the General settings screen.


4 Use 🖪 and 🕞 to select the setting for the initial screen display.



- Opening Screen: When the machine is turned on, the home page screen appears after the opening movie screen is touched.
- Home Page: When the machine is turned on, the home page screen appears.
- Sewing/Embroidery Screen: When the machine is turned on, the Embroidery screen appears if the embroidery unit is attached to the machine, or the sewing screen appears if the embroidery unit is not attached to the machine.
- Press close to return to the original screen. 5








Press SELECT .


① Embroidery pattern background

Selected color



Using the Sewing Machine Help Key


Press **Press** to open the sewing machine help screen. Three functions are available from the screen shown below.




- ① Press this key to see explanation for upper threading, winding the bobbin, changing the presser foot, preparing to embroider a pattern, and how to use the machine (see page 35).
- ② Press this key to select utility stitches when you are not sure which stitch to use or how to sew the stitch (see page 33).
- ③ Press this key to see an explanation of the stitch selected (see page 34).

Using the Operation Guide Function

Press operation Guide to open the screen shown below. Six categories are displayed at the top of the screen. Press a key to see more information about that category.





and

Ū

122


*8

"Q

RETRIEVE

MEMORY


RESET O I




selected stitch. Follow the directions to sew the

stitch.

```
LCD SCREEN
```




LOWER THREADING




■ Using the Supplemental Spool Pin

With this machine, you can wind the bobbin during sewing. While using the main spool pin to sew embroidery, you can conveniently wind the bobbin using the supplemental spool pin.




① Supplemental spool pin

- Turn the main power to ON and open the top cover.
- Align the groove in the bobbin with the spring on the bobbin winder shaft, and set the bobbin on the shaft.




- ① Groove in the bobbin
- ② Spring on the shaft

position.



Set the supplemental spool pin in the "up"

- ① Supplemental spool pin
- Place the spool of thread on the supplemental spool pin, so that thread unrolls from the front. Push the spool cap onto the spool pin as far as possible to secure the thread spool.




- ① Spool cap
- ② Spool pin
- ③ Thread spool

CAUTION

- If the thread spool and/or spool cap are set incorrectly, the thread may tangle on the spool pin and cause the needle to break.
- Use the spool cap (large, medium, or small) that is closest in size to the thread spool. If a spool cap smaller than the thread spool is used, the thread may become caught in the slit on the end of the spool and cause the needle to break.


🔊 Memo

• When sewing with fine, cross-wound thread, use the small spool cap, and leave a small space between the cap and the thread spool.




- ① Spool cap (small)
- ② Thread spool (cross-wound thread)
- ③ Space

5 With your right hand, hold the thread near the thread spool. With your left hand, hold the end of the thread, and use both hands to pass the thread through the thread guide.




① Thread guide

Pass the thread around the pre-tension disk making sure that the thread is under the pre-tension disk.




- ① Pre-tension disk
- \rightarrow Make sure that the thread passes under the pretension disk.



- ② Pre-tension disk
- ③ Pull it in as far as possible.
- $\rightarrow\,$ Check to make sure thread is securely set between pre-tension disks.



Wind the thread clockwise around the bobbin 5-6 times.






Pass the end of the thread through the guide slit in the bobbin winder seat, and pull the thread to the right to cut the thread with the cutter.



- ① Guide slit (with built-in cutter)
- Bobbin winder seat


- Be sure to follow the process described. If the thread is not cut with the cutter, and the bobbin is wound, when the thread runs low it may tangle around the bobbin and cause the needle to break.
- Set the bobbin winding switch to the left, until it clicks into place.




① Bobbin winding switch

🏹 Memo

- Sliding the bobbin winding switch to the left switches the machine into bobbin winding mode.
- $\rightarrow~$ The bobbin winding window appears.



 → Bobbin winding starts automatically. The bobbin stops rotating when bobbin winding is completed. The bobbin winding switch will automatically return to its original position.



Vie Note

- **START** changes to **STOP** while the bobbin is winding.
- Stay near the machine while winding the bobbin to make sure the bobbin thread is being wound correctly. If the bobbin thread

is wound incorrectly, press immediately to stop the bobbin winding.


• The sound of winding the bobbin with stiff thread, such as nylon thread for quilting, may be different from the one produced when winding normal thread; however, this is not a sign of a malfunction.


🏹 Memo

```
    You can change the winding speed by pressing ____ (to decrease) or + (to increase) in the bobbin winding window.
```




- Press to minimize the bobbin winding window. Then, you can perform other operations, such as selecting a stitch or adjusting the thread tension, while the bobbin is being wound.
- Press (in top right of the LCD screen) to display the bobbin winding window again.






Pass the thread through the thread guide.



① Thread guide

6


Pass the thread around the pre-tension disk making sure that the thread is under the pre-tension disk.



- ① Thread guide
- ② Pre-tension disk
- Follow steps 🕝 through 🕕 on page 39 through 40.

■ Using the Spool Stand

To wind thread on the bobbin while the spool stand is installed, pass the thread from the spool through the thread guide on the telescopic thread guide, and then wind the bobbin according to steps (5) through (1) of "Using the Supplemental Spool Pin" on page 38 to page 40.



🏹 Memo


See page 9 to assemble the spool stand.See page 52 to thread the machine using the spool stand.

• When winding thread on the bobbin, do not cross the bobbin winding thread with the upper thread in the thread guides.

Untangling Thread from Beneath the Bobbin Winder Seat

If the bobbin winding starts when the thread is not passed through the pre-tension disk correctly, the thread may become tangled beneath the bobbin winder seat.

Wind off the thread according to the following procedure.




- ① Thread
- ② Bobbin winder seat

CAUTION

• Do not remove the bobbin winder seat even if the thread becomes tangled under the bobbin winder seat. It may result in injuries.


If the thread becomes tangled under the

bobbin winder seat, press stop once to stop the bobbin winding.






Cut the thread with scissors near the pretension disk.




① Pre-tension disk

Push the bobbin winder switch to the right, and then raise the bobbin at least 10 cm (4 inches) from the shaft.



4 Cut the thread near the bobbin and hold the thread end with your left hand. Unwind the thread counter clockwise near the bobbin winder seat with your right hand as shown below.





Wind the bobbin again.

ப் Note


• Make sure that the thread passes through the pre-tension disk correctly (page 38).

Getting Ready 🎇

Setting the Bobbin





video example of the operation on the LCD (see page 34). Follow the steps explained below to complete the operation.



Slide the bobbin cover latch to the right. (1) Bobbin cover 2 Latch \rightarrow The bobbin cover opens. Remove the bobbin cover. Hold the bobbin with your right hand and hold the end of the thread with your left hand. Set the bobbin in the bobbin case so that the thread unwinds to the left. Hold the bobbin lightly with your right 6 hand, and then guide the thread with your left hand.


Press Site.





- Be sure to hold down the bobbin with your finger and unwind the bobbin thread correctly. Otherwise, the thread may break or the thread tension will be incorrect.

B Insert the tab in the lower-left corner of the bobbin cover (1), and then lightly press down on the right side to close the cover (2).




Pulling Up the Bobbin Thread


There may be some sewing applications where you want to pull up the bobbin thread; for example, when making gathers, darts, or doing free motion quilting or embroidery.

🏹 Memo


- You can pull up the bobbin thread after threading the upper thread ("UPPER THREADING" on page 46).
- Guide the bobbin thread through the groove, following the arrow in the illustration.
- * Do not cut the thread with the cutter.
- * Do not replace the bobbin cover.




While holding the upper thread, press the "Needle Position" button to lower the needle.



- ① "Needle Position" button
- Press the "Needle Position" button to raise the needle.
- Gently pull the upper thread. A loop of the bobbin thread will come out of the hole in the needle plate.




5 Pull up the bobbin thread, pass it under the presser foot and pull it about 100 mm (approx. 3-4 inches) toward the back of the machine, making it even with the upper thread.




- ① Upper thread
- ② Bobbin thread







UPPER THREADING



- Turn the main power to ON.
- Press the "Presser Foot Lifter" button to raise the presser foot.




→ The upper thread shutter opens so the machine can be threaded.



① Upper thread shutter


🏹 Memo

- This machine is equipped with an upper thread shutter, allowing you to check that the upper threading is performed correctly.
- Press the "Needle Position" button to raise the needle.



🗸 Note

 If you try to thread the needle automatically without raising the needle, the thread may not thread correctly. Pivot the spool pin so that it angles upward. Set the thread spool on the spool pin so that the thread unwinds from the front of the spool.




- Spool pin
- ② Spool cap
- ③ Thread spool
- ④ Spool felt
- Push the spool cap onto the spool pin as far as possible, then return the spool pin to its original position.

CAUTION

- If the thread spool and/or spool cap are set incorrectly, the thread may tangle on the spool pin and cause the needle to break.
- Use the spool cap (large, medium, or small) that is closest in size to the thread spool. If a spool cap smaller than the thread spool is used, the thread may become caught in the slit on the end of the spool and cause the needle to break.


Memo

• When sewing with fine, cross-wound thread, use the small spool cap, and leave a small space between the cap and the thread spool.




- ① Spool cap (small)
- ② Thread spool (cross-wound thread)
- ③ Space

6 While holding the thread with both hands, pull the thread up from under the thread guide plate.




① Thread guide plate

While holding the thread in your right hand, pass the thread through the thread guide in the direction indicated.




Guide the thread down, up, then down through the groove, as shown in the illustration.




Memo

Look in the upper groove area to check if the thread catches on the take-up lever visible inside the upper groove area.




① Look in the upper groove area


Pass the thread through the needle bar thread guide (marked "6") by holding the thread with both hands and guiding it as shown in the illustration.



- Needle bar thread guide
- Press the "Presser Foot Lifter" button to lower presser foot.




Pass the thread through the thread guide disks (marked "7"). Make sure that the thread passes through the groove in the thread guide.



① Groove in thread guide


Pull the thread up through the thread cutter to cut the thread, as shown in the illustration.



① Thread cutter


🟒 Note

When using thread that quickly winds off the spool, such as metallic thread, it may be difficult to thread the needle if the thread is cut. Therefore, instead of using the thread cutter, pull out about 80 mm (approx. 3 inches) of thread after passing it through the thread guide disks (marked "7").



① 80 mm (approx. 3 inches) or more

13 Press the "Automatic Threading" button to have the machine automatically thread the needle.



 \rightarrow The thread passes through the eye of the needle.


河 Memo

 When the "Automatic Threading" button is pressed, the presser foot will be automatically lowered. After threading is finished, the presser foot moves back to the position before the "Automatic Threading" button was pressed.

14

Carefully pull the end of the thread that was passed through the eye of the needle.

* If a loop was formed in the thread passed through the eye of the needle, carefully pull on the loop of thread through to the back of the needle.




ப் Note

• Pulling the loop of thread gently will avoid needle breakage.

Pull out about 10-15 cm (approx. 4-6 inches) of the thread, and then pass it under the presser foot toward the rear of the machine.

→ Raise the presser foot lever if the presser foot is lowered.




① About 10-15 cm (approx. 4-6 inches)

河 Memo

If the needle could not be threaded or the thread was not passed through the needle bar thread guides, perform the procedure again starting from step 3.
 Then, pass the thread through the eye of the needle after step 2.

VV Note

 Some needles cannot be threaded with the needle threader. In this case, instead of using the needle threader after passing the thread through the needle bar thread guide (marked "6"), manually pass the thread through the eye of the needle from the front.





Using the Twin Needle Mode

The twin needle can only be used for patterns that


show ()) after being selected. Before you select a stitch pattern, make sure the stitch can be sewn in the twin needle mode (refer to the "STITCH SETTING CHART" at the end of this manual).

- Twin needle (part code XE4963-001) is recommended for this machine. Contact your authorized retailer for replacement needles (size 2.0/11 is recommended).
- Be sure to set the twin needle mode when using the twin needle. Using the twin needle while the machine is in single needle mode could cause the needle to break, resulting in damage.
- Do not sew with bent needles. The needle could break and cause injury.
- When using the twin needle, it is recommended to use presser foot "J".
- When the twin needle is used, bunched stitches may occur depending on the types of fabric and thread that are used. Use monogramming foot "N" for decorative stitches.
- Before changing the needle or threading the machine, be sure to press on the LCD Screen, otherwise injuries may occur if the "Start/Stop" button or any other button is pressed and the machine starts sewing.





Beass the thread through the needle bar thread guides on the needle bar, then thread the needle on the left side manually.




① Needle bar thread guide

V Note


 The "Automatic Threading" button cannot be used. Manually thread the twin needle from front to back. Using the "Automatic Threading" button may result in damage to the machine.

Pull up the supplemental spool pin and set it in the up position.




① Supplemental spool pin

5 Place the additional spool of thread on the supplemental spool pin, so that the thread unwinds from the front. Push the spool cap onto the spool pin as far as possible to secure the thread spool.




- ① Spool cap
- ② Spool pin
- ③ Thread spool
- Hold the thread from the spool with both hands, and place the thread in the thread guide.
 - * Do not place the thread in the pre-tension disks.




① Thread guide

While holding the thread from the spool, pull the thread through the lower notch in the thread guide plate, then through the upper notch. Hold the end of the thread with your left hand, and then guide the thread through the groove, following the arrows in the illustration.



Continue threading however do not pass the thread in the needle bar thread guide "6" on the needle bar. Thread the needle on the right side.



- ① Needle bar thread guide
- 9 Press Store .
- 10

Select a stitch pattern. (Example:

- * Refer to the "STITCH SETTING CHART" at the end of this manual for the proper stitch to use with presser foot "J".
- \rightarrow The selected stitch is displayed.
- If the key is light gray after selecting the stitch, the selected stitch cannot be sewn in the twin needle mode.

11 Press	to select the twin needle mode.
	Character Decorative Stitch
	1-05 1-07 1-08 2 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
100%	

- ① Single needle/twin needle setting
 - appears.

• Be sure to set the twin needle mode when using the twin needle. Using the twin needle while the machine is in single needle mode could cause the needle to break, resulting in damage.

12 Start sewing.

Sample of Twin Needle Sewing

W	×××	\bigotimes
mmmm		
WW	×××	X

🆙 Memo

• To change direction when sewing with the twin needle, raise the needle from the fabric, raise the presser foot lever, and then turn the fabric.

Using the Spool Stand

The included spool stand is useful when using thread on spools with a large diameter (crosswound thread). This spool stand can hold two spools of thread.


🏹 Memo

- See page 9 to assemble the spool stand.
- See page 41 to wind the bobbin when using the spool stand.


■ Using the Spool Stand

• Be sure to use a spool cap that is slightly larger than the spool.

If the spool cap that is used is smaller or much larger than the spool, the thread may catch and sewing performance may suffer.



• When using thread on a thin spool, place the included spool felt on the spool pin, place the thread spool on the spool pin so that the center of the spool is aligned with the hole at the center of the spool felt, and then insert the spool cap onto the spool pin.




① Spool felt

• When using thread on a cone spool, use the spool holder.



① Spool holder


• Depending on the size of spool or the amount of thread remaining, choose the appropriate sized spool cap (large or medium). Spool cap (small) cannot be used with the spool cap base.



① Spool cap

② Spool cap base

Attach the spool stand to the machine. (see page 9.)




Place the spool of thread on the spool pin so that the thread feeds off the spool clockwise. Firmly insert the spool cap onto the spool pin.



🟒 Note


- When using 2 spools of thread, make sure that both spools are feeding in the same direction.
- Make sure that the spools do not touch each other, otherwise the thread will not feed off smoothly, the needle may break, or the thread may break or become tangled. In addition, make sure that the spools do not touch the telescopic thread guide at the center.
- Make sure that the thread is not caught under the spool.

Pull the thread off the spool. Pass the thread from the back to the front through the thread guides at the top.



🗸 Note

- Guide the thread so that it does not become entangled with the other thread.
- After feeding the thread as instructed, wind any excess thread back onto the spool, otherwise the excess thread will become tangled.
- Pass the thread through the machine's thread guide from the right to the left.




- ① Thread guide
- Thread the machine according to the steps 6 to 6 of "Upper Threading" on page 46.

Using Threads that Unwind Quickly

Using the Spool Net

If using transparent nylon monofilament thread, metallic thread, or other strong thread, place the included spool net over the spool before using it. When using specialty threads, threading must be done manually.

If the spool net is too long, fold it once to match it to the spool size before placing it over the spool.



🦙 Memo

- When threading the spool with the spool net on, make sure that 5-6 cm (approx. 2 2-1/2 inches) of thread are pulled out.
- It may be necessary to adjust the thread tension when using the spool net.

CHANGING THE PRESSER FOOT

- Always press with on the screen before changing the presser foot. If with is not pressed and the "Start/Stop" button or another button is pressed, the machine will start and may cause injury.
- Always use the correct presser foot for the selected stitch pattern. If the wrong presser foot is used, the needle may strike the presser foot and bend or break, and may cause injury.
- Only use presser feet made for this machine. Using other presser feet may lead to accident or injury.

Removing the Presser Foot

Press ?	\rightarrow	Operation Guide	\rightarrow	Basic Operation	\rightarrow
	,				




➤ [main this order to display a

video example of the operation on the LCD (see page 34). Follow the steps explained below to complete the operation.

0


Press the "Needle Position" button to raise the needle.






- * If the message "OK to automatically lower the presser foot?" appears on the LCD screen, press OK to continue.
- → The entire screen becomes white, and all keys and operation buttons are locked.

Raise the presser foot lever.




Press the black button on the presser foot holder and remove the presser foot.




- ① Black button
- ② Presser foot holder

Attaching the Presser Foot

- Make sure that the presser foot is installed in the correct direction, otherwise the needle may strike the presser foot, breaking the needle and causing injuries.
- Place the new presser foot under the holder, aligning the foot pin with the notch in the holder. Lower the presser foot lever so that the presser foot pin snaps into the notch in the holder.







Raise the presser foot lever.

Attaching the Walking Foot

The walking foot holds the fabric between the presser foot and the feed dogs to feed the fabric. This enables you to have better fabric control when sewing difficult fabrics (such as quilted fabrics or velvet) or fabrics that slip easily (such as vinyl, leather, or synthetic leather).


🟒 Note

- Thread the needle manually when using the walking foot, or only attach the walking foot after threading the needle using the "Automatic Threading" button.
- When sewing with the walking foot, sew at medium to low speeds.


Memo

- The walking foot can only be used with straight or zigzag stitch patterns. Reverse stitches cannot be sewn with the walking foot. Only select straight or zigzag stitch patterns with reinforcement stitches. (see page 62.)
- Follow the steps in "Removing the Presser Foot" on the previous page.
- Loosen the screw of the presser foot holder to remove the presser foot holder.

Set the operation lever of the walking foot so that the needle clamp screw is set between the fork. Position the shank of the walking foot on the presser foot bar.



- ① Operation lever
- ② Needle clamp screw
- ③ Fork
- ④ Walking foot shank
- ⑤ Presser foot bar
- 4 Lower the presser foot lever. Insert the screw, and tighten the screw securely with the screwdriver.




- Use the included screwdriver to tighten the screw securely. If the screw is loose, the needle may strike the presser foot and cause injury.
- Be sure to rotate the handwheel toward you (counterclockwise) to check that the needle does not strike the presser foot. If the needle strikes the presser foot, injury may result.

CHANGING THE NEEDLE


CAUTION

- Always press Site on the screen before changing the needle. If Site is not pressed and the Start/ Stop button or another operation button is pressed accidentally, the machine will start and injury may result.
- Use only sewing machine needles made for home use. Other needles may bend or break and may cause injury.
- Never sew with a bent needle. A bent needle will easily break and may cause injury.




- \rightarrow The entire screen becomes white, and all keys and operation buttons are locked.
- · Before replacing the needle, cover the hole in the needle plate with fabric or paper to prevent the needle from falling into the

Use the screwdriver to turn the screw toward the front of the machine and loosen the screw. Remove the needle.



4 With the flat side of the needle facing the back, insert the new needle all the way to the top of the needle stopper (viewing window) in the needle clamp. Use a screwdriver to securely tighten the needle clamp screw.



- ① Needle stopper
- ② Hole for setting the needle
- ③ Flat side of needle



• Be sure to push in the needle until it touches the stopper, and securely tighten the needle clamp screw with a screwdriver. If the needle is not completely inserted or the needle clamp screw is loose, the needle may break or the machine may be damaged.

Press to unlock all keys and buttons.

About the Needle

The sewing machine needle is probably the most important part of the sewing machine. Choosing the proper needle for your sewing project will result in a beautiful finish and fewer problems. Below are some things to keep in mind about needles.

- The smaller the needle number, the finer the needle. As the numbers increase, the needles get thicker.
- Use fine needles with lightweight fabrics, and thicker needles with heavyweight fabrics.
- To avoid skipped stitches, use ball point needle (golden colored) 90/14 with stretch fabrics.
- To avoid skipped stitches, use ball point needle (golden colored) 90/14 when sewing character or decorative stitches.
- Use needle 75/11 for embroidery. Use ball point needle 75/11 for embroidering patterns with short jump stitches such as alphabet characters when the thread trimming function is turned on.
- Ball point needles (golden colored) 90/14 are not recommended for embroidery, as they may bend or break, causing injury.
- It is recommended that a 90/14 needle should be used when embroidering on heavyweight fabrics or stabilizing products (for example, denim, puffy foam, etc.). A 75/11 needle may bend or break, which could result in injury.
- A home sewing machine needle 75/11 is inserted in the sewing machine.

Fabric/Thread/Needle Combinations

The following table provides information concerning the appropriate thread and needle for various fabrics. Please refer to this table when selecting a thread and needle for the fabric you wish to use.

Fabric type/Application		Thread		
		Туре	Size	Size of needle
Medium weight fabrics	Broadcloth	Cotton thread	60 - 90	
	Taffeta	Synthetic thread	60 - 90	75/11 - 90/14
	Flannel, Gabardine	Silk thread	50	1
Thin fabrics	Lawn	Cotton thread		
	Georgette	Synthetic thread	60 - 90	65/9 - 75/11
	Challis, Satin	Silk thread	50	
Thick fabrics	Denim	Cotton thread	30	90/14 - 100/16
			50	
	Corduroy	Synthetic thread	50 - 60	
	Tweed	Silk thread		
Stretch fabrics	Jersey	Thread for knits	50 - 60	Ball point needle (gold colored) 75/11 - 90/14
	Tricot	•		
Easily frayed fabrics		Cotton thread	50.00	
		Synthetic thread	50 - 90	65/9 - 90/14
		Silk thread	50	1
For top-stitching		Synthetic thread	50 00/14	90/14 - 100/16
		Silk thread	50	50/14 - 100/10

🏹 Memo

• For transparent monofilament nylon thread, always use needle sizes 90/14 or 100/16. The same thread is usually used for the bobbin thread and upper thread.

• Be sure to follow the needle, thread, and fabric combinations listed in the table. Using an improper combination, especially a heavyweight fabric (i.e., denim) with a small needle (i.e., 65/9 - 75/11), may cause the needle to bend or break, and lead to injury. Also, the seam may be uneven, the fabric may pucker, or the machine may skip stitches.



SEWING

- To avoid injury, pay special attention to the needle while the machine is in operation. Keep your hands away from moving parts while the machine is in operation.
- Do not stretch or pull the fabric during sewing. Doing so may lead to injury.
- Do not use bent or broken needles. Doing so may lead to injury.
- Do not attempt to sew over basting pins or other objects during sewing. Otherwise, the needle may break and cause injury.
- If stitches become bunched, lengthen the stitch length setting before continuing sewing. Otherwise, the needle may break and cause injury.


Sewing a Stitch

Turn the main power to ON and press

to display the utility stitches, and

push the "Needle Position" button to raise the needle.


Press the key of the stitch you want to sew.



→ The symbol of the correct presser foot will be displayed in the upper left corner of the LCD screen.

3 Install the presser foot ("CHANGING THE PRESSER FOOT" on page 54).

- Always use the correct presser foot. If the wrong presser foot is used, the needle may strike the presser foot and bend or break, possibly resulting in injury. Refer to page 335 for presser foot recommendations.
- Set the fabric under the presser foot. Hold the fabric and thread in your left hand, and rotate the handwheel to set the needle in the sewing start position.



河 Memo

5

 The black button on the left side of presser foot "J" should be pressed only if the fabric does not feed or when sewing thick seams (see page 64). Normally, you can sew without pressing the black button.

Lower the presser foot.


You do not have to pull up the bobbin thread.

Sewing Basics




Adjust the sewing speed with the speed control slide.

You can use this slide to adjust sewing speed during sewing.




① Slow

2 Fast




Press the "Start/Stop" button to start sewing.

Guide the fabric lightly by hand.




Memo

- When the foot controller is being used, you cannot start sewing by pressing the "Start/ Stop" button.
- Press the "Start/Stop" button again to stop sewing.





Press the "Thread Cutter" button to trim the upper and lower threads.




The needle will return to the up position automatically.

CAUTION

- Do not press the "Thread Cutter" button after the threads have been cut. Doing so could tangle the thread or break the needle and damage the machine.
- Do not press the "Thread Cutter" button when there is no fabric set in the machine or during machine operation. The thread may tangle, possibly resulting in damage.

Note

When cutting thread thicker than #30, nylon monofilament thread, or other decorative threads, use the thread cutter on the side of the machine.





When the needle has stopped moving, raise the presser foot and remove the fabric.

Memo

This machine is equipped with a bobbin thread sensor that warns you when the bobbin thread is almost empty. When the bobbin thread is nearly empty, the machine automatically stops. However, if the "Start/Stop" button is pressed, a few stitches can be sewn. When the warning displays, re-thread the machine immediately.

Using the Foot Controller


You can also use the foot controller to start and stop sewing.

Do not allow fabric pieces and dust to collect in the foot controller. Doing so could cause a fire or an electric shock.

Memo

- When the foot controller is being used, you cannot start sewing by pressing the "Start/ Stop" button.
- The foot controller cannot be used when embroidering.
- The foot controller can be used for sewing utility and decorative stitches when the embroidery unit is attached.


Pull the retractable cord out from the foot controller to the desired length, and then insert the foot controller plug into its jack on the machine.




- ① Foot controller
- Foot controller jack

Vice Note

• Do not pull the retractable cord out beyond the red mark on the cord.





🔊 Memo


 The speed that is set using the sewing speed controller is the foot controller's maximum sewing speed.

Release the foot controller to stop the machine.

Sewing Reinforcement Stitches

Reverse/reinforcement stitches are generally necessary at the beginning and end of sewing. You can use the "Reverse/Reinforcement Stitch" button to sew reverse/reinforcement stitches manually (see page 3).

If the automatic reinforcement stitch is selected on the screen, reverse stitches (or reinforcement stitches) will be sewn automatically at the beginning of sewing when the "Start/Stop" button is pressed. Press the "Reverse/Reinforcement Stitch" button to sew reverse stitches (or reinforcement stitches) automatically at the end of sewing (see page 69).




- ① Reverse stitch
- ② Reinforcement stitch

If the stitch which you select has a double mark """ at the top of the key display, you can sew reverse stitches by holding the "Reverse/ Reinforcement Stitch" button.

If the stitch which you select has a dot mark "•" at the top of the key display, you can sew reinforcement stitches by holding the "Reverse/ Reinforcement Stitch" button.


Sewing Curves

Sew slowly while keeping the seam parallel with the fabric edge as you guide the fabric around the curve.



Changing Sewing Direction


Stop the machine. Leave the needle in the fabric, and press the "Presser Foot Lifter" button to raise the presser foot. Using the needle as a pivot, turn the fabric so that you can sew in the new direction. Press the "Presser Foot Lifter" button to lower the presser foot and start sewing.



The pivot setting is useful when changing the sewing direction. When the machine is stopped at the corner of the fabric, the machine stops with the needle in the fabric and the presser foot is automatically raised so the fabric can easily be rotated ("Pivoting" on page 72).

Sewing a Seam Allowance of 0.5 cm or Less


Baste the corner before sewing, and then, after changing the sewing direction at the corner, pull the basting thread toward the back while sewing.



① 5 mm (approx. 3/16 inch)

Sewing Heavyweight Fabrics

The sewing machine can sew fabrics up to 6 mm (approx. 1/4 inch) thick. If the thickness of a seam causes sewing to occur at an angle, help guide the fabric by hand and sew on the downward slope.




CAUTION

- Do not forcefully push fabrics more than 6 mm (approx. 1/4 inch) thick through the sewing machine. This may cause the needle to break and cause injury.
- Thicker fabrics require a larger needle ("CHANGING THE NEEDLE" on page 56).

■ If the Fabric does not Fit under the Presser Foot

If the presser foot is in the up position, and you are sewing heavyweight or multiple layers of fabric which do not fit easily under the presser foot, use the presser foot lever to raise the presser foot to its highest position. The fabric will now fit under the presser foot.





You cannot use the presser foot lever after the presser foot has been raised using the "Presser Foot Lifter" button.

■ If the Fabric does not Feed

If the fabric does not feed when starting to sew or when sewing thick seams, press the black button on the left side of presser foot "J".


Raise the presser foot.

While keeping the black button on the left side of presser foot "J" pressed in, press the "Presser Foot Lifter" button to lower the presser foot.





Release the black button.



→ The presser foot remains level, enabling the fabric to be fed.

🏹 Memo

- Once the trouble spot has been passed, the foot will return to its normal position.
- When "Automatic Fabric Sensor System" (Automatic Presser Foot Pressure) in the machine settings screen is set to "ON", the thickness of the fabric is automatically detected by the internal sensor so the fabric can be fed smoothly for best sewing results. (see page 73 for details.)

Sewing Hook-and-Loop Fastener

CAUTION

- Do not use adhesive backed hook-and-loop fastener designed for sewing. If the adhesive sticks to the needle or the bobbin hook race, it may cause malfunction.
- If the hook-and-loop fastener is sewn with a fine needle (65/9-75/11), the needle may bend or break.

🟒 Note

• Before starting to sew, baste the fabric and hook-and-loop fastener together.


Make sure that the needle passes through the hook-and-loop fastener by rotating the handwheel and lower the needle into the hook-and-loop fastener before sewing. Sew the edge of the hookand-loop fastener at a slow speed. If the needle does not pass through the hook-andloop fastener, replace the needle with the needle for thick fabrics (page 58).



① Edge of the hook-and-loop fastener

Sewing Lightweight Fabrics

Place thin paper or tear away embroidery stabilizer under thin fabrics to make sewing easier. Gently tear off the paper or the stabilizer after sewing.



① Thin paper


Sewing Stretch Fabrics

First, baste together the pieces of fabric, and then sew without stretching the fabric.

In addition, a better result can be achieved by using thread for knits or a stretch stitch.

🏹 Memo

 For best results when sewing stretch fabrics, decrease the pressure of the presser foot ("Using the Machine Setting Mode Key" on page 22).



① Basting stitching

STITCH SETTINGS

When you select a stitch, your machine automatically selects the appropriate stitch width, stitch length, and upper thread tension. However, if needed, you can change any of the individual settings.

< Note

- Settings for some stitches cannot be changed (refer to the "STITCH SETTING CHART" at the end of this manual).
- If you turn off the machine or select another stitch without saving stitch setting changes ("Saving Your Stitch Settings" on page 81), the stitch settings will return to their default settings.

Setting the Stitch Width

Follow the steps below when you want to change the zigzag stitch pattern width.




🏹 Memo

For an alternate method of changing the stitch width using the speed controller, see page 104.


Example:

Press – to narrow the zigzag stitch pattern width.



 \rightarrow The value in the display gets smaller.

Press + to widen the zigzag stitch pattern width.



 \rightarrow The value in the display gets bigger.

Memo

• Press reser to return the stitch width to the original setting.

🟒 Note

 After adjusting the stitch width, slowly rotate the handwheel toward you (counterclockwise) and check that the needle does not touch the presser foot. If the needle hits the presser foot, the needle may bend or break.


Setting the Stitch Length

Follow the steps below when you want to change the stitch pattern length.




Example:







 \rightarrow The value in the display gets smaller. Press \frown to lengthen the stitch length.



 \rightarrow The value in the display gets bigger.

Memo

- Press is to check changes made to the stitch.
- Press neser to return the stitch length to the original setting.

• If the stitches get bunched together, lengthen the stitch length and continue sewing. Do not continue sewing without lengthening the stitch length. Otherwise, the needle may break and cause injury.


Setting the Thread Tension

You may need to change the thread tension, depending on the fabric and thread being used. Follow the steps below to make any necessary changes.



Proper Thread Tension

The upper thread and the bobbin thread should cross near the center of the fabric. Only the upper thread should be visible from the right side of the fabric, and only the bobbin thread should be visible from the wrong side of the fabric.




- ① Wrong side
- ② Surface
- ③ Upper thread
- ④ Bobbin thread

Upper Thread is Too Tight

If the bobbin thread is visible from the right side of the fabric, the upper thread is too tight.

_レNote

 If the bobbin thread was incorrectly threaded, the upper thread may be too tight. In this case, refer to "Setting the Bobbin" (page 43) and rethread the bobbin thread.




- Bobbin thread
- Upper thread
- ③ Surface
- 4 Locks appear on surface of fabric

Press _____, to loosen the upper thread.

🏹 Memo

• When you finish sewing, remove the bobbin cover and then make sure that the thread is shown as below. If the thread is not shown as below, the thread is not inserted through the tension-adjusting spring of the bobbin case correctly. Reinsert the thread correctly. For details, refer to page 43.




Upper Thread is Too Loose

If the upper thread is visible from the wrong side of the fabric, the upper thread is too loose.

🟒 Note

• If the upper thread was incorrectly threaded, the upper thread may be too loose. In this case, refer to "Upper Threading" (page 46) and rethread the upper thread.



Press +, to tighten the upper thread.

🏹 Memo

• Press ness to return the thread tension to the original setting.

USEFUL FUNCTIONS


Automatic Reinforcement Stitching

After selecting a stitch pattern, turn on the automatic reinforcement stitching function before sewing, and the machine will automatically sew reinforcement stitches (or reverse stitches, depending on the stitch pattern) at the beginning and end of sewing.

Select a stitch pattern.

Press (1) to set the automatic


reinforcement stitching function.




 \rightarrow The key will display as \bigcirc .

🏹 Memo

• Some stitches, such as buttonholes and bar tacks, require reinforcement stitches at the beginning of sewing. If you select one of these stitches, the machine will automatically turn on this function (the key appears



Set the fabric in the start position and start sewing.




- ① Reverse stitches (or reinforcement stitches)
- → The machine will automatically sew reverse stitches (or reinforcement stitches) and then continue sewing.

🏹 Memo

• If you press the "Start/Stop" button to pause sewing, press it again to continue. The machine will not sew reverse/reinforcement stitches again.



Press the "Reverse/Reinforcement Stitch" button.



- ① Reverse stitches (or reinforcement stitches)
- → The machine will sew reverse stitches (or reinforcement stitches) and stop.

🏹 Memo


 To turn off the automatic reinforcement stitching function, press again, so it appears as .

Automatic Thread Cutting

After selecting a stitch pattern, turn on the automatic thread cutting function before sewing, and the machine will automatically sew reinforcement stitches (or reverse stitches, depending on the stitch pattern) at the beginning and end of sewing, and trim the threads at the end of sewing. This function is useful when sewing buttonholes and bar tacks.

Select a stitch pattern.


Press 🔊 to set the automatic thread cutting function.



 \rightarrow The key will display as \gg .

🦙 Memo

 This function is set automatically when sewing embroidery. 3 Set the fabric in the start position and start sewing.




- ① Reverse stitches (or reinforcement stitches)
- → The machine will automatically sew reverse stitches (or reinforcement stitches) and then continue sewing.

🆙 Memo

- If you press the "Start/Stop" button to pause sewing, press the same button again to continue. The beginning reverse/reinforcement stitches will not be sewn again.
- **4** |

Press the "Reverse/Reinforcement Stitching" button.



- ① Reverse stitches (or reinforcement stitches)
- $\rightarrow\,$ The machine will sew reverse stitches (or reinforcement stitches), then trim the thread.

🏹 Memo

• To turn off the automatic thread cutting function, press (R) again, so it appears as

×).

Using the Knee Lifter


Using the knee lifter, you can raise and lower the presser foot with your knee, leaving both hands free to handle the fabric.




Change the operating position of the knee lifter handle before inserting into the machine.

Slide up the knee lifter handle slightly and rotate it while releasing pressure so handle will click into position.


* The knee lifter can be adjusted to three different angles.



- ① Knee lifter handle
- → Rotate knee lifter handle till it clicks into the selected position that is most comfortable for you.




Align the tabs on the knee lifter with the notches in the knee lifter slot on the front of the machine. Insert the knee lifter bar as far as possible.



• Only change position of the knee lifter handle when knee lifter is not on the machine, otherwise the knee lifter may damage the mounting slot on front of the machine.

_レNote

- If the knee lifter bar is not pushed into the mounting slot as far as possible, it may come out during use.
- Use your knee to move the knee lifter bar to the right in order to raise the presser foot. Release the knee lifter to lower the presser foot.



CAUTION


Be sure to keep your knee away from the knee lifter during sewing. If the knee lifter is pushed during machine operation, the needle may break or the thread tension may loosen.

🏹 Memo

• When the presser foot is in the up position, move the knee lifter to the far right and then release to return the presser foot to the down position.


Note **Pivoting** The "Needle Position - UP/DOWN" (3/7 of the settings screen) must be set in the down If the pivot setting is selected, the machine stops position 🔒 1 for the pivot function to be with the needle lowered (in the fabric) and the presser foot is automatically raised to an used. When "Needle Position - UP/DOWN" appropriate height when the "Start/Stop" button is is set in the raised position, (appears pressed. When the "Start/Stop" button is pressed again, the presser foot is automatically lowered as light gray and cannot be used. and sewing continues. This function is useful for • The pivot function can only be used with stopping the machine to rotate the fabric. stitches where presser foot J or N is indicated in the upper-left corner of the screen. If any other stitch is selected, (appears as light gray and is not available. When the pivot setting is selected, the Use the "Presser Foot Lifter" button to make machine starts when the "Start/Stop" button is sure the presser foot is lowered, and then press the "Start/Stop" button to continue pressed or the foot controller is pressed down sewing. even if the presser foot has been raised. Be sure to keep your hands and other items away from the needle, otherwise injuries may occur. beside "Presser Foot Height" in the settings screen are not available and the setting cannot be changed. Memo When the pivot setting is selected, the Select a stitch. height of the presser foot when sewing is stopped can be changed according to the Ē type of fabric being sewn. Press to **Press** () to select the pivot setting. display "Pivoting Height" on 2/7 of the settings screen. Press – or + to select orative Î one of the three heights (3.2 mm, 5.0 mm or Straight stitch (Left) -01 7.5 mm). To raise the presser foot further, J increase the setting. (Normally, 3.2 mm is 1/2 set.) 1-06 *~*3 1-05 1-07 1-08 *8 1-10 1-11 1-12 1-09 ww 3 Pivoting Height 3.2 0 -13 1-14 1-15 500 2 V Free Motion Foot Height 1.0 1-17 -----Q Q Automatic Fabric Sensor System ON 4h × WIDTH I ENGTH TENSION RETRIEVE +++ 4.0 MEMORY 0.0 2.5 mr RESET Vi O The key appears as $(\frown$). CLOSE

Place the fabric under the presser foot with the needle at the starting point of the stitching, and then press the "Start/Stop" button. The machine will begin sewing.




Memo

- If you press the "Start/Stop" button to pause sewing, press it again to continue, reverse stitches (or reinforcement stitches) will not be sewn.
- Press the "Start/Stop" button to stop the machine at the point where the sewing direction changes.



- → The machine stops with the needle in the fabric, and the presser foot is raised.
- Rotate the fabric, and then press the "Start/ Stop" button.



→ The presser foot is automatically lowered, and sewing continues.

Automatic Fabric Sensor System (Automatic Presser Foot Pressure)


The thickness of the fabric is automatically detected and the presser foot pressure is automatically adjusted with an internal sensor while sewing, to insure that your fabric is fed smoothly. The fabric sensor system works continuously while sewing. This function is useful for sewing over thick seams (see page 63), or quilting (see page 102).




Needle Position – Stitch Placement

When the "Needle Position – Stitch Placement" is on, the needle will be partially lowered for precise stitch placement and then press the "Needle Position" button to lower the needle completely. Each press of the "Needle Position" button changes the needle to the next position. When the "Needle Position - Stitch Placement" is turned off, each press of the "Needle Position" button simply raises and then lowers the needle.


- (1) Pointing needle mode is ON
- (2) Pointing needle mode is OFF



* When the needle is nearly lowered by pressing the "Needle Position" button, the feed dogs are lowered. At this time, the fabric can be shifted to finely adjust the needle drop position.



Set "Needle Position – Stitch Placement" to "ON" or "OFF".



Press cLose to return to the original screen.

Locking the Screen

If the screen is locked before starting to sew, the various settings such as the stitch width and stitch length are locked and cannot be changed. This prevents screen settings from accidentally being changed or the machine from being stopped while large pieces of fabric or projects are being sewn. The screen can be locked when sewing utility stitches and character decorative stitches.

- - Select a stitch pattern.

If necessary, adjust any settings such as the stitch width and stitch length.

- Press in to lock the screen settings.
- \rightarrow The key appears as \boxed{m} .



Sew your project.

When you are finished sewing, press main again to unlock the screen settings.

A CAUTION


• If the screen is locked (m), unlock the

screen by pressing main while the screen is locked, no other key can be operated.

• The settings are unlocked when the machine is turned off and on.

Checking the Needle Location in the Screen

Press to use the built-in camera to view the sewing area in the LCD screen. View the location of the needle from 2 different angles and the needle drop position, even if the needle has not actually been lowered.



- $\rightarrow~$ The camera view window appears.
- 1 CLOSE
- ② VIEW ANGLE
- ③ NEEDLE DROP POSITION
- ④ ZOOM


CLOSE


Press this key to close the screen.

VIEW ANGLE

Each press of **VIEW ANGLE** switches the built-in camera between a front view and an angled top view.

NEEDLE DROP POSITION





① Needle drop position

ZOOM

Press Press to enlarge the image in the screen.

Press **Press** again to return the image to its original display size.

🟒 Note

- The camera view window disappears when you start sewing.
- When sewing thick fabrics, the needle drop position indicated in the screen may differ from the actual position.



■ Stitch Selection Screens
Using the Mirror Image Key
■ Using the Image Key
Saving Your Stitch Settings 81
Saving Settings
Retrieving Saved Settings
SEWING THE STITCHES83

Straight Stitches
Changing the Needle Position
(Left or Middle Needle Position Stitches Only)
 Aligning the Fabric with a Mark on the Needle Plate or Bobbin Cover (with Mark)
 Aligning the Fabric with the Vertical Stitch Alignment "V" Foot
 Using the Straight Stitch Needle Plate and the Straight Stitch Foot
Basting
Dart Seam
Gathering
Flat Fell Seam
Pintuck
Zigzag Stitches
Overcasting (Using a Zigzag Stitch)
Appliqué (Using a Zigzag Stitch)91
Patchwork (for Crazy Quilt)
Sewing Curves (Using a Zigzag Stitch)
Cord Guide Bobbin Cover (Using a Zigzag Stitch)
0 0
 Tape Attaching
Overcasting
 Overcasting Using Presser Foot "G"
 Overcasting Using the Side Cutter
 When Sewing Straight Stitches While Using the Side Cutter 98
Quilting
■ Piecing
Quilting
Appliqué103
Quilting with Satin Stitches
Free Motion Quilting
■ Echo Quilting Using the Free Motion Echo
Quilting Foot "E"
 If the Needle Catches Too Much of the Hem Fold
Appliqué 113
Appliqué Sharp Curves114 Appliqué Corners114
Shelltuck Stitches
Scallop Stitches
Crazy Quilting
Fagoting
0 0
Tape or Elastic Attaching 117

Heirloom119
 Hemstitching (1) (Daisy Stitch)
 Sewing Stretch Fabrics
Holder Plate124 our-step Buttonholes
Darning127 Bar Tacks
 Bar Tacks on Thick Fabrics130 Button Sewing
Attaching 4 Hole Buttons
Aulti-directional Sewing (Straight Stitch and Zigzag Stitch)134
Zipper Insertion135
 Centered Zipper

SELECTING UTILITY STITCHES


Stitch Selection Screens

There are 6 categories of Utility Stitches. If a page number such as $\frac{1}{2}$ appears, there is more than one stitch selection screen for that category.


Decorative Stitches

Straight/Overcasting






Heirloom Stitches



Buttonholes/Bar tacks

4-01	4-02	4-03	4-04	4-05	11 11 11 11 11 11 11 11 11 11 11 11 11
4-06	4-07	4-08	4-09	4-10	<u>\$</u> 3
U 4-11	4-12	4-13	4-14	4-15	***
4-16	4-17	4-18	4-19	 4-20	
Ĩ					
4-21	4-22	4-23 ()	4-24 O	4-25 柒	-8-8-

Multi-directional Sewing



Quilting Stitches

Q-01	Q-02	Q-03	Q-04	1/2	WWV WWV
P Q-05 	Q-06		Q-08		<u>\$</u> 3
 -09	Q-10	Q-11	Q-12	F	***
S 9-13	Q-14	Q-15	Q-16		0
TTT	TTT	2-15 2%250			181
Q-17	Q-18	Q-19 《 、 、 、 、	Q-20		40

Selecting a Stitch




Turn the main power to ON and press to display the utility stitches.

→ Either "1-01 Straight stitch (Left)" or "1-03 Straight stitch (Middle)" is selected, depending on the setting selected in the setting screen.



- * Press 💌 to view the next page.
- Press to view previous page.



- ① Preview of the selected stitch
- Stitch selection screen
- ③ Percentage size of view

Press the key of the stitch you want to sew.

memo

• For details on each stitch, refer to the "STITCH SETTING CHART" at the end of this manual.

Using the Mirror Image Key

Depending on the type of utility stitch you select, you may be able to sew a horizontal mirror image of the stitch.

If () is lit when you select a stitch, it will be possible to make a mirror image of the stitch.

Note

 If (i) is light gray after you select a stitch, you cannot create a horizontal mirror image of the selected stitch due to the type of stitch or type of presser foot recommended (this is true of buttonholes, multi-directional sewing, and others).

Press () to create a horizontal mirror image of the selected stitch.

The key will display as 🝈



Mility Stitches






■ Using the Image Key


You can display an image of the selected stitch. You can check and change the colors of the image of the screen.

Press 🔟.

 \rightarrow An image of the selected stitch is displayed.



- Press is to change the thread color of the stitch on the screen.
 - Press Press to display an enlarged image of the stitch.



① Stitch screen

🔊 Memo

- The color changes every time you press
- The units of the stitch display in mm.

🟒 Note

 If stitches are wider or larger than display, press darkened arrows to move the stitch pattern for better visibility.

Press **CLOSE** to go back to the original

screen.

3


Saving Your Stitch Settings

The settings for the zigzag stitch width, stitch length, thread tension, automatic thread cutting, automatic reinforcement stitching, etc., are preset in the machine for each stitch. However, if you have specific settings that you wish to reuse later for a stitch, you can change the settings so that they can be saved for that stitch. Five sets of settings can be saved for a single stitch.

Saving Settings

) Select a stitch. (Example: Character Decorative Stitch î Tanan a series and s **a** 1-01 Straight stitch (Left) . 1 -1/2 <u></u> 1-06 . 1-05 1-07 1-08 ** -09 M 1-10 1-12 1-11 Mr. 13 2222 1-16 14 1-15 WWW. V 1-19 1-20 100% MM ------Q 1111 4 1 U × WIDTH LENGTH TENSION RETRIEVE +++ 4.0 MEMORY 2.5 0.0 mn RESET **b**iO

Specify your preferred settings.



→ The settings are saved and the original screen automatically appears.

🏹 Memo

• If you try to save settings when there are already 5 sets of settings saved for a stitch, the message "The pockets are full. Delete a pattern" will appear. Close the message and delete a setting referring to page 82.


Retrieving Saved Settings




Select a stitch.

ନୁ Memo

 When a stitch is selected, the last settings retrieved are displayed. The last settings retrieved are retained even if the machine was turned off or a different stitch was selected.






B Press the numbered key of the settings to be retrieved.

* Press close to return to the original screen without retrieving settings.

	Utility Stit	ch	Charac Decora Stitch	ter tive			Ĭ	â
			1-01	steps e	lastic 2	igzag		18D
	2		1-05	1-06	1-07	1-08	1/2	
	www		1-09	1-10.	1-11	1-12	9	<>> ₩ ₩
		-		WIDT	н	LENGT	н те	NSION
	1	9		5.0 mm		1.0	1	4.0
	2	0	$\Delta \mathbb{N}$	7.0 mm		2.0	1	4.0
1	3	0		5 .0		1.0	l	4.0
	4							
	5							
	CLOSE			DEL	ETE	ALL		TRIEVE
	Ē		,ð			?	26	i O

Numbered keys



→ The selected settings are retrieved, and the original screen automatically appears.

河 Memo

• To save new settings when there are already 5 sets of settings saved for a stitch, press nerneve. Press the numbered key of

the setting to be deleted. Press DELETE ,


press **CLOSE** and then **MEMORY**. The new setting will be saved in place of the recently deleted setting.

• You can delete all the saved settings by pressing ALL .

SEWING THE STITCHES

Straight Stitches

Stitch	Stitch name	Presser foot	Applications	ons [mm (inch)]		St [r	Twin needle	
			Auto	Manual	Auto	Manual	neeule	
1-01 	Straight stitch (Left)		General sewing, gather, pintuck, etc. Reverse stitch is sewn while pressing "Reverse/ Reinforcement Stitch" button.	0.0 (0)	0.0 - 7.0 (0 - 1/4)	2.5 (3/32)	0.2 - 5.0 (1/64 - 3/16)	ОК (Ј)
1-02 	Straight stitch (Left)		General sewing, gather, pintuck, etc. Reinforcement stitch is sewn while pressing "Reverse/ Reinforcement Stitch" button.	0.0 (0)	0.0 - 7.0 (0 - 1/4)	2.5 (3/32)	0.2 - 5.0 (1/64 - 3/16)	ОК (Ј)
1-03 	Straight stitch (Middle)		General sewing, gather, pintuck, etc. Reverse stitch is sewn while pressing "Reverse/ Reinforcement Stitch" button.	3.5 (1/8)	0.0 - 7.0 (0 - 1/4)	2.5 (3/32)	0.2 - 5.0 (1/64 - 3/16)	ОК (Ј)
1-04	Straight stitch (Middle)		General sewing, gather, pintuck, etc. Reinforcement stitch is sewn while pressing "Reverse/ Reinforcement Stitch" button.	3.5 (1/8)	0.0 - 7.0 (0 - 1/4)	2.5 (3/32)	0.2 - 5.0 (1/64 - 3/16)	ОК (Ј)
1-05 	Triple stretch stitch	J	General sewing for reinforcement and decorative topstitching	0.0 (0)	0.0 - 7.0 (0 - 1/4)	2.5 (3/32)	1.5 - 4.0 (1/16 - 3/16)	ОК (Ј)
1-06 4 4 4	Stem stitch	J	Reinforced stitching, sewing and decorative applications	1.0 (1/16)	1.0 - 3.0 (1/16 - 1/8)	2.5 (3/32)	1.0 - 4.0 (1/16 - 3/16)	ОК (Ј)
1-07 	Decorative stitch	N	Decorative stitching, top stitching	0.0 (0)	0.0 - 7.0 (0 - 1/4)	2.5 (3/32)	1.0 - 4.0 (1/16 - 3/16)	ОК (Ј)
1-08 	Basting stitch		Basting	0.0 (0)	0.0 - 7.0 (0 - 1/4)	20 (3/4)	5 - 30 (3/16 - 1-3/16)	NO



	Ş	
	Ş	
	Ś	
	≶	
	2	
1.1	<	1
1)	

2

① Left needle position

② Middle needle position

① Reverse stitch


Reinforcement stitch

· <

Memo

- If the selected stitch has a double mark """ at the top of the key display, you can sew reverse stitches holding the "Reverse/Reinforcement Stitch" button.
- If the selected stitch has a dot mark "•" at the top of the key display, you can sew reinforcement stitches holding the "Reverse/Reinforcement Stitch" button (see page 62).

Magenti Utility Stitches



"Reverse/Reinforcement Stitch" button to sew reverse stitches (or reinforcement stitches) and trim the thread automatically at


the end of sewing.

Changing the Needle Position (Left or Middle Needle Position Stitches Only)


When you select left or middle needle position

stitches, you can use - and + in the stitch

width display to change the position of the needle. Match the distance from the right edge of the presser foot to the needle with the stitch width, then align the edge of the presser foot with the edge of the fabric during sewing for an attractive finish.



① Stitch width




Example: Left/Middle needle position stitches

Aligning the Fabric with a Mark on the Needle Plate or Bobbin Cover (with Mark)


While sewing, align the edge of the fabric with the 16 mm (approx. 5/8 inch) mark on the needle plate or bobbin cover (with mark) depending on the needle position (left or middle (center) needle position stitches only).

For stitches with a left needle position (Stitch width: 0.0 mm)



- ① Seam
- ② Presser foot
- ③ Centimeters
- ④ Inches
- (5) Needle plate
- 6 16 mm (5/8 inch)

For stitches with a middle (center) needle position (Stitch width: 3.5 mm)




- ① Seam
- ② Presser foot
- ③ Inches
- ④ Bobbin cover (with mark)
- (5) 16 mm (5/8 inch)

Market Utility Stitches

Aligning the Fabric with the Vertical Stitch Alignment "V" Foot

Sew while keeping the right edge of the fabric aligned with a desired position of markings on the vertical stitch alignment "V" foot. You can also use the vertical stitch alignment "V" foot for setting a stitch width using the built-in camera (see page 138).



- Seam
- ② Vertical stitch alignment "V" foot
- ③ Markings


■ Using the Straight Stitch Needle Plate and the Straight Stitch Foot

The straight stitch needle plate and the straight stitch foot can only be used for straight stitches (middle needle position stitches). Use the straight stitch needle plate and the straight stitch foot when sewing thin fabrics or when sewing small pieces which tend to sink into the hole of the regular needle plate during sewing. The straight stitch foot is perfect to reduce puckering on lightweight fabrics. The small opening on the foot provides support for the fabric as the needle travels through the fabric.

CAUTION


- Always use the straight stitch foot in combination with the straight stitch needle plate.
- Press the "Needle Position" button to raise the needle and turn the main power to OFF or press 📲 🕂 .
- Remove the needle and the presser foot holder (see page 55 through 56).
- Remove the flat bed attachment or the embroidery unit if either are attached.

Grasp both sides of the needle plate cover, and then slide it toward you.



Needle plate cover

Grasp the bobbin case, and then pull it out.



① Bobbin case

Use the disc-shaped screw driver included with the machine to unscrew and remove the regular needle plate.



- - Set the straight stitch needle plate in place and use the disc-shaped screw driver to tighten the plate.



(1) Round hole

Note

Align the two screw holes on the needle plate with the two holes on the machine. Use the disc-shaped screw driver included with the machine to secure the screws in the needle plate.

Insert the bobbin case in its original position, and then attach the needle plate cover.




After reinstalling the needle plate cover, select any of the straight stitches.

🏹 Memo

- When using the straight stitch needle plate, all straight stitches become middle needle position stitches. You cannot change the needle position using the width display.
- Always secure the needle plate before inserting the bobbin case into its original position.

CAUTION

- Selecting other stitches will cause an error message to be displayed.
- Slowly rotate the handwheel toward you (counterclockwise) before sewing and make sure that the needle is not contacting the straight stitch foot and straight stitch needle plate.
- Insert needle and attach the straight stitch foot.





② Pin

Start sewing.

* After sewing, make sure to remove the straight stitch needle plate and the straight stitch foot, and reinstall the regular needle plate, the needle plate cover and the presser foot "J".

බ Memo


 To prevent puckering on fine fabrics, use a fine needle, size 75/11, and a short stitch length. For heavier fabrics, use a heavier needle, size 90/14, and longer stitches.

Basting



and attach presser foot "J".

Press the "Reverse/Reinforcement Stitch" button to sew reinforcement stitches, then continue sewing.



memo

- When you use the basting stitch for gathering, do not use a reinforcement stitch at the beginning; you should lift the presser foot, rotate the handwheel toward you (counterclockwise), pull up the bobbin thread and pull a length of top and bobbin thread out from the rear of the machine.
- You can set the stitch length between 5 mm (approx. 3/16 inch) and 30 mm (approx. 1-3/16 inches)



① Between 5 mm (approx. 3/16 inch) and 30 mm (approx. 1-3/16 inches)

Sew while keeping the fabric straight.





End the basting with reinforcement stitches.


Dart Seam

Select

and attach presser foot "J".


Sew a reverse stitch at the beginning of the dart and then sew from the wide end to the other end without stretching the fabric.

* If automatic reinforcement stitching is preset, a reinforcement stitch will automatically be sewn at the beginning of sewing.




① Basting

- Cut the thread at the end leaving 50 mm (approx. 1-15/16 inches), and then tie both ends together.
 - * Do not sew a reverse stitch at the end.






Insert the ends of the thread into the dart with a hand sewing needle.



Iron the dart to one side so that it is flat.




Gathering

Use on waists of skirts, sleeves of shirts, etc.



Select a straight stitch and attach presser foot "J".



Set the stitch length to 4.0 mm (approx. 3/16 inch) and the thread tension to approximately 2.0 (weaker tension).

Sewing Guide



and then


ress GATHERING after pressing

, the stitch length will be set


?

automatically to 4.0 mm (approx. 3/16 inch) and the thread tension will be automatically set to 2.0.


Pull the bobbin and upper threads out by 50 mm (approx. 1-15/16 inches) (see page 45).



- ① Upper thread
- ② Bobbin thread
- ③ About 50 mm (approx. 1-15/16 inches)
- Sew two rows of straight stitches parallel to the seam line, then trim excess thread leaving 50 mm (approx. 1-15/16 inches).




- ① Seam line
- ② 10 to 15 mm (approx. 3/8 inch to 9/16 inch)
- ③ About 50 mm (approx. 1-15/16 inches)
- Pull the bobbin threads to obtain the desired amount of gather, then tie the threads.





Smooth the gathers by ironing them.





Sew on the seam line and remove the basting stitch.

Flat Fell Seam


Use for reinforcing seams and finishing edges neatly.



and attach presser foot "J".


Sew the finish line, then cut half of the seam allowance from the side on which the flat fell seam will lie.

* When the automatic thread cutting and automatic reinforcement stitching are preset, reinforcement stitches will be sewn automatically at the beginning of sewing. Press the "Reverse/Reinforcement Stitch" button to sew a reinforcement stitch and trim the thread automatically at the end of sewing.




- ① About 12 mm (approx. 1/2 inch)
- ② Wrong side

Spread the fabric out along the finish line.




- ② Wrong side
- Lay both seam allowances on the side of the shorter seam (cut seam) and iron them.




① Wrong side

💥 Utility Stitches 💥



Sew a straight stitch along the fold.


* When the automatic thread cutting and automatic reinforcement stitching are preset, reinforcement stitches will be sewn automatically at the beginning of sewing. Press the "Reverse/Reinforcement Stitch" button to sew a reinforcement stitch and trim the thread automatically at the end of sewing.



- ② Wrong side
- ③ Surface

Δ

Iron the folds in the same direction.



Zigzag Stitches

Zigzag stitches are useful for overcasting, appliqué, patchwork, and many other applications.

Select a stitch, and attach presser foot "J".


If the stitch which you select has a double mark """ at the top of the key display, you can sew reverse stitches by holding the "Reverse/Reinforcement Stitch" button.

If the stitch which you select has a dot mark "•" at the top of the key display, you can sew reinforcement stitches by holding the "Reverse/Reinforcement Stitch" button (see page 62).

Stitch	Stitch name	Presser foot	Applications		Stitch width [mm (inch)]	Sti [n	Twin needle	
		1001		Auto	Manual	Auto	Manual	lieeule
1-09	Zigzag stitch		For overcasting, mending. Reverse stitch is sewn while pressing "Reverse/ Reinforcement Stitch" button.	3.5 (1/8)	0.0 - 7.0 (0 - 1/4)	1.4 (1/16)	0.0 - 4.0 (0 - 3/16)	ОК (Ј)
1-10.	Zigzag stitch		For overcasting, mending. Reinforcement stitch is sewn while pressing "Reverse/ Reinforcement Stitch" button.	3.5 (1/8)	0.0 - 7.0 (0 - 1/4)	1.4 (1/16)	0.0 - 4.0 (0 - 3/16)	OK (J)
1-11	Zigzag stitch (right)		Start from right needle position, zigzag sew at left.	3.5 (1/8)	2.5 - 5.0 (3/32 - 3/16)	1.4 (1/16)	0.3 - 4.0 (1/64 - 3/16)	ОК (Ј)
1-12	Zigzag stitch (left)		Start from left needle position, zigzag sew at right.	3.5 (1/8)	2.5 - 5.0 (3/32 - 3/16)	1.4 (1/16)	0.3 - 4.0 (1/64 - 3/16)	ОК (Ј)



Select a stitch.






Attach presser foot "J".

Overcasting (Using a Zigzag Stitch)

Sew the overcasting along the edge of the fabric while positioning the right-hand side needle drop point just outside the edge of the fabric.




① Needle drop position

Appliqué (Using a Zigzag Stitch)

Attach the appliqué material using a temporary spray adhesive or basting, and then sew it.


* Sew a zigzag stitch while positioning the right-hand side needle drop point just outside the edge of the fabric.



Mility Stitches


Patchwork (for Crazy Quilt)

Turn back the desired width of fabric and position it over the lower fabric, then sew so that the stitch bridges both pieces of fabric.




Sewing Curves (Using a Zigzag Stitch)

Shorten the stitch length setting to obtain a fine stitch. Sew slowly, keeping the seams parallel with the fabric edge as you guide the fabric around the curve.




Cord Guide Bobbin Cover (Using a **Zigzag Stitch**)

- Remove the bobbin cover from the machine (see page 43).
- Thread the gimp thread through the hole in the cord guide bobbin cover from top to bottom. Position the thread in the notch at the back of the cord guide bobbin cover.




- ① Notch
- Gimp thread


- Snap the cord guide bobbin cover into place, making sure that the gimp thread can be fed freely.
 - * Make sure there are no restrictions when feeding the thread.



- - Set the zigzag width from 2.0-2.5 mm (approx. 1/16 - 3/32 inch).
- Attach presser foot "N".
- Position the fabric right side up on top of the cord and place the cord to the rear of the machine under the presser foot.



- ① Fabric (right side)
- ② Gimp thread
- Lower the presser foot and start sewing to make a decorative finish.




Elastic Zigzag Stitches

Use elastic zigzag stitches for tape attaching, overcasting, darning, or a wide variety of other uses.

Stitch	Stitch name	Presser	Applications	Stitch width [mm (inch)]			itch length nm (inch)]	Twin needle	
		1001		Auto	Manual	Auto	Manual	neeule	
1-13	2 steps elastic zigzag		Overcasting (medium weight and stretch fabrics), tape and elastic	5.0 (3/16)	1.5 - 7.0 (1/16 - 1/4)	1.0 (1/16)	0.2 - 4.0 (1/64 - 1/16)	ОК (Ј)	
1-14	2 steps elastic zigzag		Overcasting (medium weight and stretch fabrics), tape and elastic	5.0 (3/16)	1.5 - 7.0 (1/16 - 1/4)	1.0 (1/16)	0.2 - 4.0 (1/64 - 1/16)	ОК (Ј)	
1-15 <;; <;; <;;	3 steps elastic zigzag	J	Overcasting (medium, heavyweight and stretch fabrics), tape and elastic	5.0 (3/16)	1.5 - 7.0 (1/16 - 1/4)	1.0 (1/16)	0.2 - 4.0 (1/64 - 1/16)	ОК (Ј)	



Select a stitch.






Attach presser foot "J".

■ Tape Attaching

Stretch the tape flat. While stretching the tape flat, sew the tape to the fabric.



① Tape

Overcasting

Use this stitch to sew overcasting on the edge of stretch fabrics. Sew the overcasting along the edge of the fabric while positioning the right-hand side needle drop point just outside the edge of the fabric.




Magenti Utility Stitches

Overcasting


Use for the edge of seams in skirts or trousers, and the edge of all cuttings. Use presser foot "G", presser foot "J", or the side cutter attachment depending on the kind of overcasting stitch you select.

■ Overcasting Using Presser Foot "G"

Stitch	Stitch name	Presser	Applications	-	Stitch width [mm (inch)]		itch length nm (inch)]	Twin needle
		1001		Auto	Manual	Auto	uto Manual	neeule
	Overcasting stitch	G	Reinforcing of light and medium weight fabrics	3.5 (1/8)	2.5 - 5.0 (3/32 - 3/16)	2.0 (1/16)	1.0 - 4.0 (1/16 - 3/16)	NO
1-17	Overcasting stitch	G	Reinforcing of heavyweight fabric	5.0 (3/16)	2.5 - 5.0 (3/32 - 3/16)	2.5 (3/32)	1.0 - 4.0 (1/16 - 3/16)	NO
1-18	Overcasting stitch	G	Reinforcing of medium, heavyweight and easily friable fabrics or decorative stitching.	5.0 (3/16)	3.5 - 5.0 (1/8 - 3/16)	2.5 (3/32)	1.0 - 4.0 (1/16 - 3/16)	NO



Lower the presser foot so that the presser foot guide is set flush against the edge of the fabric.



Sew along the presser foot guide.

① Guide

• After the stitch width is adjusted, rotate the handwheel toward you (counterclockwise). Check that the needle does not touch the presser foot. If the needle hits the presser foot, the needle may break and cause injury.




① The needle should not touch the center bar


• If the presser foot is raised to its highest level, the needle may strike the presser foot.

■ Overcasting Using Presser Foot "J"


Stitch	Stitch Stitch name		Presser Applications	-	titch width nm (inch)]		itch length nm (inch)]	Twin needle
		1001		Auto	Manual	Auto	Manual	lieeule
1-19	Overcasting stitch		Reinforced seaming of stretch fabric	5.0 (3/16)	0.0 - 7.0 (0 - 9/32)	2.5 (3/32)	0.5 - 4.0 (1/32 - 3/16)	ОК (Ј)
1-20	Overcasting stitch		Reinforcing of medium stretch fabric and heavyweight fabric, decorative stitching	5.0 (3/16)	0.0 - 7.0 (0 - 9/32)	2.5 (3/32)	0.5 - 4.0 (1/32 - 3/16)	ОК (Ј)
	Overcasting stitch		Reinforcement of stretch fabric or decorative stitching	4.0 (3/16)	0.0 - 7.0 (0 - 1/4)	4.0 (3/16)	1.0 - 4.0 (1/16 - 3/16)	ОК (Ј)
	Overcasting stitch		Stretch knit seam	5.0 (3/16)	0.0 - 7.0 (0 - 1/4)	4.0 (3/16)	1.0 - 4.0 (1/16 - 3/16)	NO
	Single diamond overcast		Reinforcement and seaming stretch fabric	6.0 (15/ 64)	1.0 - 7.0 (1/16 - 1/4)	3.0 (1/8)	1.0 - 4.0 (1/16 - 3/16)	ОК (Ј)
1-24	Single diamond overcast		Reinforcement of stretch fabric	6.0 (15/ 64)	1.0 - 7.0 (1/16 - 1/4)	1.8 (1/16)	1.0 - 4.0 (1/16 - 3/16)	ОК (Ј)

Select a stitch and attach presser foot "J".





Sew with the needle dropping slightly off the edge of the fabric.



① Needle drop position

Overcasting Using the Side Cutter

By using the side cutter, you can do overcasting while cutting the fabric.

• Recommended stitches are noted "S" in the lower right corner, therefore sure to only select one of these stitches listed below. Using another stitch may cause the needle to hit the presser foot and break, possibly causing injury.


Note

• Thread the needle manually when using the side cutter, or only attach the side cutter after threading the needle using the "Automatic Threading" button.

Stitch	Stitch name	Presser	Applications		Stitch width [mm (inch)]		itch length nm (inch)]	Twin needle
		1001		Auto	Manual	Auto	Manual	necule
1-25 \$	With side cutter	S	Straight stitch while cutting fabrics	0.0 (0)	0.0 - 2.5 (0 - 3/32)	2.5 (3/32)	0.2 - 5.0 (1/64 - 3/16)	NO
1-26 \$ \$	With side cutter	S	Zigzag stitch while cutting fabrics	3.5 (1/8)	3.5 - 5.0 (1/8 - 3/16)	1.4 (1/16)	0.0 - 4.0 (0 - 3/16)	NO
1-27 >s	With side cutter	S	Overcasting stitch while cutting fabrics	3.5 (1/8)	3.5 - 5.0 (1/8 - 3/16)	2.0 (1/16)	1.0 - 4.0 (1/16 - 3/16)	NO
1-28 S	With side cutter	S	Overcasting stitch while cutting fabrics	5.0 (3/16)	3.5 - 5.0 (1/8 - 3/16)	2.5 (3/32)	1.0 - 4.0 (1/16 - 3/16)	NO
1-29 55555 \$	With side cutter	S	Overcasting stitch while cutting fabrics	5.0 (3/16)	3.5 - 5.0 (1/8 - 3/16)	2.5 (3/32)	1.0 - 4.0 (1/16 - 3/16)	NO

Δ

Select a stitch.




2

Follow the steps on page 54 to remove the presser foot.



Thread the needle (see page 46).

Position the fork on the side cutter's operating lever onto the needle clamp screw.




① Needle clamp screw

② Operating lever


🔊 Memo

• Make sure that the fork of the operating lever is set onto the needle screw firmly.

Position the side cutter so that the side cutter pin is aligned with the notch in the presser foot holder, and then lower the presser foot.




- ① Notch in presser foot holder
- 2 Pin
- \rightarrow The side cutter is attached.
- Raise the presser foot and pull out a long 6 section of the upper thread. Pass it below the presser foot and pull it out in the fabric feed direction.



- ① Presser foot
- Upper thread




Make a cut of approximately 20 mm (approx. 3/4 inch) in the fabric.




(1) 20 mm (approx. 3/4 inch)

Position the fabric so that the right side of 8 the cut is on top of the guide plate and the left side of the cut is underneath the presser foot.



Memo


· If the fabric is not positioned correctly, the fabric will not be cut.



 \rightarrow A seam allowance is cut while the stitching is sewn.

CAUTION

• When using the side cutter, sew between low and mid-speed and do not touch the knives or operation lever of the side cutter while sewing to avoid equipment damage or injury.




Note

 If the width has been adjusted, rotate the handwheel toward you (counterclockwise).
 Check that the needle does not touch the side cutter. If the needle touches the side cutter, it might cause the needle to break.

When Sewing Straight Stitches While Using the Side Cutter


The seam margin should be approximately 5 mm (approx. 3/16 inch).



① Seam margin

🏹 Memo

 The fabric will not be cut if the whole fabric is simply spread out underneath the presser foot guide plate. Set the fabric as explained in step ³ from the previous section, and then start sewing.



- One layer of 13 oz. denim can be cut.
- Clean the side cutter after use to avoid having dust and scraps of thread build up on it.
- Add a small amount of oil as required to the cutting edge of the cutter.

Quilting

You can make beautiful quilts quickly and easily with this machine. When making a quilt, you will find it convenient to use the knee lifter and foot controller to free your hands for other tasks ("Using the Foot Controller" on page 61 and /or "Using the Knee Lifter" on page 71).

The 30 quilting stitches Q-01 through Q-30 and the utility stitches with "P" or "Q" indicated on their key are useful for quilting. The "P" or "Q" at the bottom of the key display indicates that these stitches are intended for ("Q") quilting

and ("P") piecing.

Olitak		Press	er foot	Annellandara		itch width nm (inch)]		itch length nm (inch)]	Twin
Stitch	Stitch name	6		Applications	Auto	Manual	Auto	Manual	needle
Q-01	Piecing stitch (Middle)		C O	Piecework/patchwork	-	_	2.0 (1/16)	0.2 - 5.0 (1/64 - 3/16)	NO
Q-02	Piecing stitch (Right)		ŝ	Piecework/patchwork 6.5 mm (approx. 1/4 inch) right seam allowance	5.50 (7/32)	0.00 - 7.00 (0 - 1/4)	2.0 (1/16)	0.2 - 5.0 (1/64 - 3/16)	NO
Q-03	Piecing stitch (Left)		ŝ	Piecework/patchwork 6.5 mm (approx. 1/4 inch) left seam allowance	1.50 (1/16)	0.00 - 7.00 (0 - 1/4)	2.0 (1/16)	0.2 - 5.0 (1/64 - 3/16)	NO
Q-04 	Hand-look quilting (Middle)		S S	Quilting stitch made to look like hand quilting stitch	3.50	0.00 - 7.00 (0 - 1/4)	2.5 (3/32)	1.0 - 4.0 (1/16 - 3/16)	NO
Q-05 	Basting stitch (Middle)		ŝ	Basting	3.50	0.00 - 7.00 (0 - 1/4)	20 (3/4)	5 - 30 (3/16 - 1-3/16)	NO
Q-06 4 7 7 7	Stem stitch		ŝ	Reinforced stitching, sewing and decorative applications	1.00 (1/16)	1.00 - 3.00 (1/16 - 1/8)	2.5 (3/32)	1.0 - 4.0 (1/16 - 3/16)	NO
Q-07.	Quilting appliqué zigzag stitch		ŝ	Zigzag stitch for quilting and sewing on appliqué quilt pieces	3.50 (1/8)	0.00 - 7.00 (0 - 1/4)	1.6	0.0 - 4.0 (0 - 3/16)	NO
Q-08	Zigzag stitch (Right)		ŝ	Start from right needle position, zigzag sew at left	3.50 (1/8)	2.50 - 5.00 (3/32 - 3/16)	1.6	0.3 - 4.0 (1/64 - 3/16)	NO
Q-09 >	Zigzag stitch (Left)		ŝ	Start from left needle position, zigzag sew at right	3.50 (1/8)	2.50 - 5.00 (3/32 - 3/16)	1.6	0.3 - 4.0 (1/64 - 3/16)	NO
Q-10 <; <> <> <>	2 steps elastic zigzag		ŝ	Overcasting (medium weight and stretch fabrics), tape and elastic	5.00 (3/16)	1.50 - 7.00 (1/16 - 1/4)	1.0 (1/16)	0.2 - 4.0 (1/64 - 1/16)	NO
Q-11	3 steps elastic zigzag		ŝ	Overcasting (medium, heavyweight and stretch fabrics), tape and elastic	5.00 (3/16)	1.50 - 7.00 (1/16 - 1/4)	1.0 (1/16)	0.2 - 4.0 (1/64 - 1/16)	NO
Q-12	Quilting appliqué stitch		ŝ	Quilting stitch for invisible appliqué or attaching binding	2.00	0.50 - 5.00 (1/64 - 3/16)	2.0	1.0 - 4.0 (1/16 - 3/16)	NO
Q-13 	Shell tuck edge		ŝ	Shell tuck edge finish on fabrics	4.00 (3/16)	0.00 - 7.00 (0 - 1/4)	2.5 (3/32)	0.2 - 4.0 (1/64 - 1/16)	NO
Q-14	Blanket stitch		ŝ	Appliqués, decorative blanket stitch	3.50 (1/8)	2.50 - 7.00 (3/32 - 1/4)	2.5 (3/32)	1.6 - 4.0 (1/16 - 3/16)	NO

Stitch	Stitch nome	Press	er foot	Applications		itch width nm (inch)]		itch length nm (inch)]	Twin
Stitch	Stitch name	6	60	Applications	Auto	Manual	Auto	Manual	needle
۹-15 ۲۶۶۶ ۲۶۶۶ ۲	Quilting stippling		Ś	Background quilting	7.00 (1/4)	1.00 - 7.0 (1/16 - 1/4)	1.6 (1/16)	1.0 - 4.0 (1/16 - 3/16)	NO
Q-16	Overcasting stitch		ŝ	Stretch knit seam	5.00 (3/16)	0.00 - 7.00 (0 - 1/4)	4.0 (3/16)	1.0 - 4.0 (1/16 - 3/16)	NO
Q-17 V 7 V 7 V 7 V 7	Tape attaching		Ś	Attaching tape to seam in stretch fabric	5.50	0.00 - 7.00 (0 - 1/4)	1.4	0.2 - 4.0 (1/61 - 3/16)	NO
Q-18	Serpentine stitch		Ś	Decorative stitching and attaching elastic	5.00 (3/16)	1.50 - 7.00 (1/16 - 1/4)	2.0	0.2 - 4.0 (1/64 - 3/16)	NO
Q-19	Feather stitch		ŝ	Fagoting, decorative stitching	5.00 (3/16)	0.00 - 7.00 (0 - 1/4)	2.5 (3/32)	1.0 - 4.0 (1/16 - 3/16)	NO
Q-20	Fagoting cross stitch		ŝ	Fagoting, bridging and decorative stitching	5.00 (3/16)	2.50 - 7.00 (3/32 - 1/4)	2.5 (3/32)	1.0 - 4.0 (1/16 - 3/16)	NO
Q-21 /-^-VV-^.	Couching stitch		ŝ	Decorative stitching, attaching cord and couching	5.00 (3/16)	0.00 - 7.00 (0 - 1/4)	1.2 (1/16)	0.2 - 4.0 (1/64 - 1/16)	NO
Q-22	Patchwork double overlock stitch		ŝ	Patchwork stitches, decorative stitching	5.00 (3/16)	2.50 - 7.00 (3/32 - 1/4)	2.5 (3/32)	1.0 - 4.0 (1/16 - 3/16)	NO
Q-23	Smocking stitch		ŝ	Smocking, decorative stitching	5.00 (3/16)	0.00 - 7.00 (0 - 1/4)	1.6 (1/16)	1.0 - 4.0 (1/16 - 3/16)	NO
Q-24	Rick-rack stitch		Ś	Decorative top stitching	4.00 (3/16)	0.00 - 7.00 (0 - 1/4)	2.5 (3/32)	1.0 - 4.0 (1/16 - 3/16)	NO
Q-25 MMM	Decorative stitch		Ś	Decorative stitching and appliqué	6.00 (15/ 64)	1.00 - 7.00 (1/16 - 1/4)	1.0 (1/16)	0.2 - 4.0 (1/64 - 3/16)	NO
@-26 XXXX	Decorative stitch		ŝ	Decorative stitching	5.50 (3/16)	0.00 - 7.00 (0 - 1/4)	1.6 (1/16)	1.0 - 4.0 (1/16 - 3/16)	NO
Q-27 	Hemstitching		ŝ	Heirloom, decorative hems	5.00 (3/16)	1.50 - 7.00 (1/16 - 1/4)	2.0 (1/16)	1.5 - 4.0 (1/16 - 3/16)	NO
Q-28	Hemstitching		ŝ	Decorative hems and bridging stitch	6.00 (15/ 64)	1.50 - 7.00 (1/16 - 1/4)	2.0 (1/16)	1.5 - 4.0 (1/16 - 3/16)	NO
Q-29	Single diamond overcast		ŝ	Reinforcement and seaming stretch fabric	6.00 (15/ 64)	1.00 - 7.00 (1/16 - 1/4)	3.0 (1/8)	1.0 - 4.0 (1/16 - 3/16)	NO
Q-30	Overcasting stitch		ŝ	Reinforcement of stretch fabric or decorative stitching	4.00 (3/16)	0.00 - 7.00 (0 - 1/4)	4.0 (3/16)	1.0 - 4.0 (1/16 - 3/16)	NO
1-30 	Piecing stitch (Right)		ŝ	Piecework/patchwork 6.5 mm (approx. 1/4 inch) left seam allowance	5.5 (7/32)	0.0 - 7.0 (0 - 1/4)	2.0 (1/16)	0.2 - 5.0 (1/64 - 3/16)	NO
1-31	Piecing stitch (Middle)		c	Piecework/patchwork	_	_	2.0 (1/16)	0.2 - 5.0 (1/64 - 3/16)	NO

Oritati	01111	Presser foot				itch width nm (inch)]		itch length nm (inch)]	Twin
Stitch Stitch name		6		Applications	Auto	Manual	Auto	Manual	needle
1-32 P	Piecing stitch (Left)		ŝ	Piecework/patchwork 6.5 mm (approx. 1/4 inch) left seam allowance	1.5 (1/16)	0.0 - 7.0 (0 - 1/4)	2.0 (1/16)	0.2 - 5.0 (1/64 - 3/16)	NO
1-33 	Hand-look quilting		^o	Quilting stitch made to look like hand quilting stitch	0.0 (0)	0.0 - 7.0 (0 - 1/4)	2.5 (3/32)	1.0 - 4.0 (1/16 - 3/16)	NO
1-34	Quilting appliqué zigzag stitch		ŝ	Zigzag stitch for quilting and sewing on appliqué quilt pieces	3.5 (1/8)	0.0 - 7.0 (0 - 1/4)	1.4 (1/16)	0.0 - 4.0 (0 - 3/16)	NO
1-35 	Quilting appliqué stitch		ŝ	Quilting stitch for invisible appliqué or attaching binding	1.5 (1/16)	0.5 - 5.0 (1/64 - 3/16)	1.8 (1/16)	1.0 - 4.0 (1/16 - 3/16)	NO
1-36 2% 20 Q	Quilting stippling		ŝ	Background quilting	7.0 (1/4)	1.0 - 7.0 (1/16 - 1/4)	1.6 (1/16)	1.0 - 4.0 (1/16 - 3/16)	NO

Memo

• When a stitch pattern in the Quilting Stitches category (Q-02 through Q-30) is selected, a finer stitch width can be set than is available with stitch patterns in other categories. For example: Stitch Q-03 has 57 needle positions and stitch Q-19 has 29 width selections.

V Note

• The width range of stitch setting is only available in the Quilting stitch "Q" quilting category.

Piecing

Sewing two pieces of fabric together is called piecing. When cutting pieces for quilt blocks, make sure the seam allowance is 6.5 mm (approx. 1/4 inch).




Align the edge of the fabric with the edge of the presser foot, and start sewing.

* To sew a 6.5 mm (approx. 1/4 inch) seam allowance

along the left edge of the presser foot with


selected, the width should be set to 5.50 mm (approx. 7/32 inch).



- ① 6.5 mm (approx. 1/4 inch)
- * To sew a 6.5 mm (approx. 1/4 inch) seam allowance

along the left edge of the presser foot with

selected, the width should be set to 1.50 mm (approx. 1/32 inch).



- ① 6.5 mm (approx. 1/4 inch)
- * To change the needle position, use + or in the width display.




🏹 Memo

• Using a straight stitch (middle needle position) makes it easier to sew smoothly (see page 83).

Quilting


Sewing the quilt top, batting, and backing together is called quilting. You can sew the quilt with the walking foot to keep the quilt top, batting, and backing from sliding. The walking foot has a set of feed dogs that move together with the feed dogs in the needle plate during sewing.

For straight line quilting, use the walking foot and the straight stitch needle plate. Always select a straight stitch (middle needle position) when using the straight stitch needle plate.





Attach the walking foot (see page 55).




🟒 Note

• Thread the needle manually when using the walking foot, or only attach the walking foot after threading the needle using the "Automatic Threading" button.

З

Place one hand on each side of the presser foot to hold the fabric secure while sewing.




🏹 Memo

- Sew at slow to medium speed.
- Do not sew in reverse or use stitches that require side ways or reverse feeding. Always check to be sure that your quilting surface is securely basted before beginning to sew. Specialized machine quilt needles and threads are also available for machine quilting.

Appliqué


Trace the pattern onto the appliqué fabric and then cut around it, leaving a 3 to 5 mm (approx. 1/8 to 3/16 inch) seam allowance.



- ① Seam allowance: 3 to 5 mm (approx. 1/8 to 3/16 inch)
- Place a piece of stabilizer cut to the finished size of the appliqué design onto the fabric, and then fold over the seam margin using an iron. Clip curves when necessary.




3 Turn the appliqué over, and attach the stabilizer with basting pins or a basting stitch.







and attach presser foot "J".

5 Use the quilting appliqué stitch to attach the appliqué. Sew around the edge while dropping the needle as close to the edge as possible.







- ① Appliqué
- ② Needle drop position

CAUTION

• Be careful that the needle does not strike a basting pin during sewing. Striking a pin can cause the needle to break, resulting in injury.

You can use the appliqué technique to attach appliqué designs like the three pictured below.



- ① Dresden plate
- ② Stained glass
- ③ Sunbonnet sue

Select

Quilting with Satin Stitches


For better fabric control, use the foot controller to sew with satin stitches. Set the speed control slide to control the stitch width to make subtle changes in the stitch width during sewing.



Attach the foot controller (see page 61).

 $|\hat{s}^{* \sigma}|$ and attach presser foot "J".

Press _____ in the length display to shorten the stitch length.




河 Memo

• The setting will vary according to the kind of fabric and the thickness of the thread, but a length of 0.3 to 0.5 mm (approx. 1/64 to 1/32 inch) is best for satin stitches.

Press to use the speed control slide to control the stitch width.



Set the width control to "ON".



🏹 Memo


• You can use the speed control slide to adjust the stitch width. Use the foot controller to adjust the sewing speed.

Press CLOSE

 \rightarrow The display will return to the original screen.


Start sewing.

You can adjust the stitch width during sewing by moving the sewing speed controller. Slide the lever to the left, and the stitch width becomes narrower. Slide it to the right, the stitch width becomes wider. The size of the width changes equally on both sides of the middle needle position.





1 narrower

2 wider




injuries.






→ The key appears as , the quilting foot is raised to the necessary height, and then the feed dogs are lowered for free motion sewing.



- ① Free motion quilting foot "C"
- → When stitch Q-01 or 1-31 is selected, free motion quilting foot "C" is indicated in the upper-left corner of the screen.


- **Remove the presser foot holder (see page** 55).
- 5 Attach free motion quilting foot "C" at the front with the presser foot holder screw aligned with the notch in the quilting foot.



- ① Presser foot holder screw
- 2 Notch


🗤 Note

- Make sure that the quilting foot is attached properly and not slanted.
- Hold the quilting foot in place with your right hand, and tighten the presser foot holder screw using the screwdriver with your left hand.



① Presser foot holder screw

- Be sure to securely tighten the screws with the included screwdriver. Otherwise, the needle may touch the quilting foot, causing it to bend or break.
- **7** Use both hands to stretch the fabric taut, and then move the fabric at a consistent pace in order to sew uniform stitches roughly 2.0-2.5 mm (approx. 1/16 - 3/32 inch) in length.



① Stitch

Press on to cancel the free motion sewing

mode.

→ Rotate the handwheel toward you (counterclockwise) to raise the feed dogs.

After sewing, make sure to remove the straight stitch needle plate and presser foot "C", and reinstall the regular needle plate and the needle plate cover.

🟒 Note

- Free motion open toe quilting foot "O" can also be used with the straight stitch needle plate. We recommend using free motion open toe quilting foot "O" with free motion sewing of fabrics of uneven thicknesses.
- When using the straight stitch needle plate, all straight stitches become middle needle position stitches. You cannot change the needle position using the width display.

ן Memo

- Normally, the feed dogs are raised for regular sewing.
- Do not be discouraged with your initial results. The technique requires practice.

Using free motion Open Toe Quilting Foot "O"

The free motion open toe quilting foot "O" is used for free motion quilting with zigzag or decorative stitches or for free motion quilting of straight lines on fabric with an uneven thickness. Various stitches can be sewn using free motion open toe quilting foot "O". For details on the stitches that can be used, refer to the "STITCH SETTING CHART" at the end of this manual.




Free motion open toe quilting foot "O"

🏹 Memo

 In order to sew with a balanced tension, it may be necessary to adjust the upper thread tension (see page 67). Test with a sample piece of quilting fabric.

Press 🎯 to set the machine to free motion

sewing mode.




→ The key appears as , the quilting foot is raised to the necessary height, and then the feed dogs are lowered for free motion sewing.




Select a stitch.

🥱 Memo

• When stitch Q-01 or 1-31 is selected, free motion quilting foot "C" is indicated in the upper-left corner of the screen. When the other stitches are selected, free motion open toe quilting foot "O" is indicated in the screen.



Attach free motion open toe quilting foot "O" by positioning the pin of the quilting foot above the needle clamp screw and aligning the lower-left of the quilting foot and the presser bar.



- ① Pin
- ② Needle clamp screw
- ③ Presser bar

V Note

- Make sure that the quilting foot is not slanted.
- Hold the quilting foot in place with your right hand, and tighten the presser foot holder screw using the screwdriver with your left hand.




① Presser foot holder screw

CAUTION

• Be sure to securely tighten the screws with the included screwdriver. Otherwise, the needle may touch the quilting foot, causing it to bend or break.

6 Use both hands to stretch the fabric taut, and then move the fabric at a consistent pace in order to sew uniform stitches roughly 2.0-2.5 mm (approx. 1/16 - 3/32 inch) in length.



1) Stitch

Press on to cancel the free motion sewing mode.

→ Rotate the handwheel toward you (counterclockwise) to raise the feed dogs.

🆙 Memo


• Do not be discouraged with your initial results. The technique requires practice.

Echo Quilting Using the Free Motion Echo Quilting Foot "E"

Sewing quilting lines at equal distances around a motif is called echo quilting. The quilting lines, which appear as ripples echoing away from the motif, are the distinguishing characteristic of this quilting style. Use the free motion echo quilting foot "E" for echo quilting. Using the measurement on the presser foot as a guide, sew around the motif at a fixed interval. We recommend attaching the foot controller and sewing at a consistent speed.



Free motion echo quilting foot "E" measurement



6.4 mm (approx. 1/4 inch)
 9.5 mm (approx. 3/8 inch)


• With free motion quilting, control the feeding speed of the fabric to match the sewing speed. If the fabric is moved faster than the sewing speed, the needle may break or other damage may result.

Memo · When starting to sew, the internal sensor detects the thickness of the fabric, and the quilting foot is raised to the height specified in the machine settings screen. Press to display "Free Motion Foot Height" on 2/7 of the settings screen (see page 22). Press - or + to select the height that the guilting foot is raised above the fabric. Increase the setting by pressing + , for example, when sewing very soft fabric, so that it is easier to sew. Free Motion Foot Height 1.0 **H**+

 In order to sew with a balanced tension, it may be necessary to adjust the upper thread tension (see page 67). Test with a sample piece of quilting fabric.

Select

Press is to set the machine to free motion sewing mode.




→ The key appears as , the quilting foot is raised to the necessary height, then the feed dogs are lowered for free motion sewing.

- **3** Follow the steps on page 54 "Removing the Presser Foot" to remove the presser foot.
- Remove the presser foot holder (see page 55) and the screw.
- Position the free motion echo quilting foot "E" on the left side of the presser bar with the holes in the quilting foot and presser bar aligned.




6 Tighten the screw with the included screwdriver.





 Be sure to securely tighten the screws with the included screwdriver. Otherwise, the needle may touch the quilting foot, causing it to bend or break.



Blind Hem Stitches

Secure the bottoms of skirts and pants with a blind hem. Two stitches are available for blind hem stitching.

Stitch	Stitch name	Presser	Applications	Stitch width [mm (inch)]			itch length nm (inch)]	Twin needle
		1001		Auto	Manual	Auto	Manual	neeule
2-01	Blind hem stitch	R	Blind hem stitching on mediumweight fabrics	0.0 (0)	+3.03.0 (+1/81/8)	2.0 (1/16)	1.0 - 3.5 (1/16 - 1/8)	NO
2-02	Blind hem stitch stretch	R	Blind hem stitching on stretch fabrics	0.0 (0)	+3.03.0 (+1/81/8)	2.0 (1/16)	1.0 - 3.5 (1/16 - 1/8)	NO

З

Sew a blind hem according to the following procedure.

🏹 Memo


• When the size of cylindrical pieces is too small to slide onto the arm or the length is too short, the fabric will not feed and desired results may not be achieved.



Turn the skirt or pants wrong side out.


- ① Right side of fabric
- Bottom edge of fabric

Fold the fabric along the desired edge of the hem, and press.




- * Seen from the side
- ① Wrong side of fabric
- ② Right side of fabric
- ③ Folded edge of hem
- ④ Bottom edge of fabric

Use a chalk to mark on the fabric about 5 mm (3/16 inch) from the edge of the fabric, and then baste it.




- * Seen from the side
-) Wrong side of fabric
- ② Right side of fabric
- ③ Edge of fabric
- ④ Basting stitching
- (5) 5 mm (3/16 inch)


Fold back the fabric inside along the basting line.



- * Seen from the side
- ① Wrong side of fabric
- ② Edge of fabric
- ③ Basting line
- ④ 5 mm (3/16 inch)




10 Position the fabric with the edge of the folded hem against the guide of the presser foot, and then lower the presser foot lever.




- ① Wrong side of fabric
- ② Fold of hem
- ③ Guide

Adjust the stitch width until the needle slightly catches the fold of the hem.



① Needle drop point

When you change the needle drop point, raise the needle, and then change the stitch width.



① Stitch width

Memo


• Blind hem stitches cannot be sewn if the left needle drop point does not catch the fold. If the needle catches too much of the fold, the fabric cannot be unfolded and the seam appearing on the right side of the fabric will be very large, leaving an unattractive finish. If you experience either of these cases, follow the instructions below to solve the problem.

① Free arm

If the Needle Catches Too Much of the Hem Fold

The needle is too far to the left.

Press + to decrease the stitch width so that the needle slightly catches the fold of the hem.




- ① Wrong side of fabric
- ② Right side of fabric


If the Needle does not Catch the Hem Fold


The needle is too far to the right.


Press — to increase the stitch width so that the needle slightly catches the fold of the hem.



② Right side of fabric








- ① Wrong side of fabric
- ② Right side of fabric

Appliqué

Use a temporary spray adhesive, fabric glue or a basting stitch to attach the appliqué to the fabric.

* This will keep the fabric from moving during sewing.






* Adjust the stitch length and width to correspond to the appliqué shape, size, and quality of material (see page 66).


🦙 Memo

• For details on each stitch, refer to the "STITCH SETTING CHART" at the end of this manual.

Attach presser foot "J". Check that the needle drops slightly off the edge of the appliqué, then start sewing.




① Appliqué material



① Needle drop position


Appliqué Sharp Curves


Stop the machine with the needle in the fabric outside the appliqué. Raise the presser foot and turn the fabric a little bit at a time while sewing for an attractive finish to the seam.



Appliqué Corners

Stop the machine with the needle in the right position of the outside (or inside) corner of the appliqué. Raise the presser foot and pivot the fabric to align the fabric edge. Lower the presser foot and continue stitching.





- 1) Outside corner
- ② Inside corner

n Memo

• Placing a lightweight tear away stabilizer beneath the stitching area will improve the stitch placement along the edge of the appliqué fabric.

Shelltuck Stitches

Shelltuck stitches give an attractive appearance of shells along the curve of a collar. This stitch pattern can be used for edging the neckline or sleeves of dresses and blouses.



🏹 Memo

• For details on each stitch, refer to the "STITCH SETTING CHART" at the end of this manual.

Increase the upper thread tension for an attractive scallop finish to the shelltuck


stitches (see page 67).

🏹 Memo

• If the upper thread tension is too weak, the shelltuck stitches will not scallop.




To make rows of shell tuck stitches, fold the fabric in half along the bias.






🚽 🔹 Use a thin fabric.

4 Attach presser foot "J". Set the needle drop point slightly off the edge of the fabric, and start sewing.






① Needle drop position



Unfold the fabric, and iron the tucks to one side.




Memo

• To make shell tucks at the edge of a collar or neckline, follow the pattern's instructions and then use this stitch to make a decorative finish on the collar or neckline.

Scallop Stitches

This wave-shaped satin stitch is called the scallop stitch. Use this stitch to decorate the edges of blouse collars and handkerchiefs or use it as a hem accent.



Crazy Quilting


For a decorative look called "Crazy Quilting", the following stitches can be sewn on top of a pressed seam allowance.




Select a straight stitch and attach presser foot "I".



With the right sides facing each other, sew two pieces of fabric together, and then press open the seam allowance.




- ① Straight stitch
- ② Seam margins
- ③ 6.5 mm (approx. 1/4 inch)
- ④ Wrong side





Place the fabric right side up in the machine, and center the presser foot over the seam when sewing.



① Right side of fabric


Smocking Stitches

Use smocking stitches for decorative sewing on clothes, etc.


- Select a straight stitch and attach presser foot "J".
- Set the stitch length to 4.0 mm (approx. 3/16 inch) and loosen the upper thread tension to approximately 2.0 (see "Setting the Stitch Length" on page 67 and "Setting the Thread Tension" on page 67).
- 3

Pull the bobbin and upper threads out by 50 mm (approx. 1-15/16 inches).

Sew the seams, leaving approximately 10 mm (approx. 3/8 inch) between the seams, then trim excess thread, leaving 50 mm (approx. 1-15/16 inches).




- ① Approximately 10 mm (approx. 3/8 inch)
- Pull the bobbin threads to obtain the desired amount of gather, and then smooth the gathers by ironing them.






Sew the spaces between the straight seams.






Pull out the straight stitch threads.




Fagoting

When there is a space between two fabrics with thread sewn over the space to join the fabrics together, it is called fagoting. Use this stitch when sewing blouses or children's clothes.

- Baste two pieces of fabric onto thin paper, leaving a space of 4 mm (approx. 3/16 inch) between the fabrics.
 - ^{*} If you draw a line down the middle of the thin paper or water-soluble stabilizer, sewing is easier.



Attach presser foot "J". Align the center of the presser foot with the middle of the space between the fabrics and begin sewing.




① Basting stitches

Memo
• Use a thick thread.


paper away.

- 1. When sewing is finished, gently tear the
- Tape or Elastic Attaching
- Select a straight stitch and attach presser foot "J".
- Set the stitch length to 4.0 mm (approx. 3/16 inch), and loosen the upper thread tension to 2.0 (see "Setting the Stitch Length" on page 67 and "Setting the Thread Tension" on page 67).

🏹 Memo




3 Sew two rows of straight stitches on the right side of the fabric, then pull the bobbin thread to create the necessary gather.



🔊 Memo

• Before sewing the straight stitch, rotate the handwheel toward you (counterclockwise) and pull up the bobbin thread. Holding the top and bobbin thread, pull a length of thread out from the rear of the machine. (Be sure that the presser foot is raised.)


Place the tape over the gather, and hold it in place with basting pins.




5 Select	2-13	1-13 <>> <> <> <> <>
-----------------	------	-------------------------------------

🔊 Memo

 For details on each stitch, refer to the "STITCH SETTING CHART" at the end of this manual. Sew over the tape (or elastic).






CAUTION

• Be sure the needle does not strike a basting pin, or any other objects, during sewing. The thread could tangle or the needle could break, causing injury.

Pull out the straight stitch threads.



Heirloom

Hemstitching (1) (Daisy Stitch)

Use for sewing tablecloths, decorative hems, and decorative stitching on shirt fronts.

🏹 Memo

• Use a light to medium weight homespun fabric with a little stiffness.


Insert a type 130/705H, size 100/16 Wing needle.

* This specialty sewing needle is not furnished with your machine. Must be purchased separately.

- The "Automatic Threading" button cannot be used. Thread the wing needle by hand, from front to back. Using the "Automatic Threading" button may result in damage to the machine.
- A more attractive finish can be obtained if you use a "130/705H Wing" needle when sewing these patterns. If using a wing needle and the stitch width has been set manually, check that the needle will not touch the presser foot by carefully rotating the handwheel toward you (counterclockwise) before starting to sew.




Select any stitch between 3-01 and 3-25.




Memo

• For details on each stitch, refer to the "STITCH SETTING CHART" at the end of this manual.




Example: Illustration of finished product



Hemstitching (2) (Drawn Work (1))

Pull out several threads from one area on a piece of fabric to open the area.

* Pull out 5 or 6 threads to leave a 3 mm (approx. 1/8 inch) area open.




Memo

Loosely woven fabrics work best for this.




n Memo

- For details on each stitch, refer to the "STITCH SETTING CHART" at the end of this manual.
- Attach presser foot "N". With the right side of the fabric facing up, sew one edge of the open area.




- Press (1) to create a mirror image of the stitch.
- **5** Match beginning needle drop points on the opposite edge of the open area to keep the stitching symmetrical.



Hemstitching (3) (Drawn Work (2))

- Pull out several threads from both sides of the 4 mm (approx. 3/16 inch) area which are not yet open.
 - * Pull out four threads, leave five threads, and then pull out four threads. The width of five threads is approximately 4 mm (approx. 3/16 inch) or less.




- ① Approx. 4 mm (approx. 3/16 inch) or less
- ② Four threads (pull out)
- ③ Five threads (leave)



🏹 Memo

 For details on each stitch, refer to the "STITCH SETTING CHART" at the end of this manual. 3 Sew the decorative stitch in the center of the five threads created above.



🏹 Memo


 A wing needle can be used for Hemstitching (3).

One-step Buttonholes


With one-step buttonholes, you can make buttonholes appropriate to the size of your button.

Stitch	Stitch name	Presser	Applications		titch width nm (inch)]		itch length nm (inch)]	Twin
		foot		Auto	Manual	Auto	Manual	needle
4-01 0	Narrow rounded buttonhole	A	Buttonhole on light to medium weight fabrics	5.0 (3/16)	3.0 - 5.0 (1/8 - 3/16)	0.4 (1/64)	0.2 - 1.0 (1/64 - 1/16)	NO
4-02	Wide round ended buttonhole	A	Buttonholes with extra space for larger buttons	5.5 (7/32)	3.5 - 5.5 (1/8 - 7/32)	0.4 (1/64)	0.2 - 1.0 (1/64 - 1/16)	NO
4-03	Tapered round ended buttonhole	A	Reinforced waist tapered buttonholes	5.0 (3/16)	3.0 - 5.0 (1/8 - 3/16)	0.4 (1/64)	0.2 - 1.0 (1/64 - 1/16)	NO
4-04	Round ended buttonhole	A	Buttonholes with vertical bar tack in heavyweight fabrics	5.0 (3/16)	3.0 - 5.0 (1/8 - 3/16)	0.4 (1/64)	0.2 - 1.0 (1/64 - 1/16)	NO
4-05 U	Round ended buttonhole	A	Buttonholes with bar tack	5.0 (3/16)	3.0 - 5.0 (1/8 - 3/16)	0.4 (1/64)	0.2 - 1.0 (1/64 - 1/16)	NO
4-06	Round double ended buttonhole	A	Buttonholes for fine, medium to heavyweight fabrics	5.0 (3/16)	3.0 - 5.0 (1/8 - 3/16)	0.4 (1/64)	0.2 - 1.0 (1/64 - 1/16)	NO
4-07	Narrow squared buttonhole	A	Buttonholes for light to medium weight fabrics	5.0 (3/16)	3.0 - 5.0 (1/8 - 3/16)	0.4 (1/64)	0.2 - 1.0 (1/64 - 1/16)	NO
4-08	Wide squared buttonhole	A	Buttonholes with extra space for larger decorative buttons	5.5 (7/32)	3.5 - 5.5 (1/8 - 7/32)	0.4 (1/64)	0.2 - 1.0 (1/64 - 1/16)	NO
4-09	Squared buttonhole	A	Heavy-duty buttonholes with vertical bar tacks	5.0 (7/32)	3.0 - 5.0 (1/8 - 3/16)	0.4 (1/64)	0.2 - 1.0 (1/64 - 1/16)	NO
4-10	Stretch buttonhole	A	Buttonholes for stretch or woven fabrics	6.0 (15/ 64)	3.0 - 6.0 (1/8 - 15/64)	1.0 (1/16)	0.5 - 2.0 (1/32 - 1/16)	NO
4-11	Heirloom buttonhole	A	Buttonholes for heirloom and stretch fabrics	6.0 (15/ 64)	3.0 - 6.0 (1/8 - 15/64)	1.5 (1/16)	1.0 - 3.0 (1/1 - 1/8)	NO
4-12	Bound buttonhole	A	The first step in making bound buttonholes	5.0 (3/16)	0.0 - 6.0 (0 - 15/64)	2.0 (1/16)	0.2 - 4.0 (1/64 - 3/16)	NO
4-13 []	Keyhole buttonhole	A	Buttonholes in heavyweight or thick fabrics for larger flat buttons	7.0 (1/4)	3.0 - 7.0 (1/8 - 1/4)	0.5 (1/32)	0.3 - 1.0 (1/64 - 1/16)	NO
4-14 Ĵ	Tapered keyhole buttonhole	A	Buttonholes in medium to heavy weight fabrics for larger flat buttons	7.0 (1/4)	3.0 - 7.0 (1/8 - 1/4)	0.5 (1/32)	0.3 - 1.0 (1/64 - 1/16)	NO
4-15 []	Keyhole buttonhole	A	Buttonholes with vertical bar tack for reinforcement in heavyweight or thick fabrics	7.0 (1/4)	3.0 - 7.0 (1/8 - 1/4)	0.5 (1/32)	0.3 - 1.0 (1/64 - 1/16)	NO

One-step buttonholes are sewn from the front of the presser foot to the back, as shown below.




- ① Reinforcement stitching
- Select a buttonhole stitch, and attach buttonhole foot "A".
- Mark the position and length of the buttonhole on the fabric.



-) Memo
 - The maximum buttonhole length is about 28 mm (approx. 1-1/16 inches) (diameter + thickness of the button).

Pull out the button holder plate on the presser foot, and insert the button that will be put through the buttonhole. Then tighten the button holder plate around the button.




① Button holder plate

河 Memo

 The size of the buttonhole is determined by the size of the button in the button holder plate.



Align the presser foot with the mark on the fabric, and lower the presser foot.



① Mark on the fabric


Marks on the presser foot

🟒 Note


- Pass the thread underneath the presser foot.
- Slide the outside frame of the buttonhole foot backward as far as possible as shown in the illustration, making sure that there is no gap behind the part of the foot marked "A". If the buttonhole foot is not slid back as far as possible, the buttonhole will not be sewn at the correct size.



Lower the buttonhole lever so that it is positioned behind the metal bracket on the buttonhole foot.



① Buttonhole lever




1 Metal bracket



Gently hold the end of the upper thread, and then start sewing.


* Feed the fabric carefully by hand while the buttonhole is sewn.



→ Once sewing is completed, the machine automatically sews reinforcement stitches, and then stops.

🆙 Memo

- If automatic thread cutting is turned on before you start sewing, both threads are automatically cut after the reinforcement stitches are sewn. If the fabric does not feed (for example, because it is too thick), increase the stitch length setting.
- Insert a pin along the inside of one of the bar tacks, and then insert the seam ripper into the center of the buttonhole and cut towards the pin.




- ① Basting pin
- ② Seam ripper

 When using the seam ripper to open the buttonhole, do not put your hand or finger in the path of the ripper. The ripper may slip and cause injury. Do not use the seam ripper in any other way than how it is intended.

🏹 Memo

• For keyhole buttonholes, use the eyelet punch to make a hole in the rounded end of the buttonhole. Then insert a pin along the inside of one of the bar tacks, insert a seam ripper into the hole made with the eyelet punch, and cut towards the pin.




Sewing Stretch Fabrics

When sewing on stretch fabric with sew the buttonhole stitches over a gimp thread.

Hook the gimp thread onto the back of presser foot "A". Insert the ends into the grooves at the front of the presser foot, and then temporarily tie them there.


or



Upper thread




Lower the presser foot and start sewing.



Memo

- Set the width of the satin stitches to the width of the gimp thread, and set the buttonhole width to be 2-3 times the width of the gimp thread.
- Once sewing is completed, gently pull the gimp thread to remove any slack, and trim off any excess.




Memo

After using the seam ripper to cut open the threads over the buttonhole, trim off the threads.

Odd Shaped Buttons/Buttons that do Not Fit into the Button Holder Plate

Use the markings on the presser foot scale to set the size of the buttonhole. One mark on the presser foot scale equals 5 mm (approx. 3/16 inch).


Add the button diameter and thickness together, and then set the plate at the calculated value.



- (1) Presser foot scale
- (2) Button holder plate
- ③ Completed measurement of diameter + thickness
- ④ 5 mm (approx. 3/16 inch)

Memo

For example, for a button with a diameter of 15 mm (approx. 9/16 inch) and a thickness of 10 mm (approx. 3/8 inch), the scale should be set at 25 mm (approx. 1 inch).



- ① 10 mm (approx. 3/8 inch)
- ② 15 mm (approx. 9/16 inch)

Four-step Buttonholes


You can sew 4-step buttonholes using the following 4 stitches together. You can sew any desired length for the buttonhole when using 4-step buttonholes. 4-step buttonholes are a good option when attaching oversize buttons.

Note


• When changing the stitch settings, make sure that all stitch settings are changed to match.

Stitch	Stitch name	Presser foot	Applications	Stitch width [mm (inch)]			itch length nm (inch)]	Twin needle
		1001		Auto Manual		Auto	Manual	neeule
4-16 [_]	4 steps buttonhole 1	N	Left side of 4 steps buttonhole	5.0 (7/32)	1.5 - 7.0 (1/16 - 1/4)	0.4 (1/64)	0.2 - 1.0 (1/64 - 1/16)	NO
4-17	4 steps buttonhole 2	N	Bar tack of 4 steps buttonhole	5.0 (7/32)	1.5 - 7.0 (1/16 - 1/4)	0.4 (1/64)	0.2 - 1.0 (1/64 - 1/16)	NO
4-18	4 steps buttonhole 3	N	Right side of 4 steps buttonhole	5.0 (7/32)	1.5 - 7.0 (1/16 - 1/4)	0.4 (1/64)	0.2 - 1.0 (1/64 - 1/16)	NO
4-19	4 steps buttonhole 4	N	Bar tack of 4 steps buttonhole	5.0 (7/32)	1.5 - 7.0 (1/16 - 1/4)	0.4 (1/64)	0.2 - 1.0 (1/64 - 1/16)	NO

Four-step buttonholes are sewn as shown below.




Mark the position and length of the buttonhole on the fabric.



① Marks on fabric

Finished stitching




■ Darning

Use darning stitches for mending and other applications.

Stitch	Stitch name	Presser foot	Applications	Stitch width [mm (inch)]			itch length nm (inch)]	Twin needle
		1001		Auto	Manual	Auto	Manual	neeule
4-20 INNN IIIIII UUUI	Darning	A	Darning medium weight fabric	7.0 (1/4)	2.5 - 7.0 (3/32 - 1/4)	2.0 (1/16)	0.4 - 2.5 (1/64 - 1/16)	NO
4-21	Darning	A	Darning heavyweight fabric	7.0 (1/4)	2.5 - 7.0 (3/32 - 1/4)	2.0 (1/16)	0.4 - 2.5 (1/64 - 1/16)	NO

Darning is performed by sewing from the front of the presser foot to the back as shown below.




① Reinforcement stitches

Select a stitch, and attach buttonhole foot "A".



Set the scale to the desired length of the darning.




- ① Presser foot scale
- ② Completed length measurement
- ③ Width 7 mm (approx. 1/4 inch)
- ④ 5 mm (approx. 3/16 inch)

memo

• The maximum length for darning is 28 mm (approx. 1-1/16 inches).

Check that the needle drops at the desired position and lower the presser foot, making sure the upper thread passes underneath the buttonhole foot.




Note


- Pass the thread underneath the presser foot.
- Set the presser foot so that there is no gap behind the section marked with an "A" (the shaded area in the illustration below). If there is a gap, the size of the darning will not be correct.



Lower the buttonhole lever so that it is positioned behind the metal bracket on the buttonhole foot.




① Buttonhole lever



① Metal bracket

5 Gently hold the end of the upper thread, and then press the "Start/Stop" button to start the machine.



→ Once sewing is completed, the machine automatically sews reinforcement stitches, and then stops.

🏹 Memo


 If automatic thread cutting is turned on before you start sewing, both threads are automatically cut after the reinforcement stitches are sewn. If the fabric does not feed (for example, because it is too thick), increase the stitch length setting.


Bar Tacks

Use bar tacks to reinforce areas that will be subject to strain, such as pocket corners.

Stitch Stitch name	Presser foot	Applications		titch width nm (inch)] Manual		itch length nm (inch)] Manual	Twin needle
4-22 Bar tack	A	Reinforcement at opening of pocket, etc.	2.0 (1/16)	1.0 - 3.0 (1/16 - 1/8)	0.4 (1/64)	0.3 - 1.0 (1/64 - 1/16)	NO
1 Select 1 -22		3		ne fabric so t rd you durin			oves
 Attach buttonhole fascale to the length of to sew. If the fact of the length of to sew. If the fact of the length o	etween 5 nm (appr are usua	t f f f f f f f f f f f f f	foc • Sliv foc the ga the pot con	ss the thread	e fram s far as naking part of pot is i r tack	e of the butto s possible as g sure that the the foot mark not slid back will not be sev	nhole shown in ere is no ed "A". If as far as wn to the

5 Lower the buttonhole lever so that it is positioned behind the metal bracket on the buttonhole foot.






① Metal bracket




Gently hold the end of the upper thread and begin sewing.



→ When sewing is completed, the machine will sew reinforcement stitches and stop automatically.

Bar Tacks on Thick Fabrics

Place a piece of folded fabric or cardboard beside the fabric being sewn to level the buttonhole foot and allow for easier and even feeding.



- ② Thick paper
- ③ Fabric

🆙 Memo

 If automatic thread cutting is turned on before you start sewing, both threads are automatically cut after the reinforcement stitches are sewn. If the fabric does not feed (for example, because it is too thick), increase the stitch length setting.

Button Sewing

Buttons with 2 or 4 holes can be attached, using the machine.

Stitch	Stitch name	Presser foot	Applications	Stitch width [mm (inch)]		Stitch length [mm (inch)]		Twin needle
				Auto	Manual	Auto	Manual	neeule
^{4−23}	Button sewing	M	Attaching buttons	3.5 (1/8)	2.5 - 4.5 (3/32 - 3/16)	_	_	NO

Note

• Do not use the automatic thread cutting function when sewing buttons. Otherwise, you will lose the thread ends.


Select \bigcirc^{4-23} .

 \rightarrow The feed dogs are lowered automatically.



Raise the presser foot.

3 Attach button sewing foot "M", slide the button along the metal plate and into the presser foot, and lower the presser foot.



① Button

2 Metal plate

Rotate the handwheel toward you (counterclockwise) to check that the needle goes into each hole correctly.


- * If the needle does not reach the holes on the left side, adjust the stitch width.
- * To attach the button more securely, repeat the process.

5 Gently hold the end of the upper thread and start sewing.

→ The machine stops automatically when sewing is finished.

• Make sure the needle does not strike the button during sewing. The needle may break and cause injury.


6 From the wrong side of the fabric, pull the end of the bobbin thread to pull the upper thread through to the wrong side of the fabric. Tie the two thread ends together and cut the threads.



After the button is attached, select another stitch and rotate the handwheel toward you (counterclockwise) to raise the feed dogs.


Attaching 4 Hole Buttons

Sew the two holes closest to you. Then raise the presser foot and move the fabric so that the needle goes into the next two holes, and sew them in the same way.




Attaching a Shank to the Button

Pull the shank lever toward you before sewing.



① Shank lever

Pull the two ends of the upper thread between the button and the fabric, wind them around the shank, and then tie them firmly together.





Tie the ends of the bobbin thread from the beginning and end of sewing together on the wrong side of the fabric.



• When sewing is completed, be sure to select the other stitch and rotate the handwheel toward you (counterclockwise) to raise the feed dogs.


Cut off any excess thread.


Eyelet

Use this stitch for making belt holes and other similar applications.

Stitch Stitch name	Presser foot	Applications		Stitch width [mm (inch)]		Stitch length [mm (inch)]		Twin needle	
		For making eyelets, holes on		Auto	Manual	Auto	Manual		
Eyelet	N	belts, etc.		7.0 (1/4)	7.0 6.0 5.0 (1/4 15/64 3/16)	7.0 (1/4)	7.0 6.0 5.0 (1/4 15/64 3/16)	NO	
4-25 3/4-25	N	For making star-shaped eyelets on holes.		_	_	_	_	NO	
Select ● or →	•		4	→ Wh	en sewing is fini	shed,	and start sev the machine sev stops automatic	vs	
🔁 Use 🗕 🕂 in eit	her the s	titch width					1	7	1
display or the stitch length display to choose the size of the eyelet.				 Note If the stitch pattern comes out poorly, make adjustments to "SEWING STITCH PAT-TERNS" on page 152. 					
	+ 2	RETRIEVE MEMORY RESET	5		the eyelet pu er of the stitc		o make a hol	e in the	1
 1 * Actual size 1 Large 7 mm (approx. 2 Medium 6 mm (approx. 3 Small 5 mm (approx. 3 Small 5 mm (approx. * Only one size is a 3 Attach monogramm rotate the handwhe (counterclockwise) drop position. 3 Attach monogramm otate the handwhe (counterclockwise) drop position. 1 Needle drop position 	vailable for ning foot teel towar	or ⁴⁻²⁵ ** * N", then d you				P C			

3







- ① Basting stitches
- ② Reverse stitches
- ③ End of zipper opening
- ④ Wrong side

Magnetic Utility Stitches

Press the seam allowance open and attach the zipper with a basting stitch in the middle of each side of the zipper tape.




- ① Basting stitches
- Zipper
- ③ Wrong side
- A Remove presser foot "J". Align the right side of the pin in zipper foot "I" with the presser foot holder, and attach the zipper foot.



- ① Right
- ② Left
- ③ Needle drop position

• When using zipper foot "1", make sure the straight stitch, middle needle position is selected. Rotate the handwheel toward you (counterclockwise) to make sure the needle does not strike the presser foot. If another stitch is selected, the needle will strike the presser foot, causing the needle to break and possibly causing injury.

5 Topstitch 7 to 10 mm (approx. 1/4 to 3/8 inch) from the seamed edge of the fabric, then remove the basting.




CAUTION

• Make sure the needle does not strike the zipper during sewing. If the needle strikes the zipper, the needle may break, leading to injury.

Inserting a Side Zipper

Use for side zippers in skirts or dresses.







V Note

Make sure you sew using the middle needle position.

Attach presser foot "J" and sew straight stitches up to the zipper opening. Change to a basting stitch and sew to the top of the fabric.



- ① Reverse stitches
- ② Wrong side of fabric
- ③ Basting stitches
- ④ End of zipper opening
- Press the seam allowance open and align the folded hem along the teeth of the zipper, while maintaining 3 mm (approx. 1/8 inch) of sewing space.




- ① Zipper pull tab
- ② Wrong side of fabric
- ③ Zipper teeth
- ④ End of zipper opening
- ⑤ 3 mm (approx. 1/8 inch)




Remove presser foot "J".

5 Align the right side of the pin in zipper foot "I" with the presser foot holder, and attach the presser foot.



- ② Left
- ③ Needle drop position

- When using zipper foot "I", make sure the straight stitch, middle needle position is selected. Rotate the handwheel toward you (counterclockwise) to make sure the needle does not strike the presser foot. If another stitch is selected, the needle will strike the presser foot, causing the needle to break and possibly causing injury.
- Set the presser foot in the 3 mm (approx. 1/8 inch) margin.
- Starting from the end of the zipper opening, sew to a point about 50 mm (approx. 2 inches) from the edge of the fabric, then stop the machine.
- Pull down the zipper slider, then continue sewing to the edge of the fabric.




① 50 mm (approx. 2 inches)

② 3 mm (approx. 1/8 inch)


CAUTION

Make sure the needle does not strike the zipper during sewing. If the needle strikes the zipper, the needle may break, leading to injury.

Sclose the zipper, turn the fabric over, and sew a basting stitch.




- ① Front of the skirt (wrong side of fabric)
- ② Basting stitches
- ③ Front of the skirt (right side of fabric)
- ④ Back of the skirt (right side of fabric)
- 10 Remove the presser foot, and reattach it so that the left side of the pin is attached to the presser foot holder.
 - When sewing the left side of the zipper, the needle should drop on the right side of the presser foot.
 When sewing the right side of the zipper, the needle should drop on the left side of the presser foot.



- ① Right
- ② Left
- ③ Needle drop position
- Set the fabric so that the left edge of the presser foot touches the edge of the zipper teeth.
- 2 Sew reverse stitches at the top of the zipper, then continue sewing.
- Stop sewing about 50 mm (approx.
 2 inches) from the edge of the fabric, leave the needle in the fabric, and remove the basting stitches.


Open the zipper and sew the rest of the seam.



- ① Basting stitches
- ② 7 to 10 mm (approx. 1/4 inch to 3/8 inch)
- ③ Reverse stitches
- ④ 50 mm (approx. 2 inches)


Edge Sewing


Using the built-in camera, the width of the area from the edge of the fabric to the stitching line can be measured and set for edge sewing. This function can be used when the edge of the fabric is straight or a gentle curve.



(1) Straight

② Curved







🖓 Utility Stitches 🕮

Place the edge sewing sheet on top of the needle plate cover.

Align the guides on the edge sewing sheet with the sides of the needle plate cover, and then adjust the position of the edge sewing sheet so that its cutout aligns with the edges of the opening for the feed dogs. Position the edge sewing sheet so that there is no gap between it and the edges of the opening for the feed dogs.



- ① Edge sewing sheet
- ② Guides on edge sewing sheet
- ③ Sides of needle plate cover




- Edge sewing sheet
- ② Feed dogs
- ③ Between the feed dogs and the edge sewing sheet

🗸 Note

• If the metal needle plate is visible between the feed dogs and the edge sewing sheet, the fabric may be incorrectly detected by the built-in camera.


א Memo

• Before using the edge sewing sheet, peel off the transparent sheet. After use, affix the edge sewing sheet to the transparent sheet to prevent it from collecting dust.




- ① Transparent sheet
- Set a fully wound bobbin before starting to use the edge sewing feature and built-in camera. If you need to change the bobbin while edge sewing, remove the edge sewing sheet carefully and place it again after changing the bobbin.

Press




- → Depending on the stitch, the straight stitch with the middle (center) needle position is selected, regardless of the preset stitch width.
- * Regardless of the setting selected in the machine settings screen, the brightness of the light changes to "5".



check that the vertical stitch alignment foot "V" is attached and that the edge sewing sheet is positioned, and then press or.




 \rightarrow Then the edge sewing window appears.



① Basting pin

Check that the built-in camera is correctly detecting the fabric.


* Press indicator line and starting point according to the color of the fabric. Each press of this key changes the color of the fabric edge indicator line to red (with a blue starting point), blue (with a black starting point) or black (with a red starting point).



- ① Key for changing the color of the fabric edge indicator line
- ② Fabric edge indicator line

When the Built-In Camera Can Detect the Edge of the Fabric


The fabric edge indicator line appears correctly following the edge of the fabric.



① Fabric edge indicator line

When the Fabric Edge Indicator Line Does Not Appear


The built-in camera cannot detect the edge of the fabric.




Press **close**, and then perform the procedure again starting with step **1**.

When the Fabric Edge Indicator Line Is Not Aligned With the Edge of the Fabric

The fabric edge indicator line that appears is not aligned with the edge of the fabric. The fabric at the beginning of sewing is not straight.





Try to straighten the edge of the fabric at the beginning of sewing (so it is parallel with the edge of the presser foot).




While checking the screen for the distance from the fabric edge to the edge sewing position, move the fabric to the desired position.

* The starting point of the fabric edge indicator line shows the position for the start of sewing. The actual position for the start of sewing is directly below the needle and parallel to the starting point.










- ① Middle needle position
- ② Stitching
- ③ Edge of fabric
- ④ Width of edge sewing

V Note

- Distances between 1.5 mm (about 1/16 inch) and 38.5 mm (about 1-1/2 inches) can be measured. The distance is displayed in the screen in 0.5 mm (about 1/64 inch) increments.
- The distance is displayed in millimeters. However, depending on the measurement setting, it can also be displayed in inches.
- If "-_- mm" appears as the distance and no inch measurement is displayed, the built-in camera is not able to detect the edge of the fabric.
- When a straight stitch is selected, use the scale on the edge sewing sheet as a guide for positioning the fabric for edge sewing.



① Scale on the edge sewing sheet

Lower the presser foot.


 \rightarrow The distance from the edge of the fabric to the seam is set.

🔊 Memo


• If the knee lifter is used to lower the presser foot, the fabric can be held in place with both hands so the fabric does not move when the presser foot is lowered.



Mility Stitches




- → Sewing starts with the set distance to the edge of the fabric maintained.
- * While sewing, use the red scale marks on the vertical stitch alignment foot "V" as a guide to keep a fixed distance from the edge of the fabric.



- ① Red scale marks
- * When sewing starts, a still image from the built-in camera is displayed.

_レNote

• While sewing, do not place anything, including your hands, within 2 mm (about 1/ 16 inch) from the edge of the fabric, otherwise the edge of the fabric cannot be detected correctly. When guiding the fabric with your hands, place them outside of the object-free area and more than 2 mm (about 1/16 inch) from the edge of the fabric.



- ① Approximately 2 mm (about 1/16 inch)
- ② Fabric
- ③ Edge of fabric

13 When sewing is between 1 and 2 cm (about

3/8 and 3/4 inch) from the edge of the fabric, sewing stops automatically and the following message appears. To stop sewing,



* When this message appears, edge sewing (with the seam wizard function) is canceled.



ㅗ Note

• To continue sewing to the edge of the fabric,

do not press cLOSE when the message shown above appears. With the above message displayed, press the "Start/Stop" button to sew.

🏹 Memo

 When edge sewing is finished, store the edge sewing sheet affixed to the transparent sheet in order to prevent it from collecting dust.


Chapter **4** Character/Decorative Stitches

SELECTING STITCH PATTERNS	146
Stitch Selection Screens	147
Selecting Decorative Stitch Patterns/7mm Decorative Stitch Patterns/Satin Stitch Patterns/7mm Satin	
Cross Stitch/Utility Decorative Stitch Patterns	
Alphabet Characters	
Deleting Characters	
Adjusting the Character Spacing	
SEWING STITCH PATTERNS	
Sewing Attractive Finishes	
Basic Sewing	
Making Adjustments	
EDITING STITCH PATTERNS	
	1
Key Functions	
Changing the Size Changing the Length (for 7mm Satin Stitch Patterns Only)	
Creating a Vertical Mirror Image Creating a Horizontal Mirror Image	
Sewing a Pattern Continuously	
Changing Thread Density (for Satin Stitch Patterns Only)	
Returning to the Beginning of the Pattern	
Checking the Image	
checking the mage	
COMBINING STITCH PATTERNS	162
Before Combining	
Before Combining Combining Various Stitch Patterns	
Before Combining Combining Various Stitch Patterns Combining Large and Small Stitch Patterns	
Before Combining Combining Various Stitch Patterns Combining Large and Small Stitch Patterns Combining Horizontal Mirror Image Stitch Patterns	
Before Combining Combining Various Stitch Patterns Combining Large and Small Stitch Patterns Combining Horizontal Mirror Image Stitch Patterns Combining Stitch Patterns of Different Length	
Before Combining Combining Various Stitch Patterns Combining Large and Small Stitch Patterns Combining Horizontal Mirror Image Stitch Patterns Combining Stitch Patterns of Different Length Making Step Stitch Patterns (for 7mm Satin Stitch Patterns Only)	
Before Combining Combining Various Stitch Patterns Combining Large and Small Stitch Patterns Combining Horizontal Mirror Image Stitch Patterns Combining Stitch Patterns of Different Length	162 162 164 165 165 166 168
Before Combining Combining Various Stitch Patterns Combining Large and Small Stitch Patterns Combining Horizontal Mirror Image Stitch Patterns Combining Stitch Patterns of Different Length Making Step Stitch Patterns (for 7mm Satin Stitch Patterns Only) More Examples USING THE MEMORY FUNCTION	162 162 164 165 165 165 166 168 168 169
Before Combining Combining Various Stitch Patterns Combining Large and Small Stitch Patterns Combining Horizontal Mirror Image Stitch Patterns Combining Stitch Patterns of Different Length Making Step Stitch Patterns (for 7mm Satin Stitch Patterns Only) More Examples USING THE MEMORY FUNCTION Stitch Data Precautions	162 162 164 165 165 165 166 168 168 169
Before Combining Combining Various Stitch Patterns Combining Large and Small Stitch Patterns Combining Horizontal Mirror Image Stitch Patterns Combining Stitch Patterns of Different Length Making Step Stitch Patterns (for 7mm Satin Stitch Patterns Only) More Examples USING THE MEMORY FUNCTION Stitch Data Precautions Types of Stitch Data that can be Used	162 162 164 165 165 165 166 168 168 169
Before Combining Combining Various Stitch Patterns Combining Large and Small Stitch Patterns Combining Horizontal Mirror Image Stitch Patterns Combining Stitch Patterns of Different Length Making Step Stitch Patterns (for 7mm Satin Stitch Patterns Only) More Examples USING THE MEMORY FUNCTION Stitch Data Precautions Types of Stitch Data that can be Used Types of USB Devices/Media that can be Used	162 162 164 165 165 165 166 168 168 169 169 169
Before Combining Combining Various Stitch Patterns	162 162 164 165 165 165 166 168 168 169 169 169 169 169
Before Combining Combining Various Stitch Patterns	162 162 164 165 165 165 166 168 168 169 169 169 169 169 169 169 169
Before Combining Combining Various Stitch Patterns	162 162 164 165 165 165 166 168 168 169 169 169 169 169 169 169 169
Before Combining Combining Various Stitch Patterns	162 162 164 165 165 165 166 168 168 169 169 169 169 169 169 169 169
Before Combining Combining Various Stitch Patterns	162 162 164 165 165 165 166 168 169 169 169 169 169 169 169 169
Before Combining Combining Various Stitch Patterns	162 162 164 165 165 166 168 169 169 169 169 169 169 169 169 169 170 171 172 173
Before Combining Combining Various Stitch Patterns	162 162 164 165 165 166 168 169 169 169 169 169 169 169 170 171 172 173 175
Before Combining Combining Various Stitch Patterns	162 162 164 165 165 166 168 169 169 169 169 169 169 170 171 172 173 175 176

SELECTING STITCH PATTERNS



Press , then Character to display the screen below.



- ① Decorative stitch patterns
- ② 7mm decorative stitch patterns. You can set stitch length and width.
- ③ Satin stitch patterns
- ④ 7mm satin stitch patterns. You can set stitch length and width.
- (5) Cross stitch
- 6 Utility decorative stitch patterns
- ⑦ Alphabet characters (gothic font)
- (8) Alphabet characters (handwriting font)
- ③ Alphabet characters (outline)
- 176) Patterns saved in the machine's memory (see page 176)
- ① Patterns saved in USB media (see page 177)
- (2) Patterns saved on the computer (see page 178)


Note

• If the screen is locked (m), unlock the screen by pressing m. While the screen is locked, no other key can be operated.

Stitch Selection Screens

There are 9 categories of Character/Decorative stitch patterns. If a page number such as 1/2 appears, there is more than one stitch selection screen for that category.

Decorative Stitch Patterns




7mm Satin Stitch Patterns



Alphabet Characters (Gothic Font)



7mm Decorative Stitch Patterns



Cross Stitch

XX

Alphabet Characters

(Handwriting Font)

D

I

N

8

R

C

7

6

9

9

CLOSE

10-08 *****

10-14 XXXXX 10-15 X 10-16 10-17

 \mathcal{B} С

Q

,

A

F 8 H

R L M

P

U U 10 X

Z

X

10-09 10-10 10-05

10-11

*

10-12

XXXXXX

CLOSE

abc


0~9,.

&?!


ÄÅä

ÔÖö

Satin Stitch Patterns



Utility Decorative Stitch Patterns









A	B	C	D	E	ABC
F	G	Ħ	I	J	abc
ĸ	L	M	N	0	0-9,.
P	Q	R	5	T	8?!
U	V	W	*	Y	-
\mathbb{Z}	9				ÄÅä
	_		CL	OSE	ÔÖö



Selecting Decorative Stitch Patterns/7mm Decorative Stitch Patterns/Satin Stitch Patterns/7mm Satin Stitch Patterns/ Cross Stitch/Utility Decorative Stitch Patterns




- to sew.
- * Press 💌 to view the next page.
- * Press 🚺 to view the previous page.
- Touch the bar that appears between and and to leap multiple pages at one time.
- To select a different stitch pattern, press
 When the current stitch pattern is erased, select the new stitch pattern.




 \rightarrow The selected pattern is displayed.

Alphabet Characters

Example: Entering "Blue Sky".







🔊 Memo

 There are three fonts for alphabet character stitching.



Press to change the selection screens.





Remove the jumping stitches after sewing.

S.



If you want to continue entering characters in a different font, press , and then repeat from step 1.

Deleting Characters




Press **DELETE** to delete the last character.



🏹 Memo

• Characters are deleted individually starting with the last character entered.


2 Select the correct character.




Adjusting the Character Spacing

The space between the characters can be adjusted.

Press SPACING.



 \rightarrow The character spacing window appears.



* Press + to increase the character spacing and press – to decrease the character spacing.

Example:

Each setting equals a specific distance between characters.

0

1

2

3

4

5

6

7

8

9 10 mm

0

0.18

0.36

0.54

0.72


0.9

1.08

1.26 1.44

1.62

1.8



\sim	Momo
- 1/21	WEIIIO

- The default setting is "0". No number less than "0" can be set.
 - Changing character spacing by this method, pertains to all characters. Spacing changes are valid not only while entering characters but also before and after the entering of characters.


SEWING STITCH PATTERNS

Sewing Attractive Finishes

To achieve attractive results when sewing character/decorative stitches, check the table below for the proper fabric/needle/thread combinations.


🟒 Note


- Other factors, such as fabric thickness, stabilizer material, etc., also have an effect on the stitch, so you should always sew a few trial stitches before beginning your project.
- When sewing satin stitch patterns, there may be shrinking or bunching of stitches, so be sure to attach a stabilizer material.
- Guide the fabric with your hand to keep the fabric feeding straight and even during sewing.



Basic Sewing

- Select a stitch pattern.
 - Attach monogramming foot "N".
- **3** Place the fabric under the presser foot, pull the upper thread out to the side, and then lower the presser foot.





CAUTION


• When sewing 7 mm satin stitch patterns and the stitches are bunched, lengthen the stitch length. If you continue sewing when the stitches are bunched, the needle may bend or break ("Setting the Stitch Length" on page 67).

Memo

 If the fabric is pulled or pushed during sewing, the pattern may not turn out correctly. Also, depending on the pattern, there may be movement to the left and right as well as front and back. Guide the fabric with your hand to keep the fabric feeding straight and even during sewing.


Press the "Start/Stop" button to stop sewing.

Press the "Reverse/Reinforcement Stitch" button to sew reinforcement stitches.



Memo

When sewing character stitches, the machine automatically sews reinforcement stitches at the beginning and end of each character.



· When sewing is completed, trim any excess thread between letters.



Note


When sewing some patterns, the needle will temporarily pause in the raised position while the fabric is fed due to the operation of the needle bar separation mechanism which is used in this machine. At such times, a clicking sound different from the sound generated during sewing will be heard. This sound is normal and is not the sign of a malfunction.


Making Adjustments


Your stitch pattern may sometimes turn out poorly, depending on the type or thickness of fabric, the stabilizer material used, sewing speed, etc. If your sewing does not turn out well, sew trial stitches using the same conditions as the real sewing, and adjust the stitch pattern as explained below. If the pattern does not turn out well even after making

pattern, make adjustments based on the

adjustments for each pattern individually.








EDITING STITCH PATTERNS


Key Functions

You can create just the finish you want using the editing functions. Make patterns larger or smaller, make mirror images, etc.

ட Note

• Some editing functions cannot be used with certain stitch patterns. Only the functions for the displayed keys are available when a pattern is selected.





÷

No.	Display	Key Name	Explanation	Page			
100%		Pattern display size	Show the approximate size of the pattern selected.				
	10070		100% : Nearly the same size as the sewn pattern				
			50% : 1/2 the size of the sewn pattern				
			25% : 1/4 the size of the sewn pattern				
			* The actual size of the sewn pattern may differ depending on the type of				
_			fabric and thread that is used.				
2		Pivot key	Press this key to select the pivot setting. When the pivot setting is selected, stopping the machine lowers the needle and slightly raises the presser foot automatically. In addition, when sewing is restarted, the presser foot is automatically lowered.	72			
			 If this key appears as , the pivot function cannot be used. Be sure the needle position on page 3 of Machine Settings is set to the down page? 				
0		Free motion mode key	position.	105			
3		Free motion mode key	n mode key Press this key to enter free motion sewing mode. The feed dog is lowered and presser foot is raised to a height appropriate for free motion quilting.				
4	C	Automatic reinforcement stitch key	Press this key to turn on the automatic reinforcement stitching mode.	69			
5	×	Automatic thread cutting key	Press this key to turn on the automatic thread cutting mode.	69			
6	DELETE	Delete key	When you make a mistake selecting a stitch pattern, use this key to delete the mistake. When you make a mistake in combining stitch patterns, use this key to delete stitch patterns.	148, 150			
7	WIDTH LENGTH	Stitch width and stitch length key	Shows the stitch width and stitch length of the selected stitch pattern. The machine default settings are highlighted.	66-67			
8	TENSION BBR	Thread tension key	Shows the thread tension setting for the selected stitch pattern. The machine default settings are highlighted	67			
9	MEMORY	Memory key	Use this key to save stitch pattern combinations.	171-173			
10	D 3	Elongation key	When 7mm satin stitch patterns are selected, press this key to choose from 5 automatic length settings, without changing the stitch zigzag width or stitch length settings.	157			
1		Needle mode selection key (Single/Double)	Press this key to choose single needle sewing or twin needle sewing.	49			
12	LS	Size selection key	Use this key to select the size of the stitch pattern (large, small).	157			
13		Vertical mirror image key	After selecting the stitch pattern, use this key to create a vertical mirror image of the stitch pattern.	157			
14		Horizontal mirror image key	After selecting the stitch pattern, use this key to create a horizontal mirror image of the stitch pattern.	158			
15		Single/Repeat sewing key	Press this key to choose single stitches or continuous stitches.	158			
16	Unon	Back to beginning key	When sewing is stopped, press this key to return to the beginning of the pattern.	159			
17		Image key	Press this key to display an enlarged image of the selected stitch pattern.	160			
18	Â	Home key	Press this key to return to the home page screen.	14			
19	Ē	Screen lock key	Press this key to lock the screen. When the screen is locked, the various settings, such as the stitch width and stitch length, are locked and cannot be changed. Press this key again to unlock the settings.	74			
20		Thread density key	After selecting the stitch pattern, use this key to change the thread density of the pattern.	158			
2)	SPACING	Character spacing key	Press this key to change the spacing of character patterns.	150			

Changing the Size

Select a stitch pattern, then press (us) to change the size of the stitch pattern. The stitch pattern will be sewn in the size highlighted on the key.



Memo

- If you continue entering stitch patterns after changing the size, those patterns will also be sewn in that size.
- You cannot change the size of combined stitch patterns once the stitch pattern is entered.

Actual Stitch Pattern Size

The size differs depending on the fabric and threads. *



Changing the Length (for 7mm Satin Stitch Patterns Only)

When 7mm satin stitch patterns are selected, press () to choose from 5 automatic length settings, without changing the stitch zigzag width or stitch length settings.








Creating a Vertical Mirror Image

To create a vertical mirror image, select a stitch pattern then press ().




Creating a Horizontal Mirror Image

To create a horizontal mirror image, select a stitch pattern then press (...).




Sewing a Pattern Continuously

Press is to select continuous sewing or single stitch sewing.



Changing Thread Density (for Satin Stitch Patterns Only)

After selecting a satin stitch pattern, press **(1)** to select your preferred thread density.



 If the stitches bunch when thread density is changed to is , return the thread density to

If you continue sewing when the stitches are bunched, the needle may bend or break.

🔊 Memo

• Even if you select a new pattern after changing the thread density, the thread density remains the same until you change it.

• You cannot change thread density for a combined pattern after additional patterns are added.

Returning to the Beginning of the Pattern

When sewing character/decorative stitches, you can return to the beginning of the pattern after trial sewing or when the stitching is sewn incorrectly.


Press the "Start/Stop" button to stop the

machine, a	and th	en pro	ess	Lacas .	•
Utility Stitch	Character Decorative Stitch			100001 100001	
+ V	ak		d	e	ABC
	f	9 h	<i>i</i>	j	abc
Q	k	l m	n	0	0-9,.
8		<u>q</u> r	S	t	&?!
me	<u>u</u> \	/ W ,	×	У	ÄÅä
100%			CLO	DSE	ÔÖö
	60			0	
\scriptstyle	-	CHOR	***		
WIDTH	LENGTH		SION	ING	1 100
= <u>+</u>	-	+ 3	3 +] _	
mm	mm .	- 4	-		IEMORY
	.0ª		?		

→ Sewing returns to the beginning of the selected pattern ("W") from the point where sewing was stopped.

🌈 Memo

• If this key is pressed when sewing is stopped, patterns can be added at the end of a combined stitch pattern. (In this example, "!" is added.)




2

Press the "Start/Stop" button to continue sewing.


Checking the Image

You can display an approximate size image of the selected stitch pattern. You can also check and change the colors of the image on the screen.




 \rightarrow An image of the selected pattern is displayed.

Press **I** to change the thread color in the image to red, blue, or black.




 \rightarrow The color changes every time you press the button.

Press Press at the enlarged image.



① Displays the approximate size of the pattern

Use A / I / A / I for view any part of the image that extends out of the viewable display area.



Press close to return to the original screen.

Memo

5

- You can also sew from this screen when the presser foot symbol is displayed.
- Image of some patterns will display in default size only.

COMBINING STITCH PATTERNS


You can combine many varieties of stitch patterns, such as character stitches, cross stitches or satin stitches. You can also combine stitch patterns of different sizes, mirror image stitch patterns, and others.


Before Combining

Single stitch sewing is automatically selected for sewing combined patterns. If you want to sew the


pattern continuously, press after finishing the stitch pattern combination.


When changing sizes, creating mirror images, or making other adjustments to a combined stitch pattern, be sure to edit the selected stitch pattern before selecting the next one. You cannot edit a stitch pattern once the next stitch pattern is selected.














6








 \rightarrow The entered pattern is repeated.

Making Step Stitch Patterns (for 7mm Satin Stitch Patterns Only)

You can use the 🕜 🕥 keys with 7mm satin stitch patterns to create a step effect.

Stitch patterns sewn so that they create a step effect are called step stitch patterns.


- * Press *i* to move the stitch pattern a distance equal to half of the stitch pattern's size to the left.
- * Press **y** to move the stitch pattern a distance equal to half of the stitch pattern's size to the right.



Example:








5

 $\rightarrow\,$ The entered pattern is repeated.



USING THE MEMORY FUNCTION

Stitch Data Precautions

Observe the following precautions when using stitch data other than that created and saved in this machine.

■ Types of Stitch Data that can be Used

• In the Character/Decorative Stitch memory, ".pmx" and ".pmu" stitch data files can be used with this machine. ".pmu" stitch data files can be retrieved; however, when the machine is used to save the file, it is saved as a ".pmx" stitch data file. Using data other than that created using this machine or the machine which create ".pmu" data file, may cause the machine to malfunction.

■ Types of USB Devices/Media that can be Used

Stitch data can be saved to or recalled from USB external media. Use external media that meets the following specifications.

- USB Flash drive (USB Flash memory)
- USB Floppy disk drive

Stitch data can be recalled only from;

• USB CD-ROM, CD-R, CD-RW drives

You can also use the following types of USB media with the USB Memory Card Reader/USB card writer module.

- Secure Digital (SD) Card
- CompactFlash
- Memory Stick
- Smart Media
- Multi Media Card (MMC)
- XD-Picture Card

Vie Note

- Some USB media may not be usable with this machine. Please visit our website for more details.
 The access lamp will begin blinking after inserting USB Devices/Media, and it will take about 5 to 6 seconds to recognize the Devices/Media. (Time will differ depending on the USB Device/Media).
- To create file folders, use a computer.

Computers and Operating Systems with the Following Specifications can be Used

- Compatible models: IBM PC with a USB port as standard equipment IBM PC-compatible computer equipped with a USB port as standard equipment
- Compatible operating systems: Microsoft Windows 2000/XP/Vista

Precautions on Using the Computer to Create and Save Data

- If the name of the stitch data file/folder cannot be identified, for example, because the name contains special characters, the file/folder is not displayed. If this occurs, change the name of the file/folder. We recommend using the 26 letters of the alphabet (uppercase and lowercase), the numbers 0 through 9, "-", and "_".
- Stitch data in a folder created in USB media can be retrieved.
- Do not create folders in "Removable Disk" on a computer. If stitch data is stored in a folder in "Removable Disk", that stitch data cannot be retrieved by the machine.

Trademarks

- Secure Digital (SD) Card is a registered trademark or a trademark of SD Card Association.
- CompactFlash is a registered trademark or a trademark of Sandisk Corporation.
- Memory Stick is a registered trademark or a trademark of Sony Corporation.
- Smart Media is a registered trademark or a trademark of Toshiba Corporation.
- Multi Media Card (MMC) is a registered trademark or a trademark of Infineon Technologies AG.
- xD-Picture Card is a registered trademark or a trademark of Fuji Photo Film Co. Ltd.
- IBM is a registered trademark or a trademark of International Business Machines Corporation.
- Microsoft and Windows are registered trademarks or trademarks of Microsoft Corporation.

Each company whose software title is mentioned in this manual has a Software License Agreement specific to its proprietary programs.

All other brands and product names mentioned in this manual are registered trademarks of their respective companies. However, the explanations for markings such as [®] and TM are not clearly described within the text.

Before disconnecting the USB cable, click the "Unplug or Eject Hardware" icon in the taskbar of Windows[®] 2000 or the "Safely Remove Hardware" icon in the taskbar of Windows[®] XP/Windows Vista[®]. Then, when the removable disk can safely be removed, disconnect the USB cable from the computer and the machine.

Windows[®] XP



Windows Vista[®]



Saving Stitch Patterns in the Machine's Memory

You can save often used stitch patterns in the machine's memory. A total of about 1 MB of stitch patterns can be saved in the machine's memory.


Vote

• Do not turn the main power to OFF while the "Saving" screen is displayed. You will lose the stitch pattern you are saving.


memo

- It takes a few seconds to save a stitch pattern.
- See page 176 for information on retrieving a saved stitch pattern.





* Press close to return to the original screen without saving.




→ The "Saving" screen is displayed. When the pattern is saved, the display returns to the original screen automatically.

■ If the Memory is Full


If the following screen appears while you are trying to save a pattern on the machine's memory, the memory is too full to hold the currently selected stitch pattern. To save the stitch pattern in the machine's memory, you have to delete a previously saved stitch pattern.

Press DELETE .


* Press **CANCEL** to return to the original screen without saving.



- 2 Choose a stitch pattern to delete.
 - * Press close if you decide not to delete the stitch pattern.








 \rightarrow A confirmation message appears.



* If you decide not to delete the stitch pattern, press



→ The machine deletes the stitch pattern, then automatically saves the new stitch pattern.

Saving Stitch Patterns to USB Media

When sending stitch patterns from the machine to USB media, plug the USB media into the machine's top USB port.


🏹 Memo

- USB media is commercially available, but some USB media may not be usable with this machine. Please visit our website for more details.
- Depending on the type of USB media being used, either directly plug the USB device into the machine's USB port or plug the USB media Reader/Writer into the machine's USB port.
- The USB media can be inserted or removed at any time.



2 Insert

Insert the USB media into the primary (top) USB port on the machine.




- ① Primary (top) USB port for media
- ② USB media

🗸 Note

- The processing speed may vary by port selection and quantity of data. You can also plug a USB media into the center port, but the primary (top) USB port will process the data faster. It is recommended to use the primary (top) USB port.
 - Two USB media cannot be used with this machine at the same time. If two USB media are inserted, only the USB media inserted first is detected.

- Press <
 - * Press **close** to return to the original screen without saving.



→ The "Saving" screen is displayed. When the pattern is saved, the display returns to the original screen automatically.

Viv Note

Do not insert or remove USB media while "Saving" screen is displayed. You will lose some or all of the pattern you are saving.

Saving Stitch Patterns in the Computer

Using the included USB cable, the machine can be connected to your computer, and the stitch patterns can be temporarily retrieved from and saved in the "Removable Disk" folder in your computer. A total of about 3 MB of stitch patterns can be saved in the "Removable disk", but the saved stitch patterns are deleted when the machine is turned OFF.


Note

• Do not turn the main power to OFF while the "Saving" screen is displayed. You will lose the stitch pattern you are saving.

Plug the USB cable connector into the corresponding USB ports for the computer and for the machine.

Turn on your computer and select "Computer (My computer)".

* The USB cable can be plugged into the USB ports on the computer and machine whether or not they are turned on.



- ① USB port for computer
- ② USB cable connector
- → The "Removable Disk" icon will appear in "Computer (My computer)" on the computer.

- The connectors on the USB cable can only be inserted into a port in one direction. If it is difficult to insert the connector, do not insert it with force and check the orientation of the connector.
- For details on the position of the USB port on the computer (or USB hub), refer to the instruction manual for the corresponding equipment.

Press



4 Press

Press close to return to the original screen without saving.



→ The stitch pattern will be temporarily saved to "Removable Disk" under "Computer (My computer)".

Vote



Select the stitch pattern's .pmx file and

🗸 Note

5

Do not turn off the machine while the "Saving" screen is showing. You may lose the data.

Retrieving Stitch Patterns from the Machine's Memory







 \rightarrow The pocket selection screen appears.

Choose a stitch pattern to retrieve.

- * If the entire saved stitch pattern is not displayed, press the thumbnail.
- * Press **CLOSE** to return to the original screen without saving.



- ① Saved stitch patterns
- 3 Press RETRIEVE .



Press DELETE to delete the stitch pattern.


→ The selected stitch pattern is retrieved and the sewing screen will be displayed.

Recalling from USB Media

You can recall a specific stitch pattern from either direct USB media or a folder in the USB media. If the stitch pattern is in a folder, check each folder to find the stitch pattern.




Insert the USB Media into the primary (top) USB port on the machine (see page 173).



① Primary (top) USB port for media

② USB media






→ Stitch patterns and a folder in a top folder are displayed.

3

Press when there is a subfolder to

sort two or more stitch patterns to USB media, the stitch pattern in the subfolder is displayed.

* Press **cuss** to return to the original screen without recalling.




- ① Folder name
- ② Stitch patterns in a folder show only the first pattern of any combined patterns.
- ③ Path
- \rightarrow The path shows the current folder at the top of the list.

Stitch patterns and a subfolder within a folder are displayed.

- * Press 🔃 to return to the previous folder.
- * Use the computer to create folders. Folders cannot be created with the machine.




Press the key of the stitch pattern you want to recall.



Press RETRIEVE .

* Press to delete the stitch pattern. The pattern will be deleted from the USB media.



→ The selected stitch pattern is recalled and the sewing screen will be displayed.

Recalling from the Computer

Plug the USB cable connector into the corresponding USB ports for the computer and for the machine (see page 175).

On the computer, open "Computer (My computer)" then go to "Removable Disk".



3 M

Move/copy the pattern data to "Removable Disk".

And in case of the local division of the loc	-	Contraction of the local division of the loc			
Corporation of Vienes of V	Plana	Date modified	Тури	Sone . This folder is engety.	
					þ.
Folden					

→ Stitch pattern data in "Removable Disk" is written to the machine.

Vote

- While data is being written, do not disconnect the USB cable.
- Do not create folders within "Removable Disk". Since folders are not displayed, stitch pattern data within folders cannot be recalled.






→ The stitch patterns in the computer are displayed on the selection screen.


5 Press the key of the stitch pattern you want to recall.

* Press **close** to return to the original screen without recalling.



		_
6	Press	RETRIEVE


 Press to delete the stitch pattern.
 The pattern will be deleted from the "Removable Disk" folder in your computer.



→ The selected stitch pattern is recalled and the sewing screen will be displayed.

🟒 Note

• The pattern recalled from the computer is only temporarily written to the machine. It is erased from the machine when the machine is turned off. If you wish to keep the stitch pattern, store it in the machine ("Saving Stitch Patterns in the Machine's Memory" on page 171).




Embroidery Step by Step
Copyright Information
Selecting Alphabet Character Patterns
Selecting Frame Patterns
Selecting Patterns from Embroidery Cards
About Embroidery Card Reader (Sold Separately) and USB Card Writer Module* About Embroidery Cards (Sold Separately)
VIEWING THE SEWING SCREEN 195
Key Functions
PREPARING THE FABRIC
Attaching Iron-on Stabilizers (Backing) to the Fabric197
Hooping the Fabric in the Embroidery Frame
Types of Embroidery Frames 199
 Inserting the Fabric
Embroidering Small Fabrics or Fabric Edges202
Embroidering Small Fabrics
ATTACHING THE EMBROIDERY FRAME 203
Removing the Embroidery Frame
CONFIRMING THE PATTERN POSITION
CONFIRMING THE PATTERN POSITION 205
CONFIRMING THE PATTERN POSITION

ADJUSTMENTS DURING THE EMBROIDERY PROCESS221
If the Bobbin Runs Out of Thread
If the Thread Breaks During Sewing 222
Restarting from the Beginning 223
Resuming Embroidery After Turning Off the Power
MAKING EMBROIDERY ADJUSTMENTS
Adjusting Thread Tension
Correct Thread Tension
Upper Thread is Too Tight225 Upper Thread is Too Loose
Adjusting the Alternate Bobbin Case
(with No Color on the Screw)
Correct Tension226
 Bobbin Thread is Too Loose
Using the Automatic Thread Cutting Function
(END COLOR TRIM)
Using the Thread Trimming Function (JUMP STITCH TRIM) 228
Selecting the Length of Jump Stitch Not to Trim
Adjusting the Embroidery Speed 229
Changing the Thread Color Display 229
Changing the Embroidery Frame Display
REVISING THE PATTERN232
Changing the Pattern Position
Aligning the Pattern and the Needle
Changing the Size234
Rotating the Pattern 235
Creating a Horizontal Mirror Image
Changing the Density
(Alphabet Character and Frame Patterns Only)
Changing the Colors of Alphabet Character Patterns
Embroidering Linked Characters
Embroidering Linked Characters
Embroidering Linked Characters 239 Uninterrupted Embroidering (Using a Single Color) 241 USING THE MEMORY FUNCTION 242 Embroidery Data Precautions 242 Types of Embroidery Data that can be Used 242 Types of USB Devices/Media that can be Used 242 Computers and Operating Systems 243 Precautions on Using the Computer to Create and Save Data 243 Tajima (dst) Embroidery Data 243 Tajima demarks 243
Embroidering Linked Characters 239 Uninterrupted Embroidering (Using a Single Color) 241 USING THE MEMORY FUNCTION 242 Embroidery Data Precautions 242 Types of Embroidery Data that can be Used 242 Computers and Operating Systems with the Following Specifications can be Used 243 Precautions on Using the Computer to Create and Save Data 243 Tajima (dst) Embroidery Data 243 Saving Embroidery Patterns in the Machine's Memory. 244 If the Memory is Full 245
Embroidering Linked Characters 239 Uninterrupted Embroidering (Using a Single Color) 241 USING THE MEMORY FUNCTION 242 Embroidery Data Precautions 242 Types of Embroidery Data that can be Used 242 Computers and Operating Systems 243 Precautions on Using the Computer to Create and Save Data 243 Tajima (dst) Embroidery Data 243 Tajima (dst) Embroidery Data 243 Saving Embroidery Patterns in the Machine's Memory 244
Embroidering Linked Characters 239 Uninterrupted Embroidering (Using a Single Color) 241 USING THE MEMORY FUNCTION 242 Embroidery Data Precautions 242 Types of Embroidery Data that can be Used 242 Types of USB Devices/Media that can be Used 242 Computers and Operating Systems with the Following Specifications can be Used 243 Tajima (dst) Embroidery Data 243 Saving Embroidery Patterns in the Machine's Memory. 244 Saving Embroidery Patterns to USB Media. 245
Embroidering Linked Characters 239 Uninterrupted Embroidering (Using a Single Color) 241 USING THE MEMORY FUNCTION 242 Embroidery Data Precautions 242 Types of Embroidery Data that can be Used 242 Computers and Operating Systems 243 With the Following Specifications can be Used 243 Tajima (.dst) Embroidery Data 243 Taigima (.dst) Embroidery Data 243 Saving Embroidery Patterns in the Machine's Memory. 244 Saving Embroidery Patterns to USB Media 247 Saving Embroidery Patterns in the Computer. 248
Embroidering Linked Characters 239 Uninterrupted Embroidering (Using a Single Color) 241 USING THE MEMORY FUNCTION 242 Embroidery Data Precautions 242 Types of Embroidery Data that can be Used 242 Types of USB Devices/Media that can be Used 242 Computers and Operating Systems 243 Precautions on Using the Computer to Create and Save Data 243 Tajma (.dst) Embroidery Data 243 Saving Embroidery Patterns in the Machine's Memory 244 If the Memory is Full 245 Saving Embroidery Patterns to USB Media 247 Saving Embroidery Patterns in the Computer 248 Retrieving Patterns from the Machine's Memory 249 Recalling from USB Media 250
Embroidering Linked Characters 239 Uninterrupted Embroidering (Using a Single Color) 241 USING THE MEMORY FUNCTION 242 Embroidery Data Precautions 242 Types of Embroidery Data that can be Used 242 Computers and Operating Systems 243 Precautions 243 Precautions OUsing the Computer to Create and Save Data 243 Tajima (dst) Embroidery Data 243 Saving Embroidery Patterns in the Machine's Memory. 244 Saving Embroidery Patterns in the Computer 245 Saving Embroidery Patterns in the Computer 247 Saving Embroidery Patterns in the Machine's Memory. 244 Saving Embroidery Patterns to USB Media 247 Saving Embroidery Patterns from the Machine's Memory
Embroidering Linked Characters 239 Uninterrupted Embroidering (Using a Single Color) 241 USING THE MEMORY FUNCTION 242 Embroidery Data Precautions 242 Types of Embroidery Data that can be Used 242 Topes of Suborices/Media that can be Used 242 Computers and Operating Systems 243 With the Following Specifications can be Used 243 Trajemarks 243 Traidemarks 243 Taima (dst) Embroidery Data 244 If the Memory is Full 243 Saving Embroidery Patterns in the Machine's Memory 244 If the Memory is Full 245 Saving Embroidery Patterns to USB Media 247 Saving Embroidery Patterns in the Computer 248 Retrieving Patterns from the Machine's Memory 249 Recalling from USB Media 250 Recalling from USB Media 252 EMBROIDERY APPLICATIONS 254
Embroidering Linked Characters 239 Uninterrupted Embroidering (Using a Single Color) 241 USING THE MEMORY FUNCTION 242 Embroidery Data Precautions 242 Types of Embroidery Data that can be Used 242 Computers and Operating Systems 243 With the Following Specifications can be Used 243 Tajima (dst) Embroidery Data 243 Tajima (dst) Embroidery Data 243 Saving Embroidery Patterns in the Machine's Memory. 244 Saving Embroidery Patterns in the Computer 243 Retrieving Patterns from the Machine's Memory. 244 Recalling from USB Media 245 Recalling from the Computer 250 Recalling from the Computer 252

BEFORE EMBROIDERING

Embroidery Step by Step

Follow the steps below to prepare the machine for embroidery.



Step #	Aim	Action	Page
1	Presser foot attachment	Attach embroidery foot "W".	183
2	Checking the needle	Use needle 75/11 for embroidery. *	58
3	Embroidery unit attachment	Attach the embroidery unit.	184
4	Bobbin thread setup	For the bobbin thread, wind embroidery bobbin thread and set it in place.	37
5	Fabric preparation	Attach a stabilizer material to the fabric, and hoop it in the embroidery frame.	197
6	Pattern selection	Turn the main power to ON, and select an embroidery pattern.	186
7	Embroidery frame attachment	Attach the embroidery frame to the embroidery unit.	203
8	Checking the layout	Check and adjust the size and position of the embroidery.	205
9	Embroidery thread setup	Set up embroidery thread according to the pattern.	46

* It is recommended that a 90/14 needle should be used when embroidering on heavy weight fabrics or stabilizing products (for example; denim, puffy foam, etc.). Ball point needle (golden colored) 90/14 is not recommended for embroidery.


Attaching Embroidery Foot "W"

Press
$$? \rightarrow$$
 Operation Guide \rightarrow Embroidery $-$

video example of attaching embroidery foot "W" (see page 34). Follow the steps explained below to complete the operation.

- When attaching a presser foot, always press on the screen. You may accidentally press the "Start/Stop" button and possibly cause injury.
- Be sure to use embroidery foot "W" when doing embroidery. Using another presser foot may cause the needle to strike the presser foot, causing the needle to bend or break and possibly cause injury.

Press the "Needle Position" button to raise the needle.






→ The entire screen becomes white, and all keys and operation buttons are locked.



Raise the presser foot lever.



4 Push the black button on the presser foot holder and remove the presser foot.




- ① Black button
- ② Presser foot holder
- → Remove the presser foot from the presser foot holder.

5 Use the included screwdriver to loosen the screw of the presser foot holder, then remove the presser foot holder.




- $\textcircled{1} \quad \text{Screwdriver}$
- ② Presser foot holder
- ③ Presser foot holder screw
- $\rightarrow\,$ Remove the presser foot holder.
- 6 Position embroidery foot "W" on the presser foot bar so that the arm of embroidery foot "W" is behind the needle holder and the wiper is behind the needle.



- ① Arm
- ② Needle holder
- ③ Presser foot holder screw
- ④ Wiper

7 Hold the embroidery foot in place with your right hand, and then use the included screwdriver to securely tighten the presser foot holder screw.



• Use the included screwdriver to firmly tighten the screw of the presser foot holder. If the screw is loose, the needle may strike the presser foot and possibly cause injury.

Press 📲 to unlock all keys and buttons.

→ All keys and operation buttons are unlocked, and the previous screen is displayed.

Attaching the Embroidery Unit

Press ?	\rightarrow	Operation Guide]→[Embroidery Basic Operation
Martin	\rightarrow	🗯 📔 in thi	s orde	er to display

video example of attaching the embroidery unit (see page 34). Follow the steps explained below to complete the operation.

а


About the Embroidery Unit

- Do not move the machine with the embroidery unit attached. The embroidery unit could fall off and cause injury.
- Keep your hands and foreign objects away from the embroidery carriage and frame when the machine is embroidering. Otherwise, injury may result.
- To avoid distorting your embroidery design, do not touch the embroidery carriage and frame when the machine is embroidering.

🟒 Note

• You can also sew utility/decorative stitches with the embroidery unit attached. Touch







automatically raise for utility and decorative stitching.

- Be sure to turn off the power before installing the embroidery unit. Otherwise, the machine may be damaged.
- Do not touch the inner connector of the embroidery unit. The pins on the embroidery unit connection may be damaged.
- Do not apply strong force to the embroidery unit carriage or pick up the unit by the carriage. Otherwise, the embroidery unit may be damaged.
- Store the embroidery unit in the proper storage case.

Turn the main power to OFF, and remove the flat bed attachment.




Insert the embroidery unit connection into the machine connection port. The spring hinge on the connection port cover will allow easy access to the port. Push lightly on the connection port cover until the unit clicks into place.




- ① Embroidery unit connection
- ② Machine connection port

V Note

- Be sure there is no gap between the embroidery unit and the sewing machine. If there is a gap, the embroidery patterns will not embroider with the correct registration.
- Do not push on the carriage when installing the embroidery unit onto the machine. Moving the carriage may damage the embroidery unit.



Bold down the release button, and pull the embroidery unit away from the machine.



① Release button

• Do not carry the embroidery unit by holding the release button compartment.



SELECTING PATTERNS


Copyright Information

The patterns stored in the sewing machine and embroidery cards are intended for private use only. Any public or commercial use of copyrighted patterns is an infringement of copyright law and is strictly prohibited. There are many character and decorative embroidery patterns stored in the machine's memory (see the "QUICK REFERENCE GUIDE" for a full summary of patterns in the machine's memory). You can also use patterns from

the embroidery cards (sold separately).

Once the machine has finished the initialization and the carriage has moved to the start position, the pattern type selection screen will display.

If another screen is displayed, press 🚮 , then 💏 to display the screen below.



- 1) Baby Lock "Exclusives"
- ② Embroidery patterns
- ③ Alphabet characters
- ④ Floral alphabet patterns
- ⑤ Greek alphabet patterns
- 6 Frame patterns
- ⑦ Utility embroidery patterns
- 8 Patterns saved in the machine's memory (see page 249)
- ③ Patterns saved in USB media (see page 250)
- 1 Patterns saved on the computer (see page 252)
- ① Press this key to position the embroidery unit for storage

• A key that appears stacked, such as

Exclusives

Memo

and AA,

indicates that there are sub-categories, which must be selected before a pattern selection screen appears.

Pattern Selection Screens

There are 7 categories of patterns in this machine. If a page number such as $\frac{1}{2}$ appears, there is more than one pattern selection screen for that category.




Embroidery patterns





Alphabet characters

Embroidery





Floral alphabet patterns

		[]				1/
A	B	C	D		F	4
G)- sideeen	J		L	
M	ANY I	0	D	Q	R	



Frame patterns

	\diamond			00]
0	0	0	0	0	O	
0	0	0	0	0	0	

AA G

Greek alphabet patterns

A	B	r		E	Z	1/2
H	0	I	K	\mathbb{A}	M	
N	ß	0	Π	P	\mathbb{Z}	



Utility embroidery patterns

Ш Ц Щ		*	₹X×	$\hat{\mathbf{x}}$		1
\bigotimes	Ħ	E		XX	Ŧ	Ę
7	¥‡‡	**	2	XXXX	*	r.

5

SELECTING PATTERNS

Exclusives Baby Lock "Exclusives"	Flowers Flower designs
Embroidery	
Flowers Lace Borders	
Quilting Occasions Children	Lace designs
Animals Appliqué Novelty Nancy Zreman Designs	
Borders Borders designs	Quilling Quilting designs
Occasions designs	Children designs
Animals Animals designs	Appliqué designs
Novelly Novelty designs	Nancy Zremon Nancy designs

188 _____

Selecting Embroidery Patterns/ Baby Lock "Exclusives"/Greek Alphabet Patterns/Floral Alphabet Patterns/Utility Embroidery Patterns



2


Press the key of the pattern you want to embroider.



- * Press 👿 to view the next page.
- * Press 🛕 to view the previous page.
- \rightarrow The selected pattern is displayed.


Press () to create a mirror image of the pattern as needed.


* If a mistake has been made when selecting the pattern, press the key of the pattern you want to embroider and the new selection appears.





 \rightarrow The sewing screen is displayed.






Selecting Alphabet Character Patterns

Example: Entering "Blue Sky".



Press the key of the font you want to embroider.




R P

Press to change the selection screens.



🏹 Memo

- If you continue adding characters after changing the size, the new characters will be entered in the new size.
- You cannot change the size of the entered characters after combining character stitch patterns.







 \rightarrow The sewing screen is displayed.

Proceed to "VIEWING THE SEWING SCREEN" on page 195 to embroider the pattern.

* To return to the previous screen to select another pattern, press RETURN .





Selecting Patterns from Embroidery Cards

About Embroidery Card Reader (Sold Separately) and USB Card Writer Module*


- Use only an embroidery card Reader designed for this machine. Using an unauthorized embroidery card Reader may cause your machine to operate incorrectly.
- * If you have purchased the Palette Ver5 or later, Palette Petite or Palette PTS, you can plug the included USB card writer module into the machine as an embroidery card reader, and recall patterns.

🗸 Note

• Embroidery patterns cannot be saved from the machine to an embroidery card inserted into a connected USB card writer module*.

About Embroidery Cards (Sold Separately)


- Use only embroidery cards manufactured for this machine. Using unauthorized cards may cause your machine to operate incorrectly.
- Embroidery cards sold in foreign countries cannot be used with this machine.
- Store embroidery cards in the hard case.
- Plug the optional embroidery card Reader/ USB card writer module* into the primary (top) USB port on the machine.



- ① Primary (top) USB port
- ② Embroidery card Reader/USB card writer module*

Insert the card completely into the card Reader/USB card writer module*.

* Insert the embroidery card so that the end with a printed arrow is facing up.




_レNote

• Two embroidery USB card Readers/USB card writer module* cannot be used with this machine at the same time. If two embroidery USB card Readers/USB card writer module* are inserted, only the embroidery USB card Reader/USB card writer module* inserted first is detected.

🏹 Memo

- You can also plug the embroidery card Reader/USB card writer module* into the center port of the machine.
- Press the key of the USB port that the embroidery card Reader/USB card writer module* is plugged into.




 $\rightarrow\,$ The patterns on the embroidery card are displayed on the selection screen.

Follow the steps on page 189 to select a pattern.

Selecting Patterns from USB Media/Computer

To recall patterns from the computer or USB media, see pages 250 through 253.

VIEWING THE SEWING SCREEN




- ① Shows the presser foot code.
- Attach embroidery foot "W" for all embroidery projects. When the foot presser symbol is displayed on the screen, you are able to sew.
- ② Shows the boundary for embroidering with the extra large frame (30 cm × 20 cm (approx. 12 inches × 8 inches)).
- ③ Shows a preview of the selected pattern.
- ④ Shows the size of the selected pattern.
- (5) Shows how far the sewing position is from the center (when you move the sewing position).
- (6) Shows how many stitches are in the selected pattern and how many stitches have been sewn so far.
- ⑦ Shows the time necessary to sew the pattern, and the time already spent sewing the pattern (not including time for changing and automatically trimming the thread).
- ⑧ Shows the number of colors in the selected pattern, and the number of the color currently being sewn.
- (9) Shows the part of the embroidery that will be sewn with the first thread color.
- 1 Shows the order for thread color changes and the embroidering time for each thread color.
- * The displayed time is the approximate time that will be required. The actual embroidering time may be longer than the displayed time, depending on the embroidery frame that is used. In addition, the amount of time required to change thread colors is not included.
- Shows the embroidery frames that can be used for the selected pattern. Be sure to use the proper frame (see page 199).
- ② Shows the degree of rotation of the pattern.

ப் Note

• There is an explanation of additional key functions on the next page.

Key Functions

Using these keys, you can change the size of the pattern, rotate the pattern, etc.



No.	Display	Key Name	Explanation	Page	
13	1.W	Image key	Press this key for a preview of the sewn image.	209	
14	<.>> L > J	Arrow keys (Press an arrow key to move the pattern in the direction shown by the arrow. (Press the Center key to return the pattern to the center of the embroidery area.)		
15	ROTATE	Rotate key	Press this key to rotate the pattern. You can rotate a pattern one degree, 10 degrees or 90 degrees at a time.	235	
16	SIZE	Size key	Press this key to change the size of the pattern.	234	
17	DENSITY	Density key	Press this key to change the density of alphabet character or frame patterns.	237	
18		Horizontal mirror image key	Press this key to create a horizontal mirror image of the pattern.	236	
19	MULTI	Multi color key	Press this key to change the color of each letter when sewing alphabet character patterns.	238	
20	MEMORY	Memory key	Press this key to save a pattern in the machine's memory, USB media or a computer.	244-248	
2)	RETURN	Return key	Press this key to return to the pattern type selection screen.	-	
2	×××	Cut/Tension key	Press this key to specify automatic thread cutting, thread trimming or the thread tension. For embroidery, these functions are set automatically.	227-228	
23	J=/+	Forward/Back key	Press this key to move the needle forward or back in the pattern; useful if the thread breaks while sewing or if you want to start again from the beginning.	222-224	
24	1 de la constante de la consta	Starting point key	Press this key to move the needle start position to align the needle with the pattern position.	233	
8	41	Trial key	Press this key to check the position of the pattern. The embroidery frame moves to the desired position so you can check that there is enough space to sew the pattern.	208	
8	8	Embroidery positioning key	Press this key to align the embroidering position using the built-in camera.	205	
Ø	(II.)	Uninterrupted embroidery key	Press this key to embroider the selected pattern with a single color.	241	

🗤 Note

• Some operations or functions are not available for certain patterns. If the key display is light gray, you cannot use that function or operation with the selected pattern.

PREPARING THE FABRIC

- Use fabrics with a thickness of less than 3 mm (approx. 1/8 inch). Using fabrics thicker than 3 mm (approx. 1/8 inch) may cause the needle to break.
- When using layers with thicker batting etc., you can sew more attractive embroidery by adjusting the embroidery presser foot height in the embroidery settings screen (see below).
- In the case of thick terry cloth towels we recommend that you place a piece of water soluble stabilizer on the top surface of the towel. This will help to reduce the nap of the toweling and result in more attractive embroidery.

Note

- Press , and select page 6/7 to use and + in the Embroidery Foot Height display in the embroidery settings screen. Adjust the presser foot height for thick or puffy fabrics.
 - an the prosper fact and the product plate
- To increase the space between the presser foot and the needle plate, set the embroidery foot height to a larger number, 1.5mm setting is used for most embroidery.

Attaching Iron-on Stabilizers (Backing) to the Fabric

For best results in your embroidery projects, always use stabilizer material for embroidery. Follow the package instructions for the stabilizer being used.


Press ?	\rightarrow	Operation Guide	$] \rightarrow [$	Embroidery Basic Operation	$] \rightarrow$
	\rightarrow	in thi	s orde	er to displa	y a

video example of attaching iron-on stabilizers (backing) to the fabric (see page 34). Follow the steps explained below to complete the operation.


When using fabrics that cannot be ironed (such as towel or fabrics that have loops which expand when ironed) or in places where ironing is difficult, position the stabilizer material under the fabric without fusing it, then position the fabric and stabilizer in the embroidery frame, or check with your authorized retailer for the correct stabilizer to use.


• Always use a stabilizer material for embroidery when sewing stretch fabrics, lightweight fabrics, fabrics with a coarse weave, or fabrics which cause pattern shrinkage. Otherwise, the needle may break and cause injury. Not using a stabilizer material may result in a poor finish to your project.

Use a piece of stabilizer which is larger than the embroidery frame being used.



② Iron-on stabilizer (backing)





- ① Fusible side of stabilizer
- ② Fabric (wrong side)

Memo

• When embroidering on thin fabrics such as organdy or lawn, or on napped fabrics such as towel or corduroy, use water soluble stabilizer (sold separately) for best results. The water soluble stabilizer material will dissolve completely in water, giving the project a more attractive finish.


Hooping the Fabric in the Embroidery Frame

Types of Embroidery Frames

Extra Large	Quilt	Medium	Small
	600	- Contraction	- Cor
Embroidery field	Embroidery field	Embroidery field	Embroidery field
30 cm × 20 cm	20 cm × 20 cm	10 cm × 10 cm	$2 \text{ cm} \times 6 \text{ cm}$
(approx. 12 inches \times 8 inches)	(approx. 8 inches \times 8 inches)	(approx. 4 inches \times 4 inches)	(approx. 1 inch \times 2-1/2 inches)
Use when embroidering connected or combined characters or patterns, or when embroidering large patterns.	Use when embroidering patterns between 10 cm \times 10 cm (approx. 4 inches \times 4 inches) and 20 cm \times 20 cm (approx. 8 inches \times 8 inches).	Use when embroidering patterns under 10 cm × 10 cm (approx. 4 inches × 4 inches).	Use for embroidering names or very small patterns.

Other optional embroidery frame can be used. When choosing frames that do not appear on the screen, be sure to check the design size of the embroidery field of the optional frame. Check with your authorized retailer for frame compatibility.

Select a frame that matches the pattern size. Included frame options are displayed on the LCD.



- ① Highlighted: Can be used
- ② Shaded: Cannot be used



• If you use a frame that is too small, the presser foot may strike the frame during sewing and cause injury.

■ Inserting the Fabric

Press ?



in this order to display a


video example of hoping the fabric in the embroidery frame (see page 34). Follow the steps explained below to complete the operation.

Operation Guide

Note

• If the fabric is not securely held in the embroidery frame, the embroidery design will sew out poorly. Insert the fabric on a level surface, and gently stretch the fabric taut in the frame. Follow the steps below to insert the fabric correctly.


Lift-up and loosen the frame adjustment screw and remove the inner frame.



- ① Frame adjustment screw
- ② Inner frame


Lay the fabric right side up on top of the outer frame.

Re-insert the inner frame making sure to align the inner frame's \triangle with the outer frame's \bigtriangledown .



- (1) Inner frame's \triangle
- ② Outer frame's ∇
- ③ Frame adjustment screw

3 Slightly tighten the frame adjustment screw, and then remove the slack in the fabric by pulling on the edges and corners. Do not loosen the screw.




4

Gently stretch the fabric taut, and tighten the frame adjustment screw to keep the fabric from loosening after stretching.

* After stretching the fabric, make sure the fabric is taut.




* Make sure the inside and outside frames are even before you start embroidering.



- ① Outer frame
- ② Inner frame
- ③ Fabric

🏹 Memo

 Stretch the fabric from all four corners and all four edges. While stretching the fabric, tighten the frame adjustment screw.




5

Embroidering Small Fabrics or Fabric Edges

Use an embroidery stabilizer to provide extra support. After embroidering, remove the stabilizer carefully. Attach the stabilizer as shown in the following examples. We recommend using a stabilizer for embroidery.

Embroidering Small Fabrics

Use a temporary spray adhesive to adhere the small piece of fabric to the larger piece in the frame. If you do not wish to use a temporary spray adhesive, attach the stabilizer with a basting stitch.




① Fabric

② Stabilizer

Embroidering Edges or Corners

Use a temporary spray adhesive to adhere the small piece of fabric to the larger piece in the frame. If you do not wish to use a temporary spray adhesive, attach the stabilizer with a basting stitch.




① Fabric

Stabilizer

Embroidering Ribbons or Tape

Secure with double-sided tape or a temporary spray adhesive.



① Ribbon or tape

Stabilizer

ATTACHING THE EMBROIDERY FRAME




 \rightarrow

 \rightarrow [] in this order to display a video

example of attaching the embroidery frame (see page 34). Follow the steps explained below to complete the operation.


🟒 Note


• Wind and insert the bobbin before attaching the embroidery frame.




Operation Guide


→








- Embroidery frame holder
 Embroidery frame guide
- Slide the embroidery frame into the holder, making sure to align the embroidery frame's \triangle with the holder's \bigtriangledown .



① Arrow mark


4 Lower the frame-securing lever to be level with the frame to secure the embroidery frame in the embroidery frame holder.



① Frame-securing lever

• If the frame-securing lever is not lowered, the following message appears. You cannot start sewing until you lower the frame-securing lever.





CONFIRMING THE PATTERN POSITION

The pattern is normally positioned in the center of the embroidery frame. If the pattern needs to be repositioned for better placement on the garment, you can check the layout before starting embroidery.


Using the Built-In Camera to Align the Embroidering Position

The embroidering position can easily be aligned using the machine's built-in camera and the included embroidery positioning sticker.

🗤 Note

• When embroidery frame (small) is installed, the built-in camera cannot be used to align the embroidering position. Install embroidery frame (medium) or a larger embroidery frame.


Affix the embroidery positioning sticker to the location in the fabric to be embroidered. Place the embroidery positioning sticker so that the center of the larger circle is at the center of the embroidery pattern.




- ① Embroidery positioning sticker
- ② Center of the embroidery pattern
- ③ Embroidery field

Vie Note

• When inserting the fabric in the embroidery frame, check that the embroidery pattern fits within the embroidery field for the frame that is used.



- ① Embroidery field
- ② Embroidery pattern
- ③ Embroidery positioning sticker
- Depending on the type of fabric that is used, a part of the embroidery positioning sticker may remain attached when it is peeled off. Before using the embroidery positioning sticker, check that it can be cleanly removed from a scrap piece of the fabric to be used.




SIZE

RETURN

(+) < \$ + 0.00 cm +++ + 0.00 cm 0 0° OTAT MEMOR) 2 0 0


 \rightarrow A window appears so that the area containing the embroidery positioning sticker can be selected.

From the areas shown in the window, select З the area containing the embroidery positioning sticker.



Note

- If the embroidery positioning sticker is placed in the center of embroidery frame, select any of the four areas.
- If the embroidery positioning sticker overlaps two areas, select either of the two areas.




🖑 Embroidery 👺

Checking the Pattern Position

The embroidery frame moves and shows the pattern position. Watch the frame closely to make sure the pattern will be sewn in the right place.






 \rightarrow The following screen is displayed.

, press the key for the position From 🛐 2

that you want to check.




① Selected position

 \rightarrow The needle will move to the selected position on the pattern.

Memo

• To see the entire embroidering area, press

1 . The embroidery frame moves and shows the embroidery area.



CAUTION

Make sure the needle is up when the ٠ embroidery frame is moving. If the needle is down, it could break and result in injury.

Press CLOSE

Previewing the Completed Pattern



→ An image of the pattern as it will be embroidered appears.

Press III III III III to select the frame used in the preview.

- * Frames displayed in light gray cannot be selected.
- * Press Press to enlarge the image of the pattern.
- * The pattern can be sewn as it appears in the following display.



🏹 Memo

• You can begin sewing from this screen by pressing the "Start/Stop" button.



Press **CLOSE** to return to the original screen.

SEWING AN EMBROIDERY PATTERN

Sewing Attractive Finishes

There are many factors that go into sewing beautiful embroidery. Using the appropriate stabilizer (see page 197) and hooping the fabric in the frame (see page 199) are two important factors mentioned earlier. Another important point is the appropriateness of the needle and thread being used. See the explanation of threads below. Included with this machine are two bobbin cases. Follow the explanation below.

Γ	Thread	Upper thread	Upper thread Use embroidery thread intended for use with this machine.	
			Other embroidery threads may not yield optimum results.	
Bobbin thread Use embroidery bobbin thread intended for use with this machine.		Use embroidery bobbin thread intended for use with this machine.		

Memo

If you use threads other than those listed above, the embroidery may not sew out correctly.

Bobbin case	Standard bobbin case (green marking on the screw) is in the machine for sewing and embroidery. The bobbin case originally installed in the machine has a green marking on the screw. Do not adjust green marked screw.
 Standard bobbin case (green marking on the screw) Alternate bobbin case (no color on the screw) 	Alternate bobbin case (no color on the screw) is set with tighter tension for embroidery with different weights of bobbin threads and a variety of embroidery techniques. This bobbin case is identified with a dark colored mark on the inside of the bobbin cavity. The screw on this case can be adjusted if necessary.

CAUTION


When embroidering on large garments (especially jackets or other heavy fabrics), do not let the fabric hang over the table. Otherwise, the embroidery unit cannot move freely and the embroidery frame may strike the needle, causing the needle to bend or break and possibly cause injury. Place the fabric so that it does not hang off the table or hold the fabric to keep it from dragging.

Note

- Before embroidering, check that there is enough thread in the bobbin. If you start to sew your embroidery project without enough thread in the bobbin, you will need to rewind the bobbin in the middle of the embroidery pattern.
- Do not leave objects in the range of motion of the embroidery frame. The frame may strike the object and cause a poor finish to the embroidery pattern.
- When embroidering on large garments (especially jackets or other heavy fabrics), do not let the fabric hang over the table. Otherwise, the embroidery unit cannot move freely, and the pattern may not turn out as planned.

Embroidery Needle Plate Cover

Under some conditions, based on the type of fabric, stabilizer, or thread being used, there may be some looping in the upper thread. In this case, attach the included embroidery needle plate cover to the needle plate. Attach the cover by inserting the two projections on the underside of the cover into the notches on the needle plate as shown below.



- Groove
- (2) Projection
- ③ Notch

To remove the embroidery needle plate cover, place your fingernail in the groove and lift the plate out.

• Push the embroidery needle plate cover as far as possible to attach it. If the embroidery needle plate cover is not securely attached, it may cause the needle to break.

Note

 Do not use the embroidery needle plate cover for any applications other than embroidery.

Using Prewound Bobbins

When using a prewound bobbin, not included with this machine, set the bobbin by following the steps below.

Using Prewound Bobbins with Standard Bobbin Case (Green Marking on the Screw)

Use the standard bobbin case (green marking on the screw) when embroidering with the recommended bobbin thread wound on included bobbins. When using prewound bobbins (not included with this machine) it is recommended to use prewound COATS "L" type with the standard bobbin case. (see "Using Bobbin Center Pin (Spacer)".)

Using Prewound Bobbins with Alternate Bobbin Case (No Color on the Screw)

Use the alternate bobbin case (no color on the screw) when a tighter bobbin tension is needed. See page 312 for how to remove the bobbin case.



Note

- The bobbin thread sensor does not work when prewound bobbins with a center core are used.
- Due to coating on prewound bobbin thread, the bobbin case may require cleaning occasionally. See "Cleaning the Bobbin Case" on page 313.


Using Bobbin Center Pin (Spacer)

The bobbin center pin (spacer) can be used with either the standard or alternate bobbin cases. Use the bobbin center pin (spacer) for better thread flow, bobbin stability and to provide the correct height for prewound bobbins in the bobbin case.



CAUTION

Do not use included bobbin or class 15 type bobbins with the bobbin center pin spacer. These bobbins are too deep and will damage the bobbin area of the machine.






Remove the bobbin cover.


Set the bobbin center pin.

(1) Bobbin center pin





Repeat the same steps for embroidering the remaining colors.



→ When the last color is sewn, "Finished sewing" will appear on the display. Press , and the display will return to the original screen.

🏹 Memo

• The Thread Trimming Function is originally set to trim excess thread jumps (threads linking parts of the pattern, etc.). Depending on the type of thread and fabric that are used, an end of upper thread may remain on the surface of the fabric at the beginning of the stitching. After embroidering is finished, cut off this excess thread.

*If the setting has been turned off, trim the excess thread jumps using scissors after the pattern is finished.

See page 228 for information on the thread trimming function.


Sewing Embroidery Patterns Which Use Appliqué

There are some patterns which call for an appliqué inside the pattern. Prepare the base fabric and the appliqué fabric (appliqué piece).

When sewing an embroidery pattern with an appliqué, the color sewing order display shows "APPLIQUE MATERIAL", "APPLIQUE POSITION", "APPLIQUE", and then the sewing order of the colors around the appliqué.


Memo

Attach an iron-on stabilizer to the wrong side of the appliqué material.



Appliqué material (cotton, felt, etc.)
 Iron-on stabilizer

Place the appliqué material into the embroidery frame, and then press the "Start/Stop" button to sew the outline of the appliqué.




Outline of appliqué
 Appliqué material

🏹 Memo

The embroidery procedure is the same as the basic procedure explained on page 212.


→ The machine will sew around the outline of the appliqué pieces and will then stop.

- Remove the appliqué material from the embroidery frame, and then cut carefully along the stitching. After cutting, remove all of the stitching thread carefully.
 - Carefully cut out the pattern on the outline you just sewed. Do not cut inside the stitching line, as the appliqué fabric will not be caught by the appliqué stitch.






Place the base material into the embroidery frame.



Base material


Press the "Start/Stop" button to sew the position of the appliqué.

* Use the same thread color you plan to use when attaching the appliqué in step 🔽.



- (1) Position of appliqué
- ② Base material
- \rightarrow The machine will sew around the position of the appliqué and will then stop.

Apply a thin layer of adhesive or spray 6 adhesive to the back of the appliqué piece and attach it to the appliqué position so that it follows the seam of the outline.




Memo

 If the appliqué material is a lightweight fabric, you may want to use a fusible web on the back to stabilize the fabric and for appliqué placement. Fuse appliqué in place with an iron.

Do not remove fabric from the frame to iron the appliqué material.



Press the "Start/Stop" button.




Memo

Some patterns may not show all three appliqué steps. Sometimes the "APPLIQUE" step will be shown as a color.

 \rightarrow The appliqué will then be completed.

Change the upper thread and then carry out the rest of the embroidering.




Memo

- Some glue may get onto the presser foot, needle, and needle plate at this time. Finish embroidering the appliqué pattern and then clean away the glue.
- · For best sewing results clip all threads between color steps.


PRINT AND STITCH (COMBINING EMBROIDERY PATTERNS AND PRINTED DESIGNS)

Completed embroidery patterns combined with printed designs are built into this machine. Beautiful three-dimensional embroidered designs can be created by ironing a background onto fabric or printing it onto printable fabric, then sewing complementary embroidery on top of the background.

Using iron-on paper



Using printable fabric





Select a pattern to be combined with the background image. \rightarrow See "Selecting a Pattern" on page 216.



Step2Output from the machine the background image and the positioning image.
 \rightarrow See "Outputting the Background Image and Positioning Image" on page 217.



Step3When using iron-on paper
With a printer, print the background onto iron-on paper, and print the embroidery position sheet on plain paper. Then, iron
the background image onto fabric.
When using printable fabric
With a printer, print the background onto printable fabric, and print the embroidery position sheet on plain paper.
→ See "Printing the Background and Embroidery Position Sheet" on page 219.

Step4Hoop in the embroidery frame the fabric with the background image ironed on or printed, check the embroidering
position, and then start embroidering.
→ See "Sewing Embroidery Patterns" on page 220.

ப் Note

• Print the background and embroidery position sheet in their original dimensions. If an image is printed in a different size, the sizes of the embroidery pattern and background may not match. In addition, the built-in camera cannot detect the embroidery position mark. Make sure that the print settings are correctly specified.

Selecting a Pattern


Patterns combining embroidery and printed designs can be selected from the pages that

contain _____. Select the desired pattern.

ন Memo

• Refer to the Quick Reference Guide for the detail of patterns which enable this function.


Press the key of the pattern you want to embroider.




→ An image of the pattern combined with the background appears.


Checking Only the Embroidery Pattern

Â





→ Only the embroidery pattern (not the background image of the selected embroidery pattern) is displayed.



To return to the image of the pattern combined with

the background, press

Outputting the Background Image and Positioning Image

Use USB media or the computer to output the following three images from the machine.


- * File name may differ depending on the PDF file selected.
- [xxx]r.pdf (Example: E_1r.pdf)
 An image flipped on a vertical axis (for an ironon transfer)



• [xxx]n.pdf (Example: E_1n.pdf) An image that is not flipped (for printing on printable fabric)



• [xxx]p.pdf (Example: E_1p.pdf) An image that is not flipped, but has positioning marks attached (for positioning)



Vie Note

- Print the background and embroidery position sheet in their original dimensions. If an image is printed in a different size, the sizes of the embroidery pattern and background may not match. In addition, the built-in camera cannot detect the embroidery position mark. Make sure that the print settings are correctly specified.
- When printing the PDF file of the image with positioning marks, specify the highest image quality possible for full-color printing. In addition, use matte printing paper. Due to poor printing conditions, the machine's built-in camera may not be able to correctly detect the positioning marks. (For details on printing, refer to the operating instructions for your printer.)


Using USB Media



Insert the USB media into the primary (top) USB port on the machine.




Select the pattern, and then press



 \rightarrow The select USB output screen appears.

3 Press it is select the primary (top) USB port where the USB media is inserted.




→ Two files of the background image only and one file for aligning embroidery into position are copied (PDF format) onto the USB media.

n Memo

- Do not remove the USB media from the machine until data output is finished.
- Remove the USB media where the image data is saved from the machine, and then copy the image data from the USB media to the computer.


■ Using a USB Cable

Plug the USB cable connectors into the corresponding USB ports on the computer and on the machine.





 \rightarrow The select USB output screen appears.



→ Two files of the background image and one file for aligning embroidery into position are copied (PDF format) into "Removable Disk" under "Computer (My computer)".

🥱 Memo

- Do not disconnect the USB cable from the machine until data output is finished.
- Copy the image data saved in "Removable Disk" into a different file before closing.

Printing the Background and Embroidery Position Sheet

Print the PDF files of the background and embroidery position sheet. The background file that is printed differs depending on whether ironon paper or printable fabric is used.

To view the PDF file, Adobe[®] Reader[®] is needed. If it is not installed on your computer, you can download it from the Adobe Systems website: http://www.adobe.com/ Open the PDF file to be printed, click "File"-"Print", and then set "Page Scaling" to "None (100%)".

VV Note

 Print the background and embroidery position sheet in their original dimensions. If an image is printed in a different size, the sizes of the embroidery pattern and background may not match. In addition, the built-in camera cannot detect the embroidery position mark. Make sure that the print settings are correctly specified.



Print the background image.

 When printing onto iron-on paper, print the file named E_1r.pdf (an image flipped on a vertical axis).
 When printing onto printable fabric, print the file named E_1n.pdf (an image that is not flipped).




① Background image

Vie Note

- Before printing onto iron-on paper or printable fabric, we recommend performing a test print to check the print settings.
- For details on printing on iron-on transfer sheets or printable fabric, refer to the instructions for the iron-on transfer sheets and printable fabric.
- Some printers will automatically print an image flipped if an iron-on transfer sheet is selected as the paper. For details, refer to the instructions for the printer being used.

Print the embroidery position sheet (file named E_1p.pdf) onto plain paper.



① Embroidery position sheet

🟒 Note

• When printing the PDF file for the embroidery position sheet, specify the highest image quality possible for full-color printing. In addition, we recommend printing on matte paper. If this is not done, the builtin camera may not be able to correctly detect the embroidery positioning mark.

If an iron-on transfer sheet is used, transfer Place the paper printed with the positioning the image onto fabric. image on top of the fabric so that the pattern is aligned, and then affix the paper to the fabric with cellophane tape to prevent the paper from moving. Memo · For details on transferring from iron-on transfer sheets, refer to the instructions for the iron-on transfer sheets. • If necessary, cut the iron-on transfer sheet ① Cellophane tape to the size of the pattern before transferring the image. After checking that a pattern is selected, press sewing . **Sewing Embroidery Patterns** \rightarrow The sewing screen appears. Hoop in the embroidery frame the fabric Note with the background image ironed on. Before embroidering, check that the embroidery position sheet is perfectly aligned with the background. Align the embroidering position according to steps 😑 through 🙃 of "Using the Built-In Camera to Align the Embroidering Position" on page 205. Remove the positioning sheet and press the "Start/Stop" button to begin embroidering. CAUTION Cut the paper printed with the center Before pressing the "Start/Stop" button to positioning image β so it can easily be begin embroidering, remove the positioning positioned aligned with the background sheet taped to the fabric in step 3. image on the fabric. Lines or color changes in the image can help you find the correct alignment position.

ADJUSTMENTS DURING THE EMBROIDERY PROCESS

Note

· Be careful not to bump the embroidery unit carriage or the presser foot when removing or attaching the embroidery frame. Otherwise, the pattern will not embroider correctly.

If the Bobbin Runs Out of Thread

When the bobbin begins to run out of thread during embroidering, the machine will stop and

the message below will appear. Press and follow the directions below to rethread the lower threading. If very little sewing remains, you can embroider 10 final stitches without rethreading the

machine by pressing **GLOSE**. The machine will stop after sewing the 10 stitches.




Note If "Upper and Bobbin Thread Sensor" in the General settings screen of the machine setting mode is set to "OFF", the message shown above does not appear.




 \rightarrow After the thread is automatically cut, the carriage will move.

Unlock the frame-securing lever and remove the embroidery frame.


Be careful not to apply strong force to the fabric at this time. Otherwise, the fabric may loosen in the frame.






Press

Insert a wound bobbin into the machine. (see page 43 for Setting the bobbin.)





OK



 \rightarrow The carriage will return to its original position.


OK

Attach the embroidery frame.

To return to the spot in the pattern where


you stopped sewing, follow steps 😣 through 6 in the next section.

If the Thread Breaks During Sewing



If the upper thread is broken, redo the upper threading. If the bobbin thread is broken, press 📳 and follow the directions in steps 1 through 5 from the previous section to reset the bobbin.

Press J-/+



- Press II-1, II-10, or II-100 to move the needle back the correct number of stitches before the spot where the thread broke.
 - If you cannot move back to the spot where the thread broke, press **I**- to select the color and move to the beginning position of that color, then use [1+1], [1+10], or [1+100] to move ahead to

Image: Second	Embroidery ₩ 2990 6280 2-	the thread broke. $\frac{7 \min}{15 \min} \Box - \frac{2}{6}$
	K	YELLOW 3 min TANGERINE 2 min
	+ 0.00 cm ↔ + 0.	00 cm
CLOSE +1 +10 +100 0		

6

Press **GLOSE** to return to the original screen.

Press the "Presser Foot Lifter" button to

lower the presser foot, and press the "Start/ Stop" button to continue sewing.

Restarting from the Beginning






- $\rightarrow\,$ The embroidery frame moves, returning the needle to the pattern's beginning position.
- Press the "Presser Foot Lifter" button to lower the presser foot and start sewing.

Resuming Embroidery After Turning Off the Power

The current color and stitch number are saved when embroidery is stopped. The next time the machine is turned on, you have the option to continue or delete the pattern.



• Even if the power goes out in the middle of embroidery, the machine returns to the point where embroidery was stopped when the machine is turned on again.



① Current stitch number when embroidery was stopped

_く Note


- Do not remove the embroidery unit or the memory will no longer remember your design.
- Turn the main power to ON.

Follow the instructions shown on the screen and remove the embroidery frame.

 $\rightarrow~$ The following message will appear.



- Memo
 - If you want to start a new embroidery pattern, press CANCEL so the pattern selection screen appears.



MAKING EMBROIDERY ADJUSTMENTS

Adjusting Thread Tension

When embroidering, the thread tension should be set so that the upper thread can slightly be seen on the wrong side of the fabric.

Correct Thread Tension

The pattern can be seen from the wrong side of the fabric. If the thread tension is not set correctly, the pattern will not finish well. The fabric may pucker or the thread may break.



- (1) Right side
- ② Wrong side

Follow the operations described below to adjust thread tension according to the situation.

Note

 If the thread tension setting is made extremely weak, the machine may stop during sewing. This is not the sign of a malfunction. Increase the thread tension slightly, and begin sewing again.

Memo

- If you turn the main power to OFF or select a different pattern, the thread tension will reset to the automatic setting.
- · When you retrieve a saved pattern, the thread tension setting will be the same as when the pattern was saved.

Upper Thread is Too Tight

The tension of the upper thread is too tight, resulting in the bobbin thread being visible from the right side of the fabric.


Note

 If the bobbin thread was incorrectly threaded, the upper thread may be too tight. In this case, refer to "Setting the Bobbin" (page 43) and rethread the bobbin thread.



- Right side
- ② Wrong side





Press to weaken the upper thread tension. (The tension number will decrease.)



Press CLOSE




Upper Thread is Too Loose

The tension of the upper thread is too loose, resulting in a loose upper thread, loose thread locks, or loops appearing on the right side of the fabric.

🟒 Note

• If the upper thread was incorrectly threaded, the upper thread may be too loose. In this case, refer to "Upper Threading" (page 46) and rethread the upper thread.





```
Press CLOSE
```

Note

With "Embroidery Tension" on page 6/7 of the setting screen, the tension of the upper thread can be adjusted for embroidering. The selected setting will be applied to all patterns.
 When embroidering, if the overall tension of the upper thread is too tight or too loose, adjust it from the setting screen. Press + to tighten the upper thread tension and press - to loosen the upper tension. If an individual embroidery pattern needs additional fine tuning, refer to "Adjusting Thread Tension" on page 225.

00

Embroidery

Adjusting the Alternate Bobbin Case (with No Color on the Screw)

When using the embroidery bobbin thread provided, please be sure to choose the green marked bobbin case when performing utility stitch sewing and embroidery functions. When in the embroidery function mode, the alternate bobbin case (with no color on the screw) should be selected when substitute embroidery bobbin threads (other than what is accompanied with your machine) are being used. The alternate bobbin case (with no color on the screw) can be easily adjusted when bobbin tension changes are required to accommodate different bobbin threads. See "Sewing Attractive Finishes" on page 210.

To adjust the bobbin tension for embroidery function, using the alternate bobbin case (with no color on the screw), turn the slotted screw (-) with a (small) screwdriver.



① Do not turn a phillips screw (+).

② Adjust with a screwdriver (small).

Correct Tension

Upper thread slightly appears on the wrong side of fabric.

① Right side

② Wrong side

Bobbin Thread is Too Loose


Bobbin thread appears slightly on the right side of fabric.



① Right side

② Wrong side

If this occurs, turn the slotted screw (-) clockwise, being careful not to over-tighten the screw, approximately 30-45 degrees to increase bobbin tension.




Bobbin Thread is Too Tight

Upper thread on the right side of fabric seems to be lifting/looping and bobbin thread is not seen on the wrong side of fabric.



- ① Right side
- ② Wrong side

If this occurs, turn the slotted screw (-) counterclockwise, being careful not to over-loosen the screw, approximately 30-45 degrees to decrease bobbin tension.




- When adjusting the alternate bobbin case, be sure to remove the bobbin from the alternate bobbin case.
- DO NOT adjust the position of the phillips (+) screw on the alternate bobbin case as this may result in damage to the bobbin case, rendering it unusable.
- If the slotted screw (-) is difficult to turn, do not use force. Turning the screw too much or providing force in either (rotational) direction may cause damage to the bobbin case. Should damage occur, the bobbin case may not maintain proper tension.


Using the Automatic Thread Cutting Function (END COLOR TRIM)

The automatic thread cutting function will cut the thread at the end of sewing each color. This function is initially turned on. To turn this

function off, press 📷 key and then 📷. This function can be turned on or off during embroidering.

* This setting returns to its default when the machine is turned off.







Press is to turn off the automatic thread cutting function.



- \rightarrow The key will display as **S**
- * When one color thread is sewn, the machine will stop without cutting the thread.


Using the Thread Trimming Function (JUMP STITCH TRIM)

The thread trimming function will automatically trim any excess thread jumps within the color. This function is initially turned on. To

turn this function off, press 🔤 key and then

Image: This function can be turned on or off during embroidering.

* Your customized setting remains after turning the machine off and on.




① Jump stitch

🟒 Note

• When this function is turned on, use the included ball point needle 75/11 for embroidering patterns with short jump stitches such as alphabet characters. Using other needles may cause the thread to break.

Press 🔤



Press with the thread trimming function.



- ightarrow The key will display as $\left[1
 ightarrow$
- * The machine will not trim the thread before moving to the next stitching.

Selecting the Length of Jump Stitch Not to Trim

When the thread trimming function **main** is turned

on, you can select the length of the jump stitch not to trim the thread. This function can be turned on or off during embroidering.

Select a setting from 5 mm to 50 mm in 5 mm increments.

* Your customized setting remains after turning the machine off and on.

Press + or - to select the length of jump stitch.


For example: Press + to select 25 mm (1 inch)

and the machine will not trim a jump stitch of 25 mm or less before moving to the next stitching.




Vie Note

- If design has many trims it is recommended to select a higher jump stitch trim setting in order to reduce the amount of excess tails on backside of fabric.
- The higher number of the jump stitch length selected, the fewer number of times the machine will trim. In this case, more jump stitches remain on the surface of the fabric.





- SPM is the number of stitches sewn in one minute.
- Decrease the sewing speed when embroidering on thin, thick, or heavy fabrics.
- The sewing speed can be changed while embroidery is being sewn.
- The maximum sewing speed setting does not change until a new setting is selected. The setting specified before the main power is set to OFF remains selected the next time that the machine is turned on.
- Decrease the sewing speed to 600 spm when using a speciality thread like a metallic thread.




Changing the Thread Color Display

You can display the name of the thread colors or embroidery thread number.







- * For the optional embroidery frame.
- ① Extra large frame embroidering area [30 cm × 20 cm (12 inches × 8 inches)]
- Center line
- ③ Quilt frame embroidering area [20 cm × 20 cm (8 inches × 8 inches)]
- (4) Embroidery area for optional large embroidery frame [18 cm \times 13 cm (7 inches \times 5 inches)]
- (5) Embroidering area for optional border embroidery frame [18 cm × 10 cm (7 inches × 4 inches)]
- Medium frame embroidering area
 [10 cm × 10 cm (4 inches × 4 inches)]
- ⑧ Grid lines



REVISING THE PATTERN

• When you have revised the pattern, check the display of available embroidery frames and use an appropriate frame. If you use an embroidery frame not displayed as available for use, the presser foot may strike the frame and possibly cause injury.

Changing the Pattern Position

Use to move the pattern in the direction shown by the arrow.

Press **•** to center the pattern.



① Distance from the center


The pattern can also be moved by dragging it.

If a USB mouse is connected, move the mouse to position the pointer on the desired pattern, and then select and drag the pattern. The pattern can also be dragged by selecting it directly in the screen with your finger or the touch pen.




Patterns cannot be moved in screens where

does not appear.



Aligning the Pattern and the Needle

Example: Aligning the lower left side of a pattern and the needle




Mark the embroidery start position on th	ıe
fabric, as shown.	

1

2

				_
Pre	ess 🛃			
	Embroidery	1378 2-	0 min 6 min	0 1
			AB	•
	A	BC	BLACK	6 min
	1.2 cm ₩ 9.1 cm \$ + 0.00		.00 cm <	>
	SIZE ROTAT			
(RETURN	∞‰/+	(† j	MEMORY
	Ê	, i II	?	U iO



I IWI

3 min

4 min

3 min

2 min

3 min


1 min

1

8


MEMORY

9



-	
Press ROTATE .	
Embroidery	
慶	LIME GREEN 3 min EMERALD GREEN 4 min YELLOW 3 min TANGERINE 2 min RED 3 min LIME GREEN 1 min
#_# 9.6 cm #_# 9.3 cm # + 0.00 cm ++ 0.00 © 0	

Rotating the Pattern




*

Select the angle of rotation for the pattern.

de l

- Press **1**90° to rotate the pattern 90 degrees to the left.
- 90^{-1} to rotate the pattern 90 degrees to the Press right.
- Press M10 to rotate the pattern 10 degrees to the left.
- Press 10* to rotate the pattern 10 degrees to the right.
- Press **↑** to rotate the pattern 1 degree to the left.
- Press to rotate the pattern 1 degree to the 1.7* right.

* Press **RESET** to return the pattern to its original position.



① Degree of rotation




З

Press **CLOSE** to return to the original screen.

Creating a Horizontal Mirror Image

Press (so it appears as (to create a horizontal mirror image of the selected pattern. Press (again to return the pattern to normal.







Changing the Density (Alphabet Character and Frame Patterns Only)


The thread density for some alphabet character and frame patterns can be changed.

A setting between 80% and 120% in 5% increments can be specified.



Change the density.

- * Press to make the pattern less dense.
- Press + to make the pattern more dense.



- ① Normal
- ② Fine (stitches closer together)
- ③ Coarse (stitches farther apart)
- → The pattern density changes each time you press a button.
- **B** Press **CLOSE** to return to the pattern selection screen.


Changing the Colors of Alphabet Character Patterns

Combined alphabet character patterns can be sewn with each letter in a different color. If "MULTI COLOR" is set, the machine stops after each character is sewn so that the thread can be changed to a different color.





Press (MULTI) so that it appears as (MULTI).


Press the key again to return to the original setting. *




After a character is sewn, change the thread 2 color, and then sew the next character.











tor the multicolor steps to become shaded and the selected pattern will embroider in a single color, instead of changing the thread while

embroidering. Press again to return to the pattern's original settings.



→ The thread color displayed on the screen will be grayed out.



Memo

• Even if uninterrupted embroidering (has been set, the automatic thread cutting function and the thread trimming function can be used (see page 227 and 228).

USING THE MEMORY FUNCTION

Embroidery Data Precautions

Observe the following precautions when using embroidery data other than that created and saved in this machine.

• When using embroidery data other than our original patterns, the thread or needle may break when sewing with a stitch density that is too fine or when sewing three or more overlapping stitches. In that case, use one of our original data design systems to edit the embroidery data.

Types of Embroidery Data that can be Used

• Only .pes,.pha,.phb,.phc, and .dst embroidery data files can be used with this machine. Using data other than that saved using our data design systems or sewing machines may cause the embroidery machine to malfunction.

■ Types of USB Devices/Media that can be Used

Stitch data can be saved to or recalled from USB media. Use media that meets the following specifications.

- USB Flash drive (USB Flash memory)
- USB Floppy disk drive
- Stitch data can be recalled only.
- USB CD-ROM, CD-R, CD-RW drives

You can also use the following types of USB media with the USB Memory Card Reader/USB card writer module. • Secure Digital (SD) Card

- Secure Digital (SD) Ca
 Canada at Elash
- CompactFlash
- Memory StickSmart Media
- Multi Media Card (MMC)
- XD-Picture Card

V Note

- The processing speed may vary by port selection and quantity of data stored.
- Some USB media may not be usable with this machine. Please visit our website for more details.
- The access lamp will begin blinking after inserting USB devices/media, and it will take about 5 to 6 seconds to recognize the devices/media. (Time will differ depending on the USB device/media).

🦙 Memo

- To create file folders, use a computer.
- Letters and numerals can be used in the file names. In addition, if the file name contains no more than eight characters, the entire file name will appear on the screen.
 If the file name is more than eight characters long, only the first six characters followed by "~" and a number appear as the file name.

Computers and Operating Systems with the Following Specifications can be Used

- Compatible models: IBM PC with a USB port as standard equipment IBM PC-compatible computer equipped with a USB port as standard equipment
 Compatible operating systems:
- Compatible operating systems: Microsoft Windows 2000/XP/Vista

Precautions on Using the Computer to Create and Save Data

- If the name of the embroidery data file/folder cannot be identified, for example, because the name contains special characters, the file/folder is not displayed. If this occurs, change the name of the file/folder. We recommend using the 26 letters of the alphabet (uppercase and lowercase), the numbers 0 through 9,"-", and "_".
- If embroidery data larger than 300 mm (H) × 200 mm (W) (approx.12 inches (H) × 8 inches (W)) is selected, a message is shown asking if you wish to rotate the pattern 90 degrees.
 Even after being rotated 90 degrees, embroidery data larger than 300 mm (H) × 200 mm (W) (approx. 12 inches (H) × 8 inches (W)) cannot be used. (All designs must be within the 300 mm (H) × 200 mm (W) (approx. 12 inches (H) × 8 inches (W)) design field size.)
- .pes files saved with the number of stitches or the number of colors exceeding the specified limits cannot be displayed. The combined design can not exceed a maximum number of 500,000 stitches or a maximum number of 125 color changes (Above numbers are approximate, depending on the overall size of the design). Use one of our design software programs to edit the embroidery pattern so that it meets these specifications.
- Embroidery data stored in a folder created in USB media can be retrieved.
- Do not create folders in "Removable Disk" on a computer. If embroidery data is stored in a folder in "Removable Disk", that embroidery data cannot be retrieved by the machine.
- Even if the embroidery unit is not attached, the machine will recognize embroidery data.

Tajima (.dst) Embroidery Data


- .dst data is displayed in the pattern list screen by file name (the actual image cannot be displayed). Only the first eight characters of the file name can be displayed.
- Since Tajima (.dst) data does not contain specific thread color information, it is displayed with our default thread color sequence. Check the preview and change the thread colors as desired.

Trademarks

- Secure Digital (SD) Card is a registered trademark or a trademark of SD Card Association.
- CompactFlash is a registered trademark or a trademark of Sandisk Corporation.
- Memory Stick is a registered trademark or a trademark of Sony Corporation.
- Smart Media is a registered trademark or a trademark of Toshiba Corporation.
- Multi Media Card (MMC) is a registered trademark or a trademark of Infineon Technologies AG.
- xD-Picture Card is a registered trademark or a trademark of Fuji Photo Film Co. Ltd.
- IBM is a registered trademark or a trademark of International Business Machines Corporation.
- Microsoft and Windows are registered trademarks or trademarks of Microsoft Corporation.

Each company whose software title is mentioned in this manual has a Software License Agreement specific to its proprietary programs.

All other brands and product names mentioned in this manual are registered trademarks of their respective companies. However, the explanations for markings such as [®] and TM are not clearly described within the text.



Saving Embroidery Patterns in the Machine's Memory

You can save embroidery patterns that you have customized and will use often; for example, your name, patterns that have been rotated or had the size changed, patterns that have had the sewing position changed, etc. A total of about 2 MB of patterns can be saved in the machine's memory.


```
V Note
```

• Do not turn the main power to OFF while the "Saving" screen is displayed. You will lose the pattern you are saving.

ן Memo


- It takes a few seconds to save a pattern to the machine's memory.
- See page 249 for information on retrieving a saved pattern.

Press **MEMORY** when the pattern you want to save is in the sewing screen.





* Press cLOSE to return to the original screen without saving.



→ The "Saving" screen is displayed. When the pattern is saved, the display returns to the original screen automatically.


■ If the Memory is Full

If the screen below displays, either the maximum number of patterns have been saved or the pattern you want to save takes a lot of memory, and the machine cannot save it. If you delete a previously saved pattern, you can save the current pattern.




*


Press **CANCEL** to return to the original screen without saving.



 \rightarrow The machine displays the patterns currently saved.

Select the pattern you want to delete.






- Amount of memory used by the pattern to be deleted
- ② Amount of memory needed to save the current pattern

Press or
* If you decide not to delete the pattern, press

CANCEL



→ The "Saving" screen displays. When the pattern is saved, the display returns to the original screen automatically.

V Note

• Do not turn the main power to OFF while the "Saving" screen is displayed. You will lose the pattern you are saving.

🏹 Memo

- If there is enough memory available after deleting the pattern, the pattern you want to save will be saved automatically. If there is not enough memory available after deleting the pattern, repeat the steps above to delete another pattern from the machine's memory.
- It takes a few seconds to save a pattern.
- See page 249 for more information about retrieving saved patterns.

Saving Embroidery Patterns to USB Media


When sending embroidery patterns from the machine to USB media, plug the USB media into the machine's USB port.

Memo


- USB media is commercially available, but some USB media may not be usable with this machine. Please visit our website for more details.
- Depending on the type of USB media being used, either directly plug the USB device into the machine's USB port or plug the USB media Reader/Writer into the machine's USB port.
- The USB media can be inserted or removed at any time.

Press wemory when the pattern you want to

save is in the sewing screen.



Insert the USB media into the primary (top) USB port on the machine.




- ① Primary (top) USB port for media
- ② USB media

Note

- The processing speed may vary by port selection and quantity of data. The primary (top) USB port processes the data faster than the center port. It is recommended to use the primary (top) USB port.
 - Two USB media cannot be used with this machine at the same time. If two USB media are inserted, only the USB media inserted first is detected.
- Do not insert anything other than USB media into the USB media port. Otherwise, the USB media drive may be damaged.



 Press coss to return to the original screen without saving.



→ The "Saving" screen is displayed. When the pattern is saved, the display returns to the original screen automatically.

Note

• Do not insert or remove USB media while "Saving" screen is displayed. You will lose some or all of the pattern you are saving.

Saving Embroidery Patterns in the Computer

Using the included USB cable, the machine can be connected to your computer, and the embroidery patterns can be temporarily retrieved from and saved in the "Removable Disk" folder in your computer. A total of about 3 MB of embroidery patterns can be saved in the "Removable disk", but the saved embroidery patterns are deleted when the machine is turned OFF.


Vice Note

 Do not turn the main power to OFF while the "Saving" screen is displayed. You will lose the pattern you are saving.

- Plug the USB cable connector into the corresponding USB ports for the computer and for the machine.
- 2

Turn on your computer and select "Computer (My computer)".


* The USB cable can be plugged into the USB ports on the computer and embroidery machine whether or not they are turned on.




- ① USB port for computer
- ② USB cable connector
- → The "Removable Disk" icon will appear in "Computer (My computer)" on the computer.


🟒 Note

- The connectors on the USB cable can only be inserted into a port in one direction. If it is difficult to insert the connector, do not insert it with force. Check the orientation of the connector.
- For details on the position of the USB port on the computer (or USB hub), refer to the instruction manual for the corresponding equipment.





- 4 Press 💽
 - * Press cLoss to return to the original screen without saving.



→ The pattern will be temporarily saved to "Removable Disk" under "Computer (My computer)". 5 Select the pattern's .phc file in "Removable Disk" and copy the file to the computer.

In Concession, Name	Statement Street	and the second s		
🐚 Organiza 🔹 🖽 V				in in
Favorite Linits	Plante	Date modified T)	ipa Soa	
Discuments		E.		
Fetares				
Minic .				
Facenily Charged	-			
D Seatthes	9999	9465.PHC		
III PUNC				
Folders	~			

Retrieving Patterns from the Machine's Memory





 $\rightarrow\,$ The machine displays the patterns currently in the memory.




Press the key of the pattern you want to retrieve.

* Press CLOSE to return to the original screen.



Press SEWING .



 \rightarrow The sewing screen is displayed.


Recalling from USB Media

You can recall a specific embroidery pattern from either direct USB media or a folder in the USB media. If the pattern is in a folder, check each folder to find the embroidery pattern.

V Note

• The processing speed may vary by port selection and quantity of data.

Insert the USB media into the primary (top) USB port on the machine (see page 247).



Primary (top) USB port for media
 USB media






→ Embroidery patterns and a folder in a top folder are displayed.

?

Si O

021



- ① Folder name
- ② Embroidery patterns in USB media
- ③ Path
- * The path to shows the current folder at the top of the list.


Embroidery patterns and subfolders within a folder are displayed.

- * Press 📧 to return to the previous folder.
- * Use the computer to create folders. Folders cannot be created with the machine.


- **4** Press the key of the pattern you want to retrieve.
 - * Press **CLOSE** to return to the original screen.


Embroidery	
	a la
la₁ cm ₩ cm	
PES001	PES002
Blue 🕥	
	0/ 120 - SEW
	0/ 120 ↔ sew

Press **DELETE** to delete the pattern. The pattern will be deleted from the USB media.



 $\rightarrow\,$ The sewing screen is displayed.





 $\rightarrow~$ The sewing screen is displayed.


5


EMBROIDERY APPLICATIONS

Using a Frame Pattern to Make an Appliqué (1)

You can use framed patterns of the same size and shape to create an appliqué. Embroider one pattern with a straight stitch and one pattern with a satin stitch.


Select a straight stitch frame pattern. Embroider the pattern onto the appliqué material, then cut neatly around the outside of the shape.









Embroider the same pattern from step **1** onto the base fabric.



3 Apply a thin layer of fabric glue or a temporary spray adhesive to the rear of the appliqué created in step 1. Attach the appliqué to the base fabric matching the shapes.




Select the satin stitch frame pattern of the same shape as the appliqué. Embroider over the appliqué and base fabric from step 3 to create the appliqué.



🗤 Note

 If you change the size or position of the patterns when selecting them, make a note of the size and location.




① Appliqué material

Using a Frame Pattern to Make an Appliqué (2)

This is a second method to make appliqué using embroidery patterns. You do not have to change the fabric in the embroidery frame using this method. Embroider one pattern with a straight stitch and one pattern with a satin stitch.




Select a straight stitch frame pattern, and embroider the pattern onto the base fabric.





Place the appliqué fabric over the pattern embroidered in step **1**.

* Be sure that the appliqué fabric completely covers the seam.






Embroider the same pattern on the appliqué fabric.




Remove the embroidery frame from the embroidery unit, and cut around the outside of the stitches.



Note


Do not remove the fabric from the embroidery frame to cut it. Also, do not pull strongly on the fabric. Otherwise, the fabric may loosen in the frame.

Select the satin stitch frame pattern of the 5 same shape as the appliqué.




Note

- Do not change the size or position of the pattern.
- If you change the size or position of the patterns when selecting them, make a note of the size and location.



① Appliqué material

Reattach the embroidery frame to the 6 embroidery unit, and embroider the satin stitch pattern to create an appliqué.




to be embroidered.

Sewing Split Embroidery Patterns

Split embroidery patterns created with Palette Ver.7 or later can be sewn. With split embroidery patterns, embroidery designs larger than the embroidery hoop are divided into multiple sections, which combine to create a single pattern after each section is sewn.

For details on creating split embroidery patterns and for more detailed sewing instructions, refer to the operation manual included with Palette Ver.7 or later.

The following procedure describes how to read the split embroidery pattern shown below from USB media and embroider it.



Connect to the machine the media containing the created split embroidery pattern, and then select the split embroidery pattern to be embroidered.

 For details on recalling patterns, refer to "Selecting Patterns from Embroidery Cards" on page 194, "Recalling from USB Media" on page 250, or "Recalling from the Computer" on page 252.


Embroidery			
*•∎ [≭] cm ₩ cm			
	_	_	
CLOSE	те 0/	112 ↔ MB	SEWING
	, de la	?	

 \rightarrow A screen appears so that a section of the split embroidery pattern can be selected.


Select section

- Select the sections in alphabetical order.
- A maximum of 12 sections can be displayed in one page. If there are 13 or more sections in the pattern,











Chapter **6** Embroidery Edit

EXPLANATION OF FUNCTIONS......260

SELECTING PATTERNS TO EDIT261

Selecting Embroidery Patterns/Baby Lock "Exclusives"/G	reek
Alphabet Patterns/Floral Alphabet Patterns/Utility Embro	idery
Patterns/Frame Patterns 2	262
Selecting Alphabet Character Patterns 2	262

EDITING PATTERNS......265

Key Functions
Moving the Pattern
Rotating the Pattern
Changing the Size of the Pattern
Deleting the Pattern
Changing the Configuration of
Alphabet Character Patterns
Changing Alphabet Character Spacing
Reducing Character Spacing 271
Separating Combined Character Patterns 272
Changing the Color of Each
Alphabet Character in a Pattern 273
Embroidering Linked Characters
Changing the Thread Color
Creating a Custom Thread Table 277
Adding a Color to the Custom Thread Table from the List 280 Choosing a Color from the Custom Thread Table
Designing Repeated Patterns 282
 Sewing Repeated Patterns Repeating One Element of a Repeated Pattern Color Sorting Repeated Patterns 285 Assigning Thread Marks 287 Duplicating a Pattern 288 After Editing 288
0
COMBINING PATTERNS
Editing Combined Patterns 289
Selecting combined embroidery patterns
Sewing Combined Patterns 292
VARIOUS EMBROIDERING FUNCTIONS293

Uninterrupted Embroidering (Using a Single Color) 293 Basting Embroidery 293 Creating an Appliqué Piece 294 Creating an Appliqué Piece 294 Using a Frame Pattern for the Outline 298 Using the Built-In Camera 300

USING THE MEMORY FUNCTION 303

PRINT AND STITCH (COMBINING EMBROIDERY PATTERNS AND PRINTED

Selecting a Pattern	,
Checking Only the Embroidery Pattern	5
Outputting the Background Image and	
Positioning Image	,
Using USB Media	5
Using a USB Cable	7
Printing the Background and	
Embroidery Position Sheet	3
Sewing Embroidery Patterns)

EXPLANATION OF FUNCTIONS

With the Embroidery Edit functions, you can combine embroidery patterns and character patterns, change the size of patterns, rotate patterns, and perform many other editing functions. This machine can perform the 9 functions listed below.

Print and Stitch (Combining Embroidery Patterns and Printed Designs)

You can create beautiful three-dimensional embroidered designs by ironing a background onto fabric or printing it onto printable fabric, then sewing complementary embroidery on top of the background.

Create Appliqué Piece

You can create an appliqué piece from the built-in patterns and patterns on embroidery cards.

Combine Patterns

You can easily create combinations of embroidery patterns, frame patterns, character patterns, patterns from the machine's memory, patterns from separately sold embroidery cards, and many other patterns.

Move Patterns

Within the 30 cm \times 20 cm (approx. 12 inches \times 8 inches) wide embroidery area, you can change the position of patterns, and check the position on the LCD.

Rotate Patterns

You can rotate patterns one degree, ten degrees or ninety degrees at a time.

Enlarge or Reduce Patterns

- You can make patterns larger or smaller.
- This function is not available for some patterns.

Create Mirror Images

You can create horizontal mirror images.

• This function is not available for some patterns.

Change Alphabet Character Spacing

You can increase or decrease the spacing between characters in combined patterns.

Change Alphabet Character Appearance/Layout

You can change the layout of the characters to a curved line, diagonal, etc. There are 6 choices total.

Change the Thread Colors of Patterns

You can change the thread colors of the pattern to your favorite colors.

Creating a Repeating Pattern

You can add copies of a pattern to create a pattern that repeats in a vertical or horizontal direction.








SELECTING PATTERNS TO EDIT

Prepare the machine for embroidery according to the instructions on page 182, and press and pres




to display the screen below.



- 1) Baby Lock "Exclusives"
- ② Embroidery patterns
- ③ Alphabet characters
- ④ Floral alphabet patterns
- ⑤ Greek alphabet patterns
- 6 Frame patterns
- ⑦ Utility embroidery patterns
- $\circledast\,$ Patterns saved in the machine's memory (see page 249)
- (9) Patterns saved in USB media (see page 250)
- (1) Patterns saved on the computer (see page 252)
- 1 Press this key to position the embroidery unit for storage

🏹 Memo

• See page 187 for more information on each category's selection screen.




Selecting Embroidery Patterns/ Baby Lock "Exclusives"/Greek Alphabet Patterns/Floral Alphabet Patterns/Utility Embroidery Patterns/Frame Patterns

Select the category of the pattern.




Press the key of the pattern you want to edit.

- * See pages 189 and 193 for more information on selecting patterns.
- \rightarrow The pattern is displayed in the top part of the screen.




→ The pattern selected for editing is outlined in red on the embroidery edit display.


Proceed to "EDITING PATTERNS" on page 265 to edit the pattern.



Selecting Alphabet Character Patterns

When you select character patterns from the embroidery edit screen, you can edit the appearance of the pattern at the same time.







Embroidery Edit 🛞

6 After you finish your selections, press
Embroidery Edit
BLACK 5 min
$\begin{array}{c} \blacksquare^{\ddagger} 4.7 \text{ orm} \\ 10.7 \text{ orm} \\ \blacksquare \\ $
$\rightarrow The embroidery edit screen will appear.$
Proceed to "EDITING PATTERNS" on page 265 to edit the pattern.
Embroidery Edit
L ↓ 10.7 cm ↓ 10.7 cm ↓ 10.7 cm ↓ 10.7 cm ↓ + 0.00 cm ↓ 0.0

EDITING PATTERNS






-) Shows the size of the entire combined pattern.
- O Shows the size of the pattern currently selected.
- $\ensuremath{\textcircled{}}$ Shows the distance from the center of the frame.
- ④ Shows the color sequence and times of each step of the pattern currently selected.
- $\ensuremath{\textcircled{}}$ Shows the degree of rotation for the pattern.

Memo

• If a key display is light gray, you cannot use that function with the selected pattern.

Key Functions




No.	Display	Key Name	Explanation	Page
1		Thread palette key	Press this key to change the colors of the displayed pattern.	276
2	ROTATE	Rotate key	Press this key to rotate the pattern. You can rotate a pattern one degree, ten degrees or ninety degrees at a time.	267
3	SIZE	Size key	Press this key to change the size of the pattern. Patterns can be enlarged or reduced.	268
4		Horizontal mirror image key	Press this key to make a horizontal mirror image of the selected pattern.	236
5	DENSITY	Density key	Press this key to change the density of frame patterns or character patterns.	237
6	MULTI	Multi color key	Press this key to change the color of individual characters in a pattern.	273
0	ADD	Add key	Press this key to add another pattern to the editing pattern.	288
8	DELETE	Delete key	Press this key to delete the selected pattern (the pattern outlined by the red box).	269
9		Pattern select key	When a combined pattern is selected, use these keys to select a part of the pattern to edit.	_
10	SEWING	Sewing key	Press this key to call up the sewing screen.	288
1	ARRAY	Array key	Press this key to change the configuration of a character pattern.	269
12	SPACING	Character spacing key	Press this key to change the spacing of character patterns.	270
13		Duplicate key	Press this key to duplicate a pattern.	288
14		Border key	Press this key to make and edit a repeating pattern.	282
19	< • >	Arrow keys (Center key)	Press these keys to move the pattern in the direction indicated by the arrow on the key. (Press of to return the pattern to its original position.)	267

Moving the Pattern

Press **Control** to move the pattern in the direction shown on the key.


Press • to return the pattern to the center.



① Distance from the center


The pattern can also be moved by dragging it. If a USB mouse is connected, move the mouse to position the pointer on the desired pattern, and then select and drag the pattern. The pattern can also be dragged by selecting it directly in the screen with your finger or the touch pen.

Rotating the Pattern





Select the angle by which the pattern is rotated.


- * Press for to rotate the pattern 90 degrees to the left.
- * Press to rotate the pattern 90 degrees to the right.
- * Press 10 to rotate the pattern 10 degrees to the left.
- * Press 10th to rotate the pattern 10 degrees to the right.
- * Press 📺 to rotate the pattern 1 degree to the left.
- * Press right.
- * Press **RESET** to return the pattern to its original position.




Degree of the pattern's rotation











Press close to return to the original screen.


Deleting the Pattern

Press **DELETE** to delete the pattern from the screen.




Changing the Configuration of Alphabet Character Patterns






* See page 263 for more information about layout types.





 \rightarrow The display will show the selected layout.




Changing Alphabet Character Spacing

1






- Note
 - It is not recommended to edit data and transfer to other or older version machines.
 Same features do not apply in other machines, so problems may occur.
 - Character spacing can be reduced only when characters are arranged normally on a straight line.




Separating Combined Character Patterns

Combined character patterns can be separated to adjust the character spacing or to separately edit the patterns after all characters have been entered.




Press ABC .



Use 📻 🐋 to select where the pattern is

to be separated, and then press *for to separate it.* For this example, the pattern will be separated between "T" and "a".



_上、Note

З


• A separated character pattern cannot be combined again.




① Color for each character

6

🖓 Embroidery Edit 👺







→ The needle is positioned in the lower-left corner of the pattern. The embroidery frame moves so that the needle is positioned correctly.

💥 Embroidery Edit 💥








Press the "Start/Stop" button to begin embroidering the remaining character patterns.



Changing the Thread Color


٦

You can change the thread color by moving the color to be changed to the top of the sewing order and selecting a new color from the thread colors in the machine.



 $\rightarrow~$ The thread color palette screen displays.


Press **m** or **m** to put the color you want to change at the top of the sewing order.




① 64 Embroidery threads table



- * To return to the original color, press **RESET**. If multiple colors have been changed, this command
- multiple colors have been changed, this command will return all colors to their original colors.
 You can select colors from the color palette by
- directly touching the color selection with the touch pen.



- ① Color palette
- → The selected color appears at the top of the sewing order.



 \rightarrow The display shows the changed colors.

🏹 Memo


• To select a color from the Custom Thread Table, "Choosing a Color from the Custom Thread Table" on page 281.

Creating a Custom Thread Table

You can create a custom thread table containing the thread colors that you most often use. You can select thread colors from the machine's extensive list of thread colors from nine different thread brands. You can select any color and move the color to your custom thread table.

Note


- Some machines may already have an additional 300 Robison-Anton thread colors contained in the custom thread table.
- You have the option to completely clear, or to restore the Custom Thread Table to the original factory setting. Visit the website for Custom Thread Table Clear/Restore Program and instructions.



🔁 Use 🗻 🔇 逐 💽 to choose where to add a color on the custom thread table. * You can choose colors from the custom thread from the custom thread table by directly touching the screen with the touch pen. You can scroll through 100 colors at a time using and 🐺 on the custom thread table. **Embroidery Edit** 1 30(¥ 1 CLEAR 100 2 LIST LOAD 2 1 3 4 5 6 Embroidery 7 8 9 -0 SET C CLOSE Bit del 2

① Custom thread table


② Press LOAD to download the clear and restore programs from the website



① Thread brand

ŝ

Embroidery Edit



2

- 1

~

V

CLEAR

Ł

V

SET

O i


<u>4</u> 300 ₹

50

100

LC AD

?




6


Designing Repeated Patterns

Sewing Repeated Patterns


Using the border function, you can create stitches using repeated patterns. You can also adjust the spacing of the patterns within a repeated pattern stitch.



3 Select the direction in which the pattern will be repeated.




- ① Vertical direction
- Horizontal direction
- ③ Repeating and deleting vertical keys
- ④ Repeating and deleting horizontal keys
- (5) Spacing keys
- → The pattern direction indicator will change depending on the direction selected.




6

- (1)




Choose the direction in which the repeated pattern will be cut.

- to cut horizontally.
- to cut vertically.




 \rightarrow The pattern direction indicator will change depending on the direction selected.




 \rightarrow The cut line will move.





- → The repeated pattern will be divided into separate elements.
- Press .
- Use 🖪 and 📄 to select the element to repeat.



Repeat the selected element.
Press CLOSE to finish repeating.
Embroidery Edit
16.6 cm 5.8 cm F 6.7 cm F 7

Viv Note

- Once you have cut a repeated pattern into separate elements, you cannot return to the original repeated pattern.
- Each element can be edited separately in the edit screen. See "Selecting combined embroidery patterns" on page 291.


Color Sorting Repeated Patterns


Press **SEWING** to automatically change the sewing


order of colors in combined border embroidery patterns so that the same color can be continuously sewn. This allows you to continue sewing without repeatedly changing the upper thread or changing the sewing order manually.


河 Memo

- In combined stitch patterns that contain two or more border patterns or other patterns combined with border patterns, the sewing order of only the border patterns is changed.
- When a group of two or more patterns using border patterns is repeated, the sewing order is changed so that the same color can be sewn continuously in each pattern.











1 min

7

×

HARVEST GOLD

HARVEST GOLD

HARVEST GOLD

HARVEST GOLD

÷

Ľ \checkmark Ы

 \uparrow R

◄ SELECT ►

LIME GREEN

LIME GREEN

LIME GREEN

l + To

B‡ + 0.00 cm

90 O 0°

+

10

+ 0.00 cm


\$ 16.7 cm

 \Leftrightarrow


000

CLOSE


2.9 cm



 \rightarrow The duplicate is positioned over the original pattern.



After Editing



- * To combine the pattern with other patterns, select (see page 289).
- * See page 210 for more information about sewing patterns.

🔊 Memo

If you want to return to the edit screen after

pressing sewing , press RETURN .

COMBINING PATTERNS Use \bigtriangledown to view 2/7, then select \blacksquare . 2 **Editing Combined Patterns** Embroidery Edit **Example:** Combining alphabet characters with an embroidery pattern and editing LIME GREEN 5 min MOSS GREEN 4 min 7 min CREAM BROWN 6 min 2 min 11 min LIGHT LILAC 5 min 16.7 cm 12.3 cm *• I • 2/7 -S. the set to select an embroidery V Press 1 pattern. $(\Delta \mathbf{A})$ LMS RETURN SET O i **Embroidery Edit** Press З SET **Exclusives** Embroidery Edit AA 300 LIME GREEN 5 min MOSS GREEN 4 min T YELLOW 7 min 6 min . -ORANGE 2 min 11 min LIGHT LILAC 5 min *. 16.7 cr • 2/7 -打ち Always press when removing Embroidery unit. 的 Ŵ ? O IS 0=1 (LMS) (AL RETURN SET



* With a USB mouse, your finger or the touch pen, drag the characters to move them.



Press ARRAY to change the layout of the

characters. Press CLOSE .


See page 269 for more information about changing the layout.



9


Press **me** to change the color of the characters.

See page 276 for more information about changing the color.





When all editing is finished, press **SEWING**.



Selecting combined embroidery patterns


If multiple patterns have been combined, use


select be to select the pattern to be edited. If a

USB mouse is connected, the pattern can be selected by clicking it. Move the mouse to position the pointer over the desired pattern, and then click the left mouse button. In addition, patterns can be selected by directly touching the screen with your finger or touch pen.




• Use **SELECT b** to select patterns that are overlapping and cannot be selected by clicking them or by touching the screen.





Sewing Combined Patterns

Combined patterns will be embroidered in the order they were entered. In this example, the embroidery order will be as follows:



🗤 Note

• Follow the directions in "Sewing Embroidery Patterns" on page 212.




by following the

Embroider

1

→ After the flowers are embroidered, the [+] cursor will move to the "Spring" part of the pattern.



→ When "Spring" is embroidered, the display returns to the sewing screen.

VARIOUS EMBROIDERING FUNCTIONS


Uninterrupted Embroidering (Using a Single Color)

A selected pattern can be stitched out in one color instead of multicolor. The machine will hesitate but not stop between color steps, and then

continue till the pattern is completed. Press


for the multicolor steps to become shaded and the selected pattern will embroider in a single color, instead of changing the thread while

embroidering. Press again to return to the pattern's original settings.




Basting Embroidery


Before embroidering, basting stitches can be sewn along the outline of the pattern. This is useful for embroidering fabric that cannot have stabilizer material affixed with an iron or adhesive. By stitching stabilizer material to the fabric, shrinkage of the stitching or misaligned pattern can be minimized.



n Memo

- The higher the setting, the farther the basting is from the pattern.
- The setting remains selected even if the machine is turned off.






295

6

🖓 Embroidery Edit 👺




- B Hoop the appliqué fabric in the embroidery frame, attach the embroidery frame to the machine, and then start embroidering.
- 9 After the pattern is embroidered, thread the machine with the thread for the cutting line, and then sew the cutting line (APPLIQUE MATERIAL).



① Cutting line for appliqué

🆙 Memo


- We recommend using thread for the cutting line that is closest to the color of the fabric.
- Remove the appliqué material from the embroidery frame, and then carefully cut along the stitching. After cutting, carefully remove all of the cutting line thread.



🟒 Note


- Depending on the pattern density and fabric used, there may be shrinking of the pattern or the appliqué may be misaligned with the placement line. We recommend cutting slightly outside of the cutting line.
 - When using patterns that are vertically and horizontally symmetrical, use a chalk pencil to indicate the pattern orientation before cutting it out.
 - Carefully cut out the pattern on the outline you just sewed. Do not cut inside the cutting line, otherwise the appliqué fabric will not be caught by the appliqué stitch.

Use two layers of adhesive water-soluble stabilizer material with their sticky sides together, and then hoop them in the embroidery frame.




🟒 Note

- If water-soluble stabilizer is used, it is not necessary to remove the stabilizer material after sewing the appliqué outline. To reduce shrinkage of the pattern, we recommend using water-soluble stabilizer.
- Put together two layers of water-soluble stabilizer, otherwise the stabilizer material may tear during embroidering.
- 2 Thread the machine with the thread for the outline from step (2), and then sew the placement line for the appliqué position (APPLIQUE POSITION).





Lightly apply glue or spray adhesive, and paste the appliqué piece so that it aligns with the placement line.



🟒 Note

Before pasting the appliqué piece down, make sure the appliqué piece is positioned correctly within the placement line. 4 With the machine threaded using the thread for the outline from step 12, sew the outline (APPLIQUE).




① Outline of appliqué piece

🏹 Memo

- The outline is sewn using satin stitching.
- Some glue may get onto the presser foot, needle, and needle plate at this time. Finish embroidering the appliqué pattern, and then clean off the glue.

After embroidering is finished, remove the stabilizer material from the embroidery frame.

- Use scissors to cut the excess water-soluble stabilizer from outside the appliqué outline.
- Soak the appliqué piece in water to dissolve the water-soluble stabilizer.



Dry the appliqué piece, and then iron it if necessary.

Note


Do not apply a strong force when ironing, otherwise the stitching may be damaged.

Using a Frame Pattern for the Outline

Using a frame pattern, the desired shape can be added as the outline of the appliqué.



- Perform the operations described in steps
 through <a>o of "Creating an Appliqué Piece" on page 294.
- Select the desired frame shape and pattern, and add it to the appliqué pattern.






Using the Built-In Camera to Align the Embroidering Position

The embroidering position can easily be aligned using the machine's built-in camera and the included embroidery positioning sticker.

🟒 Note


- When embroidery frame (small) is installed, the built-in camera cannot be used to align the embroidering position. Install embroidery frame (medium) or a larger embroidery frame.
- Affix the embroidery positioning sticker to the location in the fabric to be embroidered. Place the embroidery positioning sticker so that the center of the larger circle is at center of the embroidery pattern.



- ① Embroidery positioning sticker
- ② Center of the embroidery pattern
- ③ Embroidery field

🗤 Note


• When inserting the fabric in the embroidery frame, check that the embroidery pattern fits within the embroidery field for the frame that is used.



- ① Embroidery field
- ② Embroidery pattern
- ③ Embroidery positioning sticker
- Depending on the type of fabric that is used, a part of the embroidery positioning sticker may remain attached when it is peeled off. Before using the embroidery positioning sticker, check that it can be cleanly removed from a scrap piece of the fabric to be used.


After selecting the pattern, press sewing,


and then press (8).



→ A window appears so that the area containing the embroidery positioning sticker can be selected.

From the areas shown in the window, select the area containing the embroidery positioning sticker.






🗤 Note

3


- If the embroidery positioning sticker is placed in the center of embroidery frame, select any of the four areas.
- If the embroidery positioning sticker overlaps two areas, select either of the two areas.



レ Note

• Attach embroidery foot "W" before pressing scan. The embroidery foot "W" lowers and check the fabric thickness, to help the built-in camera recognize the embroidery positioning sticker.

Embroidery Edit 🛞




USING THE MEMORY FUNCTION


In the same way as embroidery patterns in Chapter 5, you can save and retrieve edited embroidery patterns to and from the machine's memory, a personal computer, or USB media. Refer to the relevant sections in Chapter 5 on saving and retrieving embroidery patterns and follow the same procedures in order to save and retrieve edited embroidery patterns. See page 242 for more information about the MEMORY FUNCTION.

PRINT AND STITCH (COMBINING EMBROIDERY PATTERNS AND PRINTED DESIGNS)

Completed embroidery patterns combined with printed designs are built into this machine. Beautiful three-dimensional embroidered designs can be created by ironing a background onto fabric or printing it onto printable fabric, then sewing complementary embroidery on top of the background.

Using iron-on paper





Select a pattern to be combined with the background image. \rightarrow See "Selecting a Pattern" on page 305.



Step2Output from the machine the background image and the positioning image.
 \rightarrow See "Outputting the Background Image and Positioning Image" on page 306.

Step3With a printer, print the background onto iron-on paper, and print the embroidery position sheet on plain paper. Then, iron the background image onto fabric.When using printable fabric		When using iron-on paper
Step3		With a printer, print the background onto iron-on paper, and print the embroidery position sheet on plain paper. Then, iron
When using printable fabric	Stop2	the background image onto fabric.
	Steps	When using printable fabric
With a printer, print the background onto printable fabric, and print the embroidery position sheet on plain paper.		With a printer, print the background onto printable fabric, and print the embroidery position sheet on plain paper.
\rightarrow See "Printing the Background and Embroidery Position Sheet" on page 308.		\rightarrow See "Printing the Background and Embroidery Position Sheet" on page 308.

 Step4
 Hoop in the embroidery frame the fabric with the background image ironed on or printed, check the embroidering position, and then start embroidering.

 →
 See "Sewing Embroidery Patterns" on page 309.

🟒 Note

• Print the background and embroidery position sheet in their original dimensions. If an image is printed in a different size, the sizes of the embroidery pattern and background may not match. In addition, the built-in camera cannot detect the embroidery position mark. Make sure that the print settings are correctly specified.


Selecting a Pattern


Patterns combining embroidery and printed designs can be selected from the pages that

contain _____. Select the desired pattern.

🏹 Memo

• Refer to the Quick Reference Guide for the detail of patterns which enable this function.






→ An image of the pattern combined with the background appears.

Checking Only the Embroidery Pattern





→ Only the embroidery pattern (not the background image of the selected embroidery pattern) is displayed.



 To return to the image of the pattern combined with the background, press

Outputting the Background Image and Positioning Image

Use USB media or the computer to output the following three images from the machine.


- * File name may differ depending on the PDF file selected.
- [xxx]r.pdf (Example: E_1r.pdf)
 An image flipped on a vertical axis (for an ironon transfer)



• [xxx]n.pdf (Example: E_1n.pdf) An image that is not flipped (for printing on printable fabric)



• [xxx]p.pdf (Example: E_1p.pdf) An image that is not flipped, but has positioning marks attached (for positioning)




ப் Note

- Print the background and embroidery position sheet in their original dimensions. If an image is printed in a different size, the sizes of the embroidery pattern and background may not match. In addition, the built-in camera cannot detect the embroidery position mark. Make sure that the print settings are correctly specified.
- When printing the PDF file of the image with positioning marks, specify the highest image quality possible for full-color printing. In addition, use matte printing paper. Due to poor printing conditions, the machine's built-in camera may not be able to correctly detect the positioning marks. (For details on printing, refer to the operating instructions for your printer.)

Using USB Media


Insert the USB media into the primary (top) USB port on the machine.





 \rightarrow The select USB output screen appears.

Press ito select the primary (top) USB port where the primary USB media is inserted.




→ Two files of the background image only and one file for aligning embroidery into position are copied (PDF format) onto the USB media.

🦙 Memo


- Do not remove the USB media from the machine until data output is finished.
- Remove the USB media where the image data is saved from the machine, and then copy the image data from the USB media to the computer.

■ Using a USB Cable

Plug the USB cable connectors into the corresponding USB ports on the computer and on the machine.



 \rightarrow The select USB output screen appears.



→ Two files of the background image and one file for aligning embroidery into position are copied (PDF format) into "Removable Disk" under "Computer (My computer)".

ן Memo

- Do not disconnect the USB cable from the machine until data output is finished.
- Copy the image data saved in "Removable Disk" into a different file before closing.

Printing the Background and Embroidery Position Sheet

Print the PDF files of the background and embroidery position sheet. The background file that is printed differs depending on whether ironon paper or printable fabric is used.

To view the PDF file, Adobe[®] Reader[®] is needed. If it is not installed on your computer, you can download it from the Adobe Systems website: http://www.adobe.com/

1

Open the PDF file to be printed, click "File"-"Print", and then set "Page Scaling" to "None (100%)".

🟒 Note

• Print the background and embroidery position sheet in their original dimensions. If an image is printed in a different size, the sizes of the embroidery pattern and background may not match. In addition, the built-in camera cannot detect the embroidery position mark. Make sure that the print settings are correctly specified.

Print the background image.

When printing onto iron-on paper, print the file named E_1r.pdf (an image flipped on a vertical axis). When printing onto printable fabric, print the file named E_1n.pdf (an image that is not flipped).



① Background image

🟒 Note

- Before printing onto iron-on paper or printable fabric, we recommend performing a test print to check the print settings.
- For details on printing on iron-on transfer sheets or printable fabric, refer to the instructions for the iron-on transfer sheets and printable fabric.
- Some printers will automatically print an image flipped if an iron-on transfer sheet is selected as the paper. For details, refer to the instructions for the printer being used.

Print the embroidery position sheet (file named E_1p.pdf) onto plain paper.



① Embroidery position sheet

🟒 Note


- When printing the PDF file for the embroidery position sheet, specify the highest image quality possible for full-color printing. In addition, we recommend printing on matte paper. If this is not done, the builtin camera may not be able to correctly detect the embroidery positioning mark.
- If an iron-on transfer sheet is used, transfer the image onto fabric.



memo


- For details on transferring from iron-on transfer sheets, refer to the instructions for the iron-on transfer sheets.
- If necessary, cut the iron-on transfer sheet to the size of the pattern before transferring the image.

Sewing Embroidery Patterns






- Cut the paper printed with the center positioning image $\frac{8}{5}$ so it can easily be positioned aligned with the background image on the fabric.
 - * Lines or color changes in the image can help you find the correct alignment position.



Place the paper printed with the positioning image on top of the fabric so that the pattern is aligned, and then affix the paper to the fabric with cellophane tape to prevent the paper from moving.



① Cellophane tape

After checking that a pattern is selected, press **SEWING**.

 \rightarrow The sewing screen appears.

🟒 Note

• Before embroidering, check that the embroidery position sheet is perfectly aligned with the background.

Align the embroidering position according to steps ² through ⁶ of "Using the Built-In Camera to Align the Embroidering Position" on page 300.

Remove the positioning sheet and press the "Start/Stop" button to begin embroidering.

CAUTION

Before pressing the "Start/Stop" button to begin embroidering, remove the positioning sheet taped to the fabric in step 3.



CARE AND MAINTENANCE
Cleaning the LCD Screen
Cleaning the Machine Casing
Cleaning the Race
Cleaning the Bobbin Case
Cleaning the Cutter in the Bobbin Case Area
About the Maintenance Message
ADJUSTING THE SCREEN
Touch Panel is Malfunctioning
TROUBLESHOOTING
ERROR MESSAGES
ERROR MESSAGES
Alarm Sounds
Alarm Sounds
Alarm Sounds
 Alarm Sounds

CARE AND MAINTENANCE

Be sure to unplug the machine before cleaning it. Otherwise, electric shock or injury may result.

Cleaning the LCD Screen

If the screen is dirty, gently wipe it with the included LCD cleaning cloth or a soft, dry cloth. Do not use organic solvents or detergents.

• Do

• Do not wipe the LCD screen with a damp cloth.

ച്ച Memo

 Occasionally, condensation may form on the LCD screen or it may become fogged up; however, this is not a malfunction. After a while, the cloudiness will disappear.

Cleaning the Machine Casing

If the surface of the machine is dirty, lightly soak a cloth in a neutral detergent, squeeze it out firmly, and then wipe the surface. Then wipe again with a dry cloth.


Cleaning the Race

If dust or bits of dirt collect in the race or bobbin case, the machine will not run well, and the bobbin thread detection function may not operate. Keep the machine clean for best results.




video example of cleaning the race (see page 34). Follow the steps explained below to complete the operation. Press the "Needle Position" button to raise the needle.

- Turn the main power to OFF.
- Remove the needle and the presser foot holder (see pages 55 through 56).
- Remove the flat bed attachment or the embroidery unit if either is attached.
- Grasp both sides of the needle plate cover, and then slide it toward you.




- ① Needle plate cover
- \rightarrow The needle plate cover is removed.



① Bobbin case

Use the cleaning brush or a vacuum cleaner to remove any lint and dust from the race and bobbin thread sensor and the surrounding area.





- Cleaning brush
- 2) Race
- ③ Bobbin thread sensor

Note

- Do not apply oil to the bobbin case.
- If lint or dust collects on the bobbin thread sensor, the sensor may not operate correctly.

Insert the bobbin case so that the projection on the bobbin case aligns with the spring.






- ① Projection
- ② Spring

CAUTION

Be sure that the bobbin case is correctly installed. Otherwise, the needle may break. Insert the tabs on the needle plate cover into the needle plate, and then slide the cover back on.



Note


- Never use a bobbin case that is scratched; otherwise, the upper thread may become tangled, the needle may break, or sewing performance may suffer. For a new bobbin case (part code: XC3153-251 (green marking on the screw), XC8167-451 (no color on the screw)), contact your nearest authorized retailer.
- If the needle plate has been removed it is especially important to reinstall the needle plate and tighten the screws prior to installing the bobbin case.

Cleaning the Bobbin Case

Thread wax and dust easily collect around the notch in the tension spring on the bobbin case, resulting in an incorrect thread tension. Therefore, the bobbin case should be cleaned as necessary should tension problems arise.

When cleaning the bobbin case, use card stock or another type of paper of similar thickness and sturdiness in order to prevent pieces of paper tearing off and getting lodged in the bobbin case.

- Follow steps 1 to 6 in "Cleaning the Race" to remove the bobbin case.
- 2 Using a piece of paper of adequate thickness and sturdiness, slide the paper between the tension plate base and the tension spring and also slide the paper behind the notch of the spring to remove any dirt or dust.



- ① Tension plate base
- ② Notch
- ③ Paper (e.g. business card type)
- ④ Tension spring

🏹 Memo

 Do not bend the tension spring. In addition, do not use anything other than recommended paper to clean the bobbin case.

Use the cleaning brush to remove any lint and dust from inside the bobbin case.

Replace the bobbin case and needle plate cover.

Cleaning the Cutter in the Bobbin Case Area


The cutter below the needle plate should be cleaned. If dust or lint accumulate on the cutter, it will be difficult to cut the thread when the "Thread Cutter" button is pressed or the automatic thread cutting function is used. Clean the cutter when the thread is not easily cut.

- Foll
 - Follow steps 1 through 5 in "Cleaning the Race" to remove the needle plate cover.
- 2

Use the screwdriver included with the machine to unscrew and remove the needle plate.



Use the cleaning brush or a vacuum cleaner to remove any lint and dust from the cutter in the bobbin case area.



① Cutter

• Do not touch the cutter, otherwise injuries may result.

4 Use the screwdriver included with the machine to screw and attach the needle plate.



Insert the tabs on the needle plate cover into the needle plate, and then slide the cover back on.

About the Maintenance Message



Once this message appears, it is recommended to take your machine to an authorized retailer for a regular maintenance check. Although this message will disappear and the machine will continue to

function once you press or, the message will display several more times until the appropriate maintenance is performed. Please take the time to arrange the maintenance

your machine requires once this message appears. Such steps will help to ensure you receive continued, uninterrupted hours of machine operation for the future.

ADJUSTING THE SCREEN

Touch Panel is Malfunctioning

If the screen does not respond correctly when you touch a key (the machine does not perform the operation or performs a different operation), follow the steps below to make the proper adjustments.



Holding your finger on the screen, turn the main power switch to OFF and back to ON.



 \rightarrow The touch panel adjustment screen is displayed.

Using the included touch pen, lightly touch the center of each +, in order from 1 to 5.

Note

 Only use the included touch pen to touch the screen. Do not use a mechanical pencil, pin, or other sharp object. Do not press strongly on the screen. Otherwise, damage may result.





Turn the main power to OFF, then turn it back to ON.

_レNote

• If you finish the screen adjustment and the screen still does not respond, or if you cannot do the adjustment, contact your authorized retailer.

Operation Guide

 \rightarrow

 \rightarrow

TROUBLESHOOTING

If you have a minor problem with your sewing machine, check the following solutions. If the solutions

suggested do not correct the problem, contact your authorized retailer. Press

Troublestioning for advice about minor sewing problems during sewing. Press cLOSE at any time to return to the original screen. If the problem persists, contact your nearest authorized retailer.

Problem	Cause	Solution	Page		
The thread is tangled on the wrong side of	Upper threading is incorrect.	Check the steps for threading the machine and rethread the machine.	46		
the fabric.	Using improper needle or thread for the selected fabric.	Check the "Fabric/Thread/Needle Combinations" chart.	58		
The upper thread is too tight.	The bobbin thread is incorrectly installed.	Correctly install the bobbin thread.	43		
Cannot thread the needle	Needle is not in the correct position.	Press the "Needle Position" button to raise the needle.	3		
	Needle is installed incorrectly.	Reinstall the needle correctly.	56		
	Needle is turned, bent or the point is dull.	Replace the needle.	56		
Cannot lower the presser foot with the presser foot lever	sser foot with the Lifter" button. the presser foot.				
Thread tension is incorrect	Upper threading is incorrect.	Check the steps for threading the machine and rethread the machine.	46		
	Bobbin is set incorrectly.	Reset the bobbin. (If needle plate was removed, reinstall needle plate and tighten screws prior to installing bobbin case.)	43		
	Using improper needle or thread for the selected fabric.	Check the "Fabric/Thread/Needle Combination" chart.	58		
	Presser foot holder is not attached correctly.	Reattach the presser foot holder correctly.	55		
	Thread tension is set incorrectly.	Adjust the thread tension.	67, 225		
	Bobbin thread is incorrectly wound.	Use a correctly wound bobbin.	37		
	Needle is turned, bent or the point is dull.	Replace the needle.	56		
Upper thread breaks	Machine is not threaded correctly (used the wrong spool cap, spool cap is loose, the thread did not catch the needle bar threader, etc.)	Rethread the machine correctly.	46		
	Needle is turned, bent or the point is dull.	Replace the needle.	56		
	There are scratches on the race.	Replace the race, or consult your authorized retailer.	312		
	Upper thread tension is too strong.	Adjust the thread tension.	67, 225		
	Using improper needle or thread for the selected fabric.	Check the "Fabric/Thread/Needle Combinations" chart.	58		
	Thread is twisted.	Use scissors, etc., to cut the twisted thread and remove it from the race, etc.	_		
	There are scratches near the hole of the needle plate.	Replace the needle plate, or consult your authorized retailer.	86		
	There are scratches near the hole in the presser foot.	Replace the presser foot, or consult your authorized retailer.	54		
	Needle is installed incorrectly.	Reinstall the needle correctly.	56		
	Thread is knotted or tangled.	Rethread upper and lower thread.	43, 46		
	A bobbin designed specifically for this machine is not used.	Incorrect bobbins will not work properly. Only use a bobbin designed specifically for this machine.	43		

Problem	Cause	Solution	Page
Bobbin thread breaks	Bobbin is set incorrectly.	Reset the bobbin thread correctly.	43
	There are scratches on the bobbin or it doesn't rotate properly.	Replace the bobbin.	43
	Thread is twisted.	Use scissors, etc. to cut the twisted thread and remove it from the race, etc.	_
	A bobbin designed specifically for this machine is not used.	Incorrect bobbins will not work properly. Only use a bobbin designed specifically for this machine.	43
Bobbin thread does not wind neatly on the	The thread is not passed through the bobbin winding thread guide correctly.	Correctly pass the thread through the bobbin winding thread guide.	38
oobbin.	Bobbin spins slowly.	Press [+] in the bobbin winding window to increase the bobbin winding speed.	39
	The thread that was pulled out was not wound onto the bobbin correctly.	Wind the thread that was pulled off around the bobbin 5 or 6 times clockwise.	39
Skipped stitches	Needle is turned, bent or the point is dull.	Replace the needle.	56
	Using improper needle or thread for the selected fabric.	Check the "Fabric/Thread/Needle Combination" chart.	58
	Machine is threaded incorrectly.	Check the steps for threading the machine and rethread it correctly.	46
	Dust or lint has collected under the needle plate.	Remove the dust or lint with the brush.	312
	Needle is installed incorrectly.	Reinstall the needle correctly.	56
	Needle is defective.	Replace the needle.	56
	Thin or stretch fabrics are being sewn.	Sew with one sheet of thin paper under the fabric.	64
leedle breaks	Needle is installed incorrectly.	Reinstall the needle correctly.	56
ŀ	Needle clamp screw is not tightened.	Tighten the needle clamp screw.	57
	Needle is turned or bent.	Replace the needle.	56
	Using improper needle or thread for the selected fabric.	Check the "Fabric/Thread/Needle Combination" chart.	58
	Wrong presser foot was used.	Use the recommended presser foot.	"STITCH SETTING CHART"
	Upper thread tension is too strong.	Adjust the thread tension setting.	67, 225
	Fabric is pulled during sewing.	Do not pull the fabric during sewing.	—
	Spool cap is set incorrectly.	Check the method for attaching the spool cap, then reattach the spool cap.	46
	There are scratches around the holes in the needle plate.	Replace the needle plate, or consult your authorized retailer.	86
	There are scratches around the hole(s) in the presser foot.	Replace the presser foot, or consult your authorized retailer.	54
	There are scratches on the race.	Replace the race, or consult your authorized retailer.	312
	Needle is defective.	Replace the needle.	56
	Upper threading is incorrect.	Check the steps for threading the machine and rethread the machine.	46
	Bobbin is set incorrectly.	Reset the bobbin thread correctly.	43
	Presser foot is attached incorrectly.	Attach the presser foot correctly.	54
	Screw of the presser foot holder is loose.	Securely tighten the screw of the presser foot.	55
	Fabric is too thick.	Use fabric that the needle can pierce when the handwheel is turned.	63
	Fabric is fed forcefully when sewing thick fabric or thick seams.	Allow the fabric to be fed without being forcefully pushed.	
	Stitch length is too short.	Adjust the stitch length.	67
	Stabilizer is not attached to fabric being embroidered.	Attach stabilizer.	152, 197
	Bobbin thread is incorrectly wound.	Use a correctly wound bobbin.	37

Problem	Cause	Solution	Page
Fabric does not feed through the machine	Feed dogs are set in the down position.	Press , and then turn the handwheel to	105
		raise the feed dogs.	
	Stitches are too close together.	Lengthen the stitch length setting.	67
	Wrong presser foot was used.	Use the correct presser foot.	"STITCH SETTING CHART"
	Needle is turned, bent or the point is dull.	Replace the needle.	56
	Thread is entangled.	Cut the entangled thread and remove it from the race.	—
Fabric puckers	There is a mistake in the upper or bobbin threading.	Check the steps for threading the machine and rethread it correctly.	43, 46
	Using improper needle or thread for the selected fabric.	Check the "Fabric/Thread/Needle Combination" chart.	58
	Thread tension is set incorrectly.	Adjust the thread tension.	67, 225
	Stitches are too long when sewing thin fabrics.	Shorten the stitch length.	67
	Needle is turned, bent or the point is dull.	Replace the needle.	56
	Spool cap is set incorrectly.	Check the method for attaching the spool cap, then reattach the spool cap.	46
	Wrong presser foot.	Use the correct presser foot.	"STITCH SETTING CHART"
High-pitched sound	Dust or lint is caught in the feed dogs.	Remove the dust or lint.	312
while sewing	Pieces of thread are caught in the race.	Clean the race.	312
	Upper threading is incorrect.	Check the steps for threading the machine and rethread the machine.	46
	There are scratches on the race.	Replace the race, or consult your authorized retailer.	312
	A bobbin designed specifically for this machine is not used.	Incorrect bobbins will not work properly. Only use a bobbin designed specifically for this machine.	43
Character pattern does not turn out	Wrong presser foot was used.	Attach the correct presser foot.	"STITCH SETTING CHART"
	Pattern adjustment settings were set incorrectly.	Revise the pattern adjustment settings.	153
	Did not use a stabilizer material on thin fabrics or stretch fabrics.	Attach a stabilizer material.	152
	Thread tension is set incorrectly.	Adjust the thread tension.	67, 225
	Fabric was pulled, pushed or fed at an angle while it was being sewn.	Sew while guiding the fabric with your hands so that the fabric is fed in a straight line.	60

생활Appendix응왕

Problem	Cause	Solution	Page	
Embroidery pattern does not sew out	Thread is twisted.	Use scissors, etc., to cut the twisted thread and remove it from the race, etc.	—	
correctly	Fabric was not inserted into the frame correctly (fabric was loose, etc.).	If the fabric is not stretched tight in the frame, the pattern may turn out poorly or there may be shrinkage of the pattern. Set the fabric into the frame correctly.	200	
	Stabilizing material was not attached.	Always use stabilizing material, especially with stretch fabrics, lightweight fabrics, fabrics with a coarse weave, or fabrics that often cause pattern shrinkage. See your authorized retailer for the proper stabilizer.	197	
	There was an object placed near the machine, and the carriage or embroidery frame hit the object during sewing.	If the frame bumps something during sewing, the pattern will turn out poorly. Do not place anything in the area where the frame may bump it during sewing.	210	
	Fabric outside the frame edges interferes with the sewing arm, so the embroidery unit cannot move.	Reinsert the fabric in the embroidery frame so that the excess fabric is away from the sewing arm, and rotate the pattern 180 degrees.	200	
	Fabric is too heavy, so the embroidery unit cannot move freely.	Place a large thick book or similar object under the arm head to lightly lift the heavy side and keep it level.		
	Fabric is hanging off the table.	If the fabric is hanging off the table during embroidery, the embroidery unit will not move freely. Place the fabric so that it does not hang off the table or hold the fabric to keep it from dragging.		
	Fabric is snagged or caught on something.	Stop the machine and place the fabric so that it does not get caught or snagged.		
	Embroidery frame was removed during sewing (for example, to reset the bobbin). The presser foot was bumped or moved while removing or attaching the embroidery frame, or the embroidery unit was moved.	If the presser foot is bumped or the embroidery unit is moved during sewing, the pattern will not turn out. Be careful when removing or reattaching the embroidery frame during sewing.	221	
	Stabilizer is incorrectly attached, for example, it is smaller than the embroidery frame.	Attach the stabilizer correctly.	197	
Machine does not	There is no pattern selected.	Select a pattern.	79, 146, 186, 261	
operate	"Start/Stop" button was not pushed.	Press the "Start/Stop" button.	3	
	Main power switch is not turned on.	Turn the main power to ON.	12	
	Presser foot is not lowered.	Lower the presser foot.	3	
	"Start/Stop" button was pushed with the foot controller attached.	Remove the foot controller, or use the foot controller to operate the machine.	61	
	The "Start/Stop" button was pressed while the machine is set for the sewing speed controller to control the zigzag stitch width.	Use the foot controller instead of the "Start/ Stop" button to operate the machine, or set the Width control to OFF in the Sewing settings.	22, 61	
	All keys and buttons have been locked by	Press with to unlock all keys and buttons.	54, 56	
Embroidery unit does	There is no pattern selected.	Select a pattern.	186, 261	
not operate	Main power switch is not turned on.	Turn the main power to ON.	12	
	Embroidery unit is not attached correctly.	Reattach the embroidery unit correctly.	184	
	Embroidery frame was attached before the unit was initialized.	Perform the initialization process correctly.	184	
Nothing happens, even if the LCD display is pressed	The screen has been locked.	Press either of the following keys to unlock the screen.	_	
The fabric feeds in the opposite direction.	The feed mechanism is damaged.	Contact your nearest authorized retailer.		
The LCD screen is fogged up.	Condensation has formed on the LCD screen.	After a while, the cloudiness will disappear.		




- This machine is equipped with a thread detection device. If the "Start/Stop" button is pushed before the upper threading is done, the machine will not operate properly. Also, depending on the pattern selected, the machine may feed the fabric even if the needle is raised. This is due to the needle bar release mechanism. At these times, the machine will make a sound different from that made during normal sewing. This is not the sign of a malfunction.
- If the power is disconnected during sewing: Turn the main power to OFF and unplug the machine. If you restart the machine, follow the instructions for operating the machine correctly.

ERROR MESSAGES

If the machine is not properly set and the "Start/Stop" button or the "Reverse/Reinforcement Stitch" button is pressed, or if the operation procedure is incorrect, the machine does not start. An alarm sounds and an error message is displayed on the LCD. If an error message displays, follow the instructions in the message.

Below is an explanation of error messages. Refer to these when necessary (if you press or do the operation correctly while the error message is displayed, the message disappears).



CLOSE

the machine

OK

322

This message appears when


pressed to delete the settings

for a utility stitch. To delete the selected settings, press

DELETE OF DELETE IS

ок

OK



This message is displayed when an unusable embroidery card is inserted.



?

(...)

This message is displayed when the "Reverse/ Reinforcement Stitch" button is pushed while the embroidery unit is attached.



This message is displayed when the foot controller is pressed while the embroidery unit is attached and machine is set up for embroidering.

Appe

ndix

ŚŚ



when the patterns you are editing take up too much memory, or if you are editing too many patterns for the memory.





This message is displayed when the built-in camera cannot detect the edge of the fabric. If this message appeared

after sewing has reached 1 to 2 cm (about 3/8 to 3/4 inch) from the edge of the fabric, refer to step 13 in "Edge Sewing" on page 144. If this message appeared during edge sewing, the edge of the fabric cannot be detected by the built-in

camera. Press CLOSE , raise

the presser foot, raise the needle if it is lowered, and then perform the procedure described in "Edge Sewing" on page 140 starting from step 6.

If this error message appears again, sew without using edge sewing function.


This message is displayed



This message is displayed when a key on the LCD display is touched while the needle is in the down position.

broider			
	y fram	е.	

This message is displayed when the machine is in embroidery mode and the embroidery unit tries to initialize while the embroidery frame is attached.



This message is displayed when the machine is ready to sew an embroidery pattern, and the "Start/Stop" button is pushed while the embroidery frame is not attached.



This message is displayed when there are too many characters and the curved character configuration is impossible.



This message is displayed when the machine is in embroidery edit mode, and you try to use an editing function when the pattern is not completely within the red outline.



This message is displayed when the machine is in embroidery mode, and the character pattern combination is too large to fit in the embroidery frame.




This message is displayed when you try to save a copyright protected pattern to USB media/Computer. According to copyright laws, patterns that are illegal to reproduce or edit cannot be saved to USB media or computer. If this message displays, save the pattern in the machine's memory.



This message is displayed when the machine is in embroidery mode and the combined character pattern is too large for the embroidery frame. You can rotate the pattern 90 degrees and continue combining characters.

 $\langle \cdot \rangle$ Change to a larger embroidery frame CLOSE

This message is displayed when the machine is in embroidery mode and the small frame is attached, and the selected pattern does not fit in the small frame. This message appears when embroidery frame (small) is attached while aligning the embroidery position using the built-in camera.








This message appears when the built-in camera is being used to align the embroidery position, but the embroidery positioning sticker is too near an edge or the pattern extends from the embroidery frame. Change the position of the embroidery positioning sticker, and then try aligning the position again. See page 205 or 300.

This message is displayed when the upper thread is broken or not threaded correctly, and the "Start/Stop" button or the "Reverse/ Reinforcement Stitch" button is pressed.



This message is displayed when there is no stitch or embroidery pattern selected and the "Start/Stop" button or the "Reverse/Reinforcement Stitch" button is pressed.



This message is displayed when the bobbin thread is running out.



This message is displayed when the "Presser Foot Lifter" button is pushed while the presser foot lever is raised/ the needle is lowered.




This message is displayed when the memory is full and the stitch or pattern cannot be saved.



This message is displayed when the "Start/Stop" button is pushed to sew Utility stitches or Character/ Decorative stitches while the foot controller is connected. (This message does not appear when embroidering).



This message is displayed when the machine is retrieving a previously saved pattern while in embroidery edit mode.




This message is displayed when the "Start/ Stop" button is pushed while the machine is in embroidery edit mode and a pattern is being edited.

? OK to delete the selected pattern? CANCEL ОК


This message is displayed when, after selecting a


pattern, UtilityStitch ,



pressed and the pattern is about to be deleted.

CLOSE







This message is displayed
when you press

Sewing Guide in the screen other than the Utility Stitch, or

ess Pattern Explanation in the

screen other than the Utility Stitch or Character/ Decorative Stitch.

Alarm Sounds

If the operation was performed incorrectly, an alarm sounds to indicate that an error occurred. If the operation was performed correctly, the machine beeps to confirm the operation.



 To cancel the operation beep or to change the volume, press , display screen 3/7, and then change the setting for "Speaker". See page 23 for more details.

SPECIFICATIONS

	Item	Specification				
Sewing Machine (Box 1 of 3)	Dimensions of machine	Approx. 61.5 cm (W) \times 33.1 cm (H) \times 28.1 cm (D) (approx. 24-7/32 inches (W) \times 13-1/32 inches (H) \times 11-1/16 inches (D))				
	Dimensions of box	Approx. 68.5 cm (W) \times 47.0 cm (H) \times 39.0 cm (D) (approx. 26-31/32 inches (W) \times 18-1/2 inches (H) \times 15-11/32 inches (D))				
	Weight of machine	Approx. 15 kg (approx. 33 lb)				
	Weight of box (for shipping)	Approx. 19 kg (approx. 42 lb)				
	Sewing speed	70 to 1000 stitches per minute				
	Needles	Home sewing machine needles (HA × 130)				
Accessory Box (Box 2 of 3)	Dimension of box	Approx. 68.5 cm (W) \times 15.2 cm (H) \times 39.4 cm (D) (approx. 26-31/32 inches (W) \times 6 inches (H) \times 15-33/64 inches (D))				
	Weight of box (for shipping)	Approx. 5 kg (approx. 11 lb)				
Embroidery Unit (Box 3 of 3)	Dimensions of embroidery unit	Approx. 51.0 cm (W) \times 13.9 cm (H) \times 46.2 cm (D) (approx. 20-5/64 inches (W) \times 5-15/32 inch (H) \times 18-3/16 inches (D))				
	Dimensions of machine with embroidery unit attached	$\label{eq:Approx.81.6 cm (W) \times 33.1 cm (H) \times 46.2 cm (D) (approx. 32-1/8 inches (W) \times 13-1/32 inches (H) \times 18-3/16 inches (D))}$				
	Dimensions of box	Approx. 68.5 cm (W) \times 62.2 cm (H) \times 23.6 cm (D) (approx. 26-31/32 inches (W) \times 24-31/64 inches (H) \times 9-19/64 inches (D))				
	Weight of embroidery unit	Approx. 4 kg (approx. 9 lb)				
	Weight of box (for shipping)	Approx. 13 kg (approx. 29 lb)				
Total Shipping Weight (Com	bination of all 3 boxes complete)	Approx. 41 kg (approx. 90 lb)				

* Please be aware that some specifications may change without notice.


UPGRADING YOUR MACHINE'S SOFTWARE

You can use USB media or a computer to download software upgrades for your sewing machine. When an upgrade program is available on "www.babylock.com", please download the files following the instructions on the website and steps below.



• When using USB media to upgrade the software, check that no data other than the upgrade file is saved on the USB media being used before starting to upgrade.

Upgrade Procedure Using USB Media




 \rightarrow The following screen will appear on the LCD.



З

Insert the USB media into the primary (top) USB port on the machine. The media device should only contain the upgrade file.




- ① Primary (top) USB port for media
- ② USB media

レ Note

• The access lamp will begin blinking after inserting USB media, and it will take about 5 to 6 seconds to recognize the media. (Time will differ depending on the USB media).

Appendix 🛞



 \rightarrow The following message will appear. Connected to PC. Do not disconnect the USB cable. When the message disappears, press LOAD Press LOAD after saving the upgrade file in the machine. CLOSE LOAD \rightarrow The upgrade file is downloaded. Note • If an error occurs, a red text error message will appear. If the download is performed successfully, following message will appear. Upgrade complete. Unplug the USB cable, and turn the 6 machine off and on again.

STITCH SETTING CHART

The following chart shows information for each utility stitch concerning applications, stitch lengths, stitch widths, and whether or not the twin needle mode can be used.

• Quil

• Quilting foot "C" is used when the straight stitch needle plate is attached to the machine. Refer to "Using Free motion Quilting Foot "C"" on page 105.

Stitch	Stitch name	Press	er foot	Applications		h width (inch)]		h length 1 (inch)]	Twin
Stiten	Stitch hame	6	60	Αμριτατιοπο	Auto.	Manual	Auto.	Manual	needle
1-01 	Straight stitch (Left)		°S	General sewing, gather, pintuck, etc. Reverse stitch is sewn while pressing "Reverse/ Reinforcement Stitch" button.	0.0 (0)	0.0 - 7.0 (0 - 1/4)	2.5 (3/32)	0.2 - 5.0 (1/64 - 3/16)	ОК (Ј)
1-02 : : : : :	Straight stitch (Left)		ŝ	General sewing, gather, pintuck, etc. Reinforcement stitch is sewn while pressing "Reverse/Reinforcement Stitch" button.	0.0 (0)	0.0 - 7.0 (0 - 1/4)	2.5 (3/32)	0.2 - 5.0 (1/64 - 3/16)	ОК (Ј)
1-03 " " "	Straight stitch (Middle)		ŝ	General sewing, gather, pintuck, etc. Reverse stitch is sewn while pressing "Reverse/ Reinforcement Stitch" button.	3.5 (1/8)	0.0 - 7.0 (0 - 1/4)	2.5 (3/32)	0.2 - 5.0 (1/64 - 3/16)	ОК (Ј)
1-04	Straight stitch (Middle)		ŝ	General sewing, gather, pintuck, etc. Reinforcement stitch is sewn while pressing "Reverse/Reinforcement Stitch" button.	3.5 (1/8)	0.0 - 7.0 (0 - 1/4)	2.5 (3/32)	0.2 - 5.0 (1/64 - 3/16)	ОК (Ј)
1-05 	Triple stretch stitch		ŝ	General sewing for reinforcement and decorative topstitching	0.0 (0)	0.0 - 7.0 (0 - 1/4)	2.5 (3/32)	1.5 - 4.0 (1/16 - 3/16)	ОК (J)
1-06 4 4	Stem stitch		ŝ	Reinforced stitching, sewing and decorative applications	1.0 (1/16)	1.0 - 3.0 (1/16 - 1/8)	2.5 (3/32)	1.0 - 4.0 (1/16 - 3/16)	ОК (J)
1-07 	Decorative stitch	N	° s	Decorative stitching, top stitching	0.0 (0)	0.0 - 7.0 (0 - 1/4)	2.5 (3/32)	1.0 - 4.0 (1/16 - 3/16)	ОК (J)
1-08 	Basting stitch		o s	Basting	0.0 (0)	0.0 - 7.0 (0 - 1/4)	20 (3/4)	5 - 30 (3/16 - 1-3/ 16)	NO
1-09	Zigzag stitch		S	For overcasting, mending. Reverse stitch is sewn while pressing "Reverse/ Reinforcement Stitch" button.	3.5 (1/8)	0.0 - 7.0 (0 - 1/4)	1.4 (1/16)	0.0 - 4.0 (0 - 3/16)	ОК (Ј)
	Zigzag stitch		ŝ	For overcasting, mending. Reinforcement stitch is sewn while pressing "Reverse/ Reinforcement Stitch" button.	3.5 (1/8)	0.0 - 7.0 (0 - 1/4)	1.4 (1/16)	0.0 - 4.0 (0 - 3/16)	ОК (Ј)
1-11	Zigzag stitch (right)		ŝ	Start from right needle position, zigzag sew at left.	3.5 (1/8)	2.5 - 5.0 (3/32 - 3/16)	1.4 (1/16)	0.3 - 4.0 (1/64 - 3/16)	ОК (J)
1-12	Zigzag stitch (left)		ŝ	Start from left needle position, zigzag sew at right.	3.5 (1/8)	2.5 - 5.0 (3/32 - 3/16)	1.4 (1/16)	0.3 - 4.0 (1/64 - 3/16)	ОК (J)
1-13 <` <` <` <`	2 steps elastic zigzag		Ś	Overcasting (medium weight and stretch fabrics), tape and elastic	5.0 (3/16)	1.5 - 7.0 (1/16 - 1/4)	1.0 (1/16)	0.2 - 4.0 (1/64 - 1/16)	ОК (Ј)

Stitch	Stitch name	Presser foot	er foot	Applications		Stitch width [mm (inch)]		Stitch length [mm (inch)]		
Stiten	Stiten name	6		Applications	Auto.	Manual	Auto.	Manual	needle	
1-14	2 steps elastic zigzag		ŝ	Overcasting (medium weight and stretch fabrics), tape and elastic	5.0 (3/16)	1.5 - 7.0 (1/16 - 1/4)	1.0 (1/16)	0.2 - 4.0 (1/64 - 1/16)	ОК (Ј)	
1-15 <, <, <,	3 steps elastic zigzag		ŝ	Overcasting (medium, heavyweight and stretch fabrics), tape and elastic	5.0 (3/16)	1.5 - 7.0 (1/16 - 1/4)	1.0 (1/16)	0.2 - 4.0 (1/64 - 1/16)	ОК (Ј)	
	Overcasting stitch		G	Reinforcing of light and medium weight fabrics	3.5 (1/8)	2.5 - 5.0 (3/32 - 3/16)	2.0 (1/16)	1.0 - 4.0 (1/16 - 3/16)	NO	
1-17 (XXX)	Overcasting stitch		G	Reinforcing of heavyweight fabric	5.0 (3/16)	2.5 - 5.0 (3/32 - 3/16)	2.5 (3/32)	1.0 - 4.0 (1/16 - 3/16)	NO	
1-18	Overcasting stitch		G	Reinforcing of medium, heavyweight and easily friable fabrics or decorative stitching.	5.0 (3/16)	3.5 - 5.0 (1/8 - 3/16)	2.5 (3/32)	1.0 - 4.0 (1/16 - 3/16)	NO	
1-19	Overcasting stitch		ŝ	Reinforced seaming of stretch fabric	5.0 (3/16)	0.0 - 7.0 (0 - 9/32)	2.5 (3/32)	0.5 - 4.0 (1/32 - 3/16)	ОК (Ј)	
1-20	Overcasting stitch		ŝ	Reinforcing of medium stretch fabric and heavyweight fabric, decorative stitching	5.0 (3/16)	0.0 - 7.0 (0 - 9/32)	2.5 (3/32)	0.5 - 4.0 (1/32 - 3/16)	ОК (Ј)	
	Overcasting stitch		ŝ	Reinforcement of stretch fabric or decorative stitching	4.0 (3/16)	0.0 - 7.0 (0 - 1/4)	4.0 (3/16)	1.0 - 4.0 (1/16 - 3/16)	ОК (Ј)	
	Overcasting stitch		ŝ	Stretch knit seam	5.0 (3/16)	0.0 - 7.0 (0 - 1/4)	4.0 (3/16)	1.0 - 4.0 (1/16 - 3/16)	NO	
	Single diamond overcast		ŝ	Reinforcement and seaming stretch fabric	6.0 (15/64)	1.0 - 7.0 (1/16 - 1/4)	3.0 (1/8)	1.0 - 4.0 (1/16 - 3/16)	ОК (Ј)	
1-24	Single diamond overcast		ŝ	Reinforcement of stretch fabric	6.0 (15/64)	1.0 - 7.0 (1/16 - 1/4)	1.8 (1/16)	1.0 - 4.0 (1/16 - 3/16)	ОК (Ј)	
1-25 	With side cutter	2	S	Straight stitch while cutting fabrics	0.0 (0)	0.0 - 2.5 (0 - 3/32)	2.5 (3/32)	0.2 - 5.0 (1/64 - 3/16)	NO	
1-26 \$\$	With side cutter		S	Zigzag stitch while cutting fabrics	3.5 (1/8)	3.5 - 5.0 (1/8 - 3/16)	1.4 (1/16)	0.0 - 4.0 (0 - 3/16)	NO	
-27 >_S	With side cutter	2	S	Overcasting stitch while cutting fabrics	3.5 (1/8)	3.5 - 5.0 (1/8 - 3/16)	2.0 (1/16)	1.0 - 4.0 (1/16 - 3/16)	NO	
1-28 S	With side cutter	s		Overcasting stitch while cutting fabrics	5.0 (3/16)	3.5 - 5.0 (1/8 - 3/16)	2.5 (3/32)	1.0 - 4.0 (1/16 - 3/16)	NO	
1-29	With side cutter	T s		Overcasting stitch while cutting fabrics	5.0 (3/16)	3.5 - 5.0 (1/8 - 3/16)	2.5 (3/32)	1.0 - 4.0 (1/16 - 3/16)	NO	
1-30 	Piecing stitch (Right)		ŝ	Piecework/patchwork 6.5 mm (approx. 1/4 inch) left seam allowance	5.5 (7/32)	0.0 - 7.0 (0 - 1/4)	2.0 (1/16)	0.2 - 5.0 (1/64 - 3/16)	NO	
1-31 	Piecing stitch (Middle)		C	Piecework/patchwork	_	_	2.0 (1/16)	0.2 - 5.0 (1/64 - 3/16)	NO	

Stitch Stitch name		Presser foot	Applications	Stitch width [mm (inch)]		Stitch length [mm (inch)]		Twin	
Such	Stitch hame	6		Applications	Auto.	Manual	Auto.	Manual	needle
1-32 	Piecing stitch (Left)		Ś	Piecework/patchwork 6.5 mm (approx. 1/4 inch) left seam allowance	1.5 (1/16)	0.0 - 7.0 (0 - 1/4)	2.0 (1/16)	0.2 - 5.0 (1/64 - 3/16)	NO
1-33 Q	Hand-look quilting		ŝ	Quilting stitch made to look like hand quilting stitch	0.0 (0)	0.0 - 7.0 (0 - 1/4)	2.5 (3/32)	1.0 - 4.0 (1/16 - 3/16)	NO
1-34	Quilting appliqué zigzag stitch		ŝ	Zigzag stitch for quilting and sewing on appliqué quilt pieces	3.5 (1/8)	0.0 - 7.0 (0 - 1/4)	1.4 (1/16)	0.0 - 4.0 (0 - 3/16)	NO
1-35 Q	Quilting appliqué stitch		ŝ	Quilting stitch for invisible appliqué or attaching binding	1.5 (1/16)	0.5 - 5.0 (1/64 - 3/16)	1.8 (1/16)	1.0 - 4.0 (1/16 - 3/16)	NO
1-36 2%%{{\}}	Quilting stippling		ŝ	Background quilting	7.0 (1/4)	1.0 - 7.0 (1/16 - 1/4)	1.6 (1/16)	1.0 - 4.0 (1/16 - 3/16)	NO
2-01 / · · · · ·	Blind hem stitch		R	Hemming woven fabrics	0.0 (0)	+3.03.0 (+1/81/8)	2.0 (1/16)	1.0 - 3.5 (1/16 - 1/8)	NO
2-02	Blind hem stitch stretch		BU	Hemming stretch fabric	0.0 (0)	+3.03.0 (+1/81/8)	2.0 (1/16)	1.0 - 3.5 (1/16 - 1/8)	NO
2-03	Blanket stitch		ŝ	Appliqués, decorative blanket stitch	3.5 (1/8)	2.5 - 7.0 (3/32 - 1/4)	2.5 (3/32)	1.6 - 4.0 (1/16 - 3/16)	ОК (Ј)
2-04 	Shell tuck edge		ŝ	Shell tuck edge finish on fabrics	4.0 (3/16)	0.0 - 7.0 (0 - 1/4)	2.5 (3/32)	0.2 - 4.0 (1/64 - 1/16)	ОК (Ј)
3	Satin scallop stitch	N	ŝ	Decorating collar of blouse, edge of handkerchief	5.0 (3/16)	2.5 - 7.0 (3/32 - 1/4)	0.5 (1/32)	0.1 - 1.0 (1/64 - 1/16)	ОК (Ј)
2-06 ,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	Scallop stitch	N	ŝ	Decorating collar of blouse, edge of handkerchief	7.0 (1/4)	0.0 - 7.0 (0 - 1/4)	1.4 (1/16)	1.0 - 4.0 (1/16 - 3/16)	NO
2-07	Patchwork join stitch		ŝ	Patchwork stitches, decorative stitching	4.0 (1/16)	0.0 - 7.0 (0 - 1/4)	1.2 (1/16)	0.2 - 4.0 (1/64 - 1/16)	ОК (Ј)
2-08	Patchwork double overlock stitch		ŝ	Patchwork stitches, decorative stitching	5.0 (3/16)	2.5 - 7.0 (3/32 - 1/4)	2.5 (3/32)	1.0 - 4.0 (1/16 - 3/16)	ОК (Ј)
2-09 <i>y</i> -^-v-^-	Couching stitch		ŝ	Decorative stitching, attaching cord and couching	5.0 (3/16)	0.0 - 7.0 (0 - 1/4)	1.2 (1/16)	0.2 - 4.0 (1/64 - 1/16)	OK (J)
2-10	Smocking stitch		ŝ	Smocking, decorative stitching	5.0 (3/16)	0.0 - 7.0 (0 - 1/4)	1.6 (1/16)	1.0 - 4.0 (1/16 - 3/16)	ОК (J)
2-11	Feather stitch		ŝ	Fagoting, decorative stitching	5.0 (3/16)	0.0 - 7.0 (0 - 1/4)	2.5 (3/32)	1.0 - 4.0 (1/16 - 3/16)	ОК (Ј)
2-12 X X X X X	Fagoting cross stitch		ŝ	Fagoting, bridging and decorative stitching	5.0 (3/16)	2.5 - 7.0 (3/32 - 1/4)	2.5 (3/32)	1.0 - 4.0 (1/16 - 3/16)	ОК (Ј)
2-13	Tape attaching		ŝ	Attaching tape to seam in stretch fabric	4.0 (3/16)	0.0 - 7.0 (0 - 1/4)	1.0 (1/16)	0.2 - 4.0 (1/61 - 3/16)	ОК (Ј)

Stitch	Stitch name	Presser foot		- Applications		h width ı (inch)]	Stite [mn	Twin	
Suich		6		- Applications -	Auto.	Manual	Auto.	Manual	needle
2-14	Ladder stitch		Ś	Decorative stitching	4.0 (3/16)	0.0 - 7.0 (0 - 1/4)	3.0 (1/8)	2.0 - 4.0 (1/16 - 3/16)	NO
2-15	Rick-rack stitch		ŝ	Decorative top stitching	4.0 (3/16)	0.0 - 7.0 (0 - 1/4)	2.5 (3/32)	1.0 - 4.0 (1/16 - 3/16)	ОК (Ј)
2-16 444 444	Decorative stitch		ŝ	Decorative stitching	1.0 (1/16)	1.0 - 3.0 (1/16 - 1/8)	2.5 (3/32)	1.0 - 4.0 (1/16 - 3/16)	ОК (Ј)
2-17	Decorative stitch		ŝ	Decorative stitching	5.5 (3/16)	0.0 - 7.0 (0 - 1/4)	1.6 (1/16)	1.0 - 4.0 (1/16 - 3/16)	ОК (Ј)
2-18	Serpentine stitch	N	ŝ	Decorative stitching and attaching elastic	5.0 (3/16)	1.5 - 7.0 (1/16 - 1/4)	1.0 (1/16)	0.2 - 4.0 (1/64 - 3/16)	ОК (Ј)
2-19 MMM	Decorative stitch	N	ŝ	Decorative stitching and appliqué	6.0 (15/64)	1.0 - 7.0 (1/16 - 1/4)	1.0 (1/16)	0.2 - 4.0 (1/64 - 3/16)	ОК (Ј)
2-20	Decorative stippling stitch	N	ŝ	Decorative stitching	7.0 (1/4)	1.0 - 7.0 (1/16 - 1/4)	1.6 (1/16)	1.0 - 4.0 (1/16 - 3/16)	NO
3-01	Hemstitching	N	ŝ	Decorative hems, triple straight at left	1.0 (1/16)	1.0 - 7.0 (1/16 - 1/4)	2.5 (3/32)	1.5 - 4.0 (1/16 - 3/16)	ОК (J)
3-02	Hemstitching	N	Ś	Decorative hems, triple straight at center	3.5 (1/8)	1.0 - 7.0 (1/16 - 1/4)	2.5 (3/32)	1.5 - 4.0 (1/16 - 3/16)	ОК (J)
3-03	Hemstitching zigzag	N	ŝ	Decorative hems, top stitching	6.0 (15/64)	1.5 - 7.0 (1/16 - 1/4)	3.0 (1/8)	1.0 - 4.0 (1/16 - 3/16)	ОК (J)
3-04 E	Hemstitching	N	ŝ	Decorative hems, lace attaching pin stitch	3.5 (1/8)	1.5 - 7.0 (1/16 - 1/4)	2.5 (3/32)	1.6 - 4.0 (1/16 - 3/16)	NO
3-05	Hemstitching	N	ŝ	Decorative hems	3.0 (1/8)	1.5 - 7.0 (1/16 - 1/4)	3.5 (1/8)	1.6 - 4.0 (1/16 - 3/16)	NO
^{3−06} ₩ ₩	Hemstitching	N	Ś	Decorative hems daisy stitch	6.0 (15/64)	1.5 - 7.0 (1/16 - 1/4)	3.0 (1/8)	1.5 - 4.0 (1/16 - 3/16)	NO
³⁻⁰⁷ ♦ ♦	Hemstitching	N	Ś	Heirloom, decorative hems	5.0 (3/16)	1.5 - 7.0 (1/16 - 1/4)	3.5 (1/8)	1.6 - 4.0 (1/16 - 3/16)	NO
3-08	Hemstitching	N	ŝ	Heirloom, decorative hems	5.0 (3/16)	1.5 - 7.0 (1/16 - 1/4)	3.5 (1/8)	1.5 - 4.0 (1/16 - 3/16)	NO
3-09	Hemstitching	N	Ś	Heirloom, decorative hems	5.0 (3/16)	1.5 - 7.0 (1/16 - 1/4)	3.5 (1/8)	1.6 - 4.0 (1/16 - 3/16)	ОК (J)
3-10	Hemstitching	N	ŝ	Heirloom, decorative hems	5.0 (3/16)	1.5 - 7.0 (1/16 - 1/4)	4.0 (3/16)	1.5 - 4.0 (1/16 - 3/16)	ОК (Ј)
^{3–11}	Hemstitching	N	ŝ	Heirloom, decorative hems	4.0 (3/16)	1.5 - 7.0 (1/16 - 1/4)	2.5 (3/32)	1.5 - 4.0 (1/16 - 3/16)	ОК (Ј)

Stitch	Stitch name	Presser foot		Applications		h width (inch)]		h length n (inch)]	Twin
Such	Suten name	6		Αρριτατιοπε	Auto.	Manual	Auto.	Manual	needle
3-12	Honeycomb stitch	N	ŝ	Heirloom, decorative hems	5.0 (3/64)	1.5 - 7.0 (1/16 - 1/4)	2.5 (3/32)	1.5 - 4.0 (1/16 - 3/16)	ОК (Ј)
3-13	Honeycomb stitch	N	ŝ	Heirloom, decorative hems	6.0 (15/64)	1.5 - 7.0 (1/16 - 1/4)	3.5 (1/8)	1.5 - 4.0 (1/16 - 3/16)	ОК (Ј)
3-14 × ×	Hemstitching	N	Ś	Heirloom, decorative hems	6.0 (15/64)	1.5 - 7.0 (1/16 - 1/4)	1.6 (1/16)	1.0 - 4.0 (1/16 - 3/16)	ОК (J)
3-15	Hemstitching	N	ŝ	Heirloom, decorative hems	6.0 (15/64)	1.5 - 7.0 (1/16 - 1/4)	3.0 (1/8)	1.5 - 4.0 (1/16 - 3/16)	NO
3-16 × ×	Hemstitching	N	ŝ	Heirloom, decorative hems	6.0 (15/64)	1.5 - 7.0 (1/16 - 1/4)	4.0 (3/16)	1.5 - 4.0 (1/16 - 3/16)	ОК (Ј)
3-17 + +	Hemstitching	N	ŝ	Heirloom, decorative hems	4.0 (3/16)	1.5 - 7.0 (1/16 - 1/4)	2.5 (3/32)	1.6 - 4.0 (1/16 - 3/16)	NO
3-18 1+ 1+ 1+ 1+ 1+	Hemstitching	N	ŝ	Heirloom, decorative hems	5.0 (3/16)	1.5 - 7.0 (1/16 - 1/4)	2.0 (1/16)	1.5 - 4.0 (1/16 - 3/16)	ОК (J)
^{3−19}	Hemstitching	N	ŝ	Decorative hems and bridging stitch	6.0 (15/64)	1.5 - 7.0 (1/16 - 1/4)	2.0 (1/16)	1.5 - 4.0 (1/16 - 3/16)	ОК (Ј)
3-20	Hemstitching	N	ŝ	Decorative hems. Fagoting, attaching ribbon	5.0 (3/16)	1.5 - 7.0 (1/16 - 1/4)	3.0 (1/8)	1.5 - 4.0 (1/16 - 3/16)	ОК (J)
3-21 	Hemstitching	N	ŝ	Decorative hems, smocking	6.0 (15/64)	1.5 - 7.0 (1/16 - 1/4)	1.6 (1/16)	1.0 - 4.0 (1/16 - 3/16)	NO
3-22 77 47 47	Hemstitching	N	ŝ	Decorative hems, smocking	5.0 (3/16)	1.5 - 7.0 (1/16 - 1/4)	1.6 (1/16)	1.0 - 4.0 (1/16 - 3/16)	NO
3-23 4 4	Hemstitching	N	ŝ	Decorative hems, smocking	5.0 (3/16)	1.5 - 7.0 (1/16 - 1/4)	1.6 (1/16)	1.0 - 4.0 (1/16 - 3/16)	NO
3-24	Hemstitching	N	ŝ	Decorative hems	5.0 (3/16)	1.5 - 7.0 (1/16 - 1/4)	1.6 (1/16)	1.0 - 4.0 (1/16 - 3/16)	NO
3-25	Ladder stitch	N	ŝ	Decorative hems. Fagoting, attaching ribbon	7.0 (1/4)	5.0 - 7.0 (3/16 - 1/4)	1.6 (1/16)	1.0 - 2.5 (1/16 - 3/32)	NO
4-01	Narrow rounded buttonhole	- All	A	Buttonhole on light to medium weight fabrics	5.0 (3/16)	3.0 - 5.0 (1/8 - 3/16)	0.4 (1/64)	0.2 - 1.0 (1/64 - 1/16)	NO
4-02	Wide round ended buttonhole	A		Buttonholes with extra space for larger buttons	5.5 (7/32)	3.5 - 5.5 (1/8 - 7/32)	0.4 (1/64)	0.2 - 1.0 (1/64 - 1/16)	NO
4-03	Tapered round ended buttonhole	La	A	Reinforced waist tapered buttonholes	5.0 (3/16)	3.0 - 5.0 (1/8 - 3/16)	0.4 (1/64)	0.2 - 1.0 (1/64 - 1/16)	NO
4-04	Round ended buttonhole	- Salver	A	Buttonholes with vertical bar tack in heavyweight fabrics	5.0 (3/16)	3.0 - 5.0 (1/8 - 3/16)	0.4 (1/64)	0.2 - 1.0 (1/64 - 1/16)	NO

Stitch	Stitch name	Presser foot		ot Applications		h width (inch)]	Stito [mn	Twin	
Stiten		6			Auto.	Manual	Auto.	Manual	needle
4-05	Round ended buttonhole	Ē	4	Buttonholes with bar tack	5.0 (3/16)	3.0 - 5.0 (1/8 - 3/16)	0.4 (1/64)	0.2 - 1.0 (1/64 - 1/16)	NO
4-06	Round double ended buttonhole			Buttonholes for fine, medium to heavyweight fabrics	5.0 (3/16)	3.0 - 5.0 (1/8 - 3/16)	0.4 (1/64)	0.2 - 1.0 (1/64 - 1/16)	NO
4-07	Narrow squared buttonhole			Buttonholes for light to medium weight fabrics	5.0 (3/16)	3.0 - 5.0 (1/8 - 3/16)	0.4 (1/64)	0.2 - 1.0 (1/64 - 1/16)	NO
4-08	Wide squared buttonhole	E		Buttonholes with extra space for larger decorative buttons	5.5 (7/32)	3.5 - 5.5 (1/8 - 7/32)	0.4 (1/64)	0.2 - 1.0 (1/64 - 1/16)	NO
4-09	Squared buttonhole			Heavy-duty buttonholes with vertical bar tacks	5.0 (7/32)	3.0 - 5.0 (1/8 - 3/16)	0.4 (1/64)	0.2 - 1.0 (1/64 - 1/16)	NO
4-10	Stretch buttonhole			Buttonholes for stretch or woven fabrics	6.0 (15/64)	3.0 - 6.0 (1/8 - 15/64)	1.0 (1/16)	0.5 - 2.0 (1/32 - 1/16)	NO
4-11	Heirloom buttonhole			Buttonholes for heirloom and stretch fabrics	6.0 (15/64)	3.0 - 6.0 (1/8 - 15/64)	1.5 (1/16)	1.0 - 3.0 (1/1 - 1/8)	NO
4-12	Bound buttonhole			The first step in making bound buttonholes	5.0 (3/16)	0.0 - 6.0 (0 - 15/64)	2.0 (1/16)	0.2 - 4.0 (1/64 - 3/16)	NO
4-13 []	Keyhole buttonhole	A		Buttonholes in heavyweight or thick fabrics for larger flat buttons	7.0 (1/4)	3.0 - 7.0 (1/8 - 1/4)	0.5 (1/32)	0.3 - 1.0 (1/64 - 1/16)	NO
4-14 ()	Tapered keyhole buttonhole			Buttonholes in medium to heavy weight fabrics for larger flat buttons	7.0 (1/4)	3.0 - 7.0 (1/8 - 1/4)	0.5 (1/32)	0.3 - 1.0 (1/64 - 1/16)	NO
4-15 []	Keyhole buttonhole			Buttonholes with vertical bar tack for reinforcement in heavyweight or thick fabrics	7.0 (1/4)	3.0 - 7.0 (1/8 - 1/4)	0.5 (1/32)	0.3 - 1.0 (1/64 - 1/16)	NO
4-16	4 steps buttonhole 1	N	ŝ	Left side of 4 step buttonhole	5.0 (7/32)	1.5 - 7.0 (1/16 - 1/4)	0.4 (1/64)	0.2 - 1.0 (1/64 - 1/16)	NO
4-17	4 steps buttonhole 2	N	ŝ	Bar tack of 4 step buttonhole	5.0 (7/32)	1.5 - 7.0 (1/16 - 1/4)	0.4 (1/64)	0.2 - 1.0 (1/64 - 1/16)	NO
4-18 [4 steps buttonhole 3	N	ŝ	Right side of 4 step buttonhole	5.0 (7/32)	1.5 - 7.0 (1/16 - 1/4)	0.4 (1/64)	0.2 - 1.0 (1/64 - 1/16)	NO
4-19	4 steps buttonhole 4	N	ŝ	Bar tack of 4 step buttonhole	5.0 (7/32)	1.5 - 7.0 (1/16 - 1/4)	0.4 (1/64)	0.2 - 1.0 (1/64 - 1/16)	NO
4-20 innn iiiiiii	Darning			Darning of medium weight fabric	7.0 (1/4)	2.5 - 7.0 (3/32 - 1/4)	2.0 (1/16)	0.4 - 2.5 (1/64 - 1/16)	NO
4-21	Darning			Darning of heavyweight fabric	7.0 (1/4)	2.5 - 7.0 (3/32 - 1/4)	2.0 (1/16)	0.4 - 2.5 (1/64 - 1/16)	NO
4-22	Bar tack			Reinforcement at opening of pocket, etc.	2.0 (1/16)	1.0 - 3.0 (1/16 - 1/8)	0.4 (1/64)	0.3 - 1.0 (1/64 - 1/16)	NO

Stitch	Stitch name	Press	er foot	Applications		ch width n (inch)]		h length n (inch)]	Twin
otton		6	6	rippiloutione	Auto.	Manual	Auto.	Manual	needle
⁴⁻²³	Button sewing			Attaching buttons	3.5 (1/8)	2.5 - 4.5 (3/32 - 3/16)	_	_	NO
4-24 •	Eyelet	N	ŝ	For making eyelets, holes on belts, etc.	7.0 (1/4)	7.0 6.0 5.0 (1/4 15/64 3/ 16)	7.0 (1/4)	7.0 6.0 5.0 (1/4 15/64 3/16)	NO
4-25 5/15	Star eyelet	N	ŝ	For making star-shaped eyelets on holes.	_	_	_	_	NO
5-01	Diagonally left up (Straight)	N	ŝ	For attaching appliqué on tubular pieces of fabric and mitering corners	_	-	_	-	NO
5-02 ┆↑	Reverse (Straight)	N	ŝ	For attaching appliqué on tubular pieces of fabric and mitering corners	_	-	_	-	NO
5-03	Diagonally right up (Straight)	N	ŝ	For attaching appliqué on tubular pieces of fabric and mitering corners	_	-	_	-	NO
5-04 	Sideways to left (Straight)	N	ŝ	For attaching appliqué on tubular pieces of fabric	_	_	_	-	NO
5-05 →	Sideways to right (Straight)	N	ŝ	For attaching appliqué on tubular pieces of fabric	_	-	_	-	NO
5-06	Diagonally left down (Straight)	N	ŝ	For attaching appliqué on tubular pieces of fabric and mitering corners	_	-	_	-	NO
5-07	Forward (Straight)	N	ŝ	For attaching appliqué on tubular pieces of fabric and mitering corners	_	-	_	-	NO
5-08	Diagonally right down (Straight)	N	Ś	For attaching appliqué on tubular pieces of fabric and mitering corners	_	_	_	_	NO
5-09 ~~~ ~	Sideways to left (Zigzag)	N	Ś	For attaching appliqué on tubular pieces of fabric	_	-	_	-	NO
5-10 ∧∽∽ →	Sideways to right (Zigzag)	N	Ś	For attaching appliqué on tubular pieces of fabric	_	-	_	-	NO
5-11 {} ↓	Forward (Zigzag)	N	Ś	For attaching appliqué on tubular pieces of fabric and mitering corners	_	_	_	_	NO
5-12	Reverse (Zigzag)	N	ŝ	For attaching appliqué on tubular pieces of fabric and mitering corners	_	_	_	_	NO
Q-01	Piecing stitch (Middle)		C	Piecework/patchwork	_	_	2.0 (1/16)	0.2 - 5.0 (1/64 - 3/16)	NO
Q-02	Piecing stitch (Right)		ŝ	Piecework/patchwork 6.5 mm (approx. 1/4 inch) right seam allowance	5.50 (7/32)	0.00 - 7.00 (0 - 1/4)	2.0 (1/16)	0.2 - 5.0 (1/64 - 3/16)	NO
Q-03 	Piecing stitch (Left)		ŝ	Piecework/patchwork 6.5 mm (approx. 1/4 inch) left seam allowance	1.50 (1/16)	0.00 - 7.00 (0 - 1/4)	2.0 (1/16)	0.2 - 5.0 (1/64 - 3/16)	NO

Stitch	Stitch name	Press	er foot	Applications		ch width n (inch)]		h length n (inch)]	Twin
onton	otten name	\bigcirc		Applications	Auto.	Manual	Auto.	Manual	needle
Q-04 	Hand-look quilting		ŝ	Quilting stitch made to look like hand quilting stitch	3.50	0.00 - 7.00 (0 - 1/4)	2.5 (3/32)	1.0 - 4.0 (1/16 - 3/16)	NO
Q-05 	Basting stitch		ŝ	Basting	3.50	0.00 - 7.00 (0 - 1/4)	20 (3/4)	5 - 30 (3/16 - 1-3/ 16)	NO
Q-06 4 4 4 4 4 4	Stem stitch		ŝ	Reinforced stitching, sewing and decorative applications	1.00 (1/16)	1.00 - 3.00 (1/16 - 1/8)	2.5 (3/32)	1.0 - 4.0 (1/16 - 3/16)	NO
Q-07 ↓ Q	Quilting appliqué zigzag stitch		ŝ	Zigzag stitch for quilting and sewing on appliqué quilt pieces	3.50 (1/8)	0.00 - 7.00 (0 - 1/4)	1.6	0.0 - 4.0 (0 - 3/16)	NO
Q-08	Zigzag stitch (Right)		ŝ	Start from right needle position, zigzag sew at left	3.50 (1/8)	2.50 - 5.00 (3/32 - 3/16)	1.6	0.3 - 4.0 (1/64 - 3/16)	NO
Q-09	Zigzag stitch (Left)		ŝ	Start from left needle position, zigzag sew at right	3.50 (1/8)	2.50 - 5.00 (3/32 - 3/16)	1.6	0.3 - 4.0 (1/64 - 3/16)	NO
Q-10 < ^ < ^ < ^ < ^ < ^ < ^	2 steps elastic zigzag		ŝ	Overcasting (medium weight and stretch fabrics), tape and elastic	5.00 (3/16)	1.50 - 7.00 (1/16 - 1/4)	1.0 (1/16)	0.2 - 4.0 (1/64 - 1/16)	NO
Q-11 <., <., <., <., <., <., <., <.,	3 steps elastic zigzag		ŝ	Overcasting (medium, heavyweight and stretch fabrics), tape and elastic	5.00 (3/16)	1.50 - 7.00 (1/16 - 1/4)	1.0 (1/16)	0.2 - 4.0 (1/64 - 1/16)	NO
Q-12 	Quilting appliqué stitch		ŝ	Quilting stitch for invisible appliqué or attaching binding	2.00	0.50 - 5.00 (1/64 - 3/16)	2.0	1.0 - 4.0 (1/16 - 3/16)	NO
Q-13	Shell tuck edge		ŝ	Shell tuck edge finish on fabrics	4.00 (3/16)	0.00 - 7.00 (0 - 1/4)	2.5 (3/32)	0.2 - 4.0 (1/64 - 1/16)	NO
Q-14	Blanket stitch		ŝ	Appliqués, decorative blanket stitch	3.50 (1/8)	2.50 - 7.00 (3/32 - 1/4)	2.5 (3/32)	1.6 - 4.0 (1/16 - 3/16)	NO
Q-15 25 20 Q	Quilting stippling		ŝ	Background quilting	7.00 (1/4)	1.00 - 7.00 (1/16 - 1/4)	1.6 (1/16)	1.0 - 4.0 (1/16 - 3/16)	NO
Q-16	Overcasting stitch		ŝ	Stretch knit seam	5.00 (3/16)	0.00 - 7.00 (0 - 1/4)	4.0 (3/16)	1.0 - 4.0 (1/16 - 3/16)	NO
Q-17 V 7 V 7 V 7 V 7	Tape attaching		ŝ	Attaching tape to seam in stretch fabric	5.50	0.00 - 7.00 (0 - 1/4)	1.4	0.2 - 4.0 (1/61 - 3/16)	NO
Q-18	Serpentine stitch		ŝ	Decorative stitching and attaching elastic	5.00 (3/16)	1.50 - 7.00 (1/16 - 1/4)	2.0	0.2 - 4.0 (1/64 - 3/16)	NO
Q-19	Feather stitch		ŝ	Fagoting, decorative stitching	5.00 (3/16)	0.00 - 7.00 (0 - 1/4)	2.5 (3/32)	1.0 - 4.0 (1/16 - 3/16)	NO
Q-20	Fagoting cross stitch		ŝ	Fagoting, bridging and decorative stitching	5.00 (3/16)	2.50 - 7.00 (3/32 - 1/4)	2.5 (3/32)	1.0 - 4.0 (1/16 - 3/16)	NO
Q-21 y-^-V-V-^-	Couching stitch		ŝ	Decorative stitching, attaching cord and couching	5.00 (3/16)	0.00 - 7.00 (0 - 1/4)	1.2 (1/16)	0.2 - 4.0 (1/64 - 1/16)	NO

Stitch Stitch name		Presser foot		Applications	Stitch width [mm (inch)]		Stitch length [mm (inch)]		Twin
Stiten	Such hame	6		Αμριιτατιοτίς	Auto.	Manual	Auto.	Manual	needle
Q-22	Patchwork double overlock stitch		ŝ	Patchwork stitches, decorative stitching	5.00 (3/16)	2.50 - 7.00 (3/32 - 1/4)	2.5 (3/32)	1.0 - 4.0 (1/16 - 3/16)	NO
Q-23	Smocking stitch		ŝ	Smocking, decorative stitching	5.00 (3/16)	0.00 - 7.00 (0 - 1/4)	1.6 (1/16)	1.0 - 4.0 (1/16 - 3/16)	NO
Q-24	Rick-rack stitch		ŝ	Decorative top stitching	4.00 (3/16)	0.00 - 7.00 (0 - 1/4)	2.5 (3/32)	1.0 - 4.0 (1/16 - 3/16)	NO
Q-25 MMM	Decorative stitch		ŝ	Decorative stitching and appliqué	6.00 (15/64)	1.00 - 7.00 (1/16 - 1/4)	1.0 (1/16)	0.2 - 4.0 (1/64 - 3/16)	NO
Q-26 2000	Decorative stitch		ŝ	Decorative stitching	5.50 (3/16)	0.00 - 7.00 (0 - 1/4)	1.6 (1/16)	1.0 - 4.0 (1/16 - 3/16)	NO
Q-27 11 11 11 11	Hemstitching		ŝ	Heirloom, decorative hems	5.00 (3/16)	1.50 - 7.00 (1/16 - 1/4)	2.0 (1/16)	1.5 - 4.0 (1/16 - 3/16)	NO
Q-28	Hemstitching		ŝ	Decorative hems and bridging stitch	6.00 (15/64)	1.50 - 7.00 (1/16 - 1/4)	2.0 (1/16)	1.5 - 4.0 (1/16 - 3/16)	NO
Q-29	Single diamond overcast		ŝ	Reinforcement and seaming stretch fabric	6.00 (15/64)	1.00 - 7.00 (1/16 - 1/4)	3.0 (1/8)	1.0 - 4.0 (1/16 - 3/16)	NO
Q-30	Overcasting stitch		ŝ	Reinforcement of stretch fabric or decorative stitching	4.00 (3/16)	0.00 - 7.00 (0 - 1/4)	4.0 (3/16)	1.0 - 4.0 (1/16 - 3/16)	NO

INDEX

Α

Accessories	
included accessories	
options	8
Accessory case	
Accessory compartment	
Adjustments	
screen	
Air vent	
Alarm sounds	
Aligning the position	
Alphabet characters	
character/decorative stitches	
embroidery	
embroidery edit	
Alternate bobbin case	
Appliqué	
embroidery patterns	
quilting	
using a zigzag stitch	
using an embroidery frame pattern	
Array key	
Arrow keys	232, 267, 290
Automatic fabric sensor system	
Automatic reinforcement stitch key	
Automatic thread cutting key	
Automatic Threading button	
~	

B

Back to beginning key159
Ball point needle 75/107 58, 228
Bar tacks
Basting
Blind hem stitches
Bobbin
prewound bobbin
pulling up the bobbin thread
runs out of thread
setting
winding
Bobbin case
alternate bobbin case (no color on the screw)
cleaning
Bobbin center pin
Bobbin cover
Bobbin holder (switch)
Bobbin winder1
Border key
Built-in cameravi, 75, 138, 205, 300
Button sewing131
4 hole buttons132
shank132
Buttonhole lever2, 123, 128
Buttonholes
four-step
odd-shaped/buttons that do not fit the button holder plate 124
one-step121

C

Character spacing key
Character/Decorative Stitches
adjustments
combining162
editing
key functions155
retrieving 176, 177
saving

selecting	146
sewing	
stitch selection screens	
Cleaning	
LCD screen	
machine casing	
race	
Combining Patterns	
character/decorative stitches	
embroidery edit	
Cord guide bobbin cover	
Crazy quilt	
Custom Thread Table	
Cut/Tension key	
. ,	

D

Darning1	27
Dart seam	88
Density key2	37

E

Echo quilting		108
Edge sewing		
edge sewing using the built-in camera	vi,	138
Editing		
character/decorative stitches		155
embroidery		232
embroidery edit		265
Elastic zigzag stitches		
Elongation key		
Embroidery		
adjusting the speed		229
automatic thread cutting function (END COLOR TRIM) .		227
edges or corners		
key functions		
restarting from the beginning		223
resuming embroidery after turning off the power		223
ribbons or tape		
selecting patterns		186
small fabrics		
thread color display		
thread trimming function (JUMP STITCH TRIM)		228
Embroidery card		194
Embroidery card reader		
Embroidery edit		ТЭт
changing the thread color		276
combined patterns	280	200
custom thread table	209,	292
explanation of functions		
key functions		
repeated patterns		
Embroidery foot "W"		
Embroidery frame display		
Embroidery frames	•••••	230
attaching		202
inserting fabric		
removing		
types		
using the embroidery sheet		
Embroidery needle plate cover	•••••	211
Embroidery patterns		200
aligning the position		
checking the position		
combining		
duplicating		
editing		
linked characters		
pattern selection screens		187

.

patterns which use appliqué	
retrieving	
revising	
saving	
selecting	
sewing	
using a frame pattern to make an appliqué	
Embroidery positioning sticker	
Embroidery sheet	
Embroidery unit	
carriage	
carrying case	
Error messages	
Eyelet	
,	

F

Fabrics
fabric/thread/needle combinations58
sewing heavyweight fabrics63
sewing lightweight fabrics64
sewing stretch fabrics
Fagoting
Feed dogs
Flat bed attachment1, 184
Flat fell Seam
Foot controller
Forward/Back key
Free motion quilting
free motion echo quilting foot "E"108
free motion open toe quilting foot "O"
free motion quilting foot "C"105
Free motion sewing mode105

G

Gathering	
Gautering	

Н

	1
Handwheel	
Heirloom	119
Hemstitching	
daisy stitch	119
drawn work	120
Home page screen	14

L

K

Key functions	
character/decorative stitches	
embroidery	
embroidery edit	
utility stitches	
Knee lifter	

L

LCD screen	
cleaning	
light	
locking	74
Lower threading	
pulling up the bobbin thread	
setting the bobbin	
winding the bobbin	
0	

Μ

Machine operation mode key	
----------------------------	--

Main power switch1, 12
Mirror image key
Multi color key
Multi-directional sewing

N

Needle	
changing the needle	56
changing the needle position	85
checking the needle location	vi, 75
fabric/thread/needle combinations	58
mode	14
twin needle	49
Needle bar thread guides	
Needle clamp screw	2
Needle mode selection key	
Needle plate	2
Needle position	
Needle Position button	

0

Operation buttons	1	, 3
Overcasting	91, 93,	94

Р

Patchwork	
Piecing	
Pintuck	
Pivoting	72
Power cord	
Power cord receptacle	1
Presser foot	
attaching	54
pressure	
removing	
types	
Presser foot code	
Presser foot holder	
Presser foot holder screw	2
Presser foot lever	
Presser Foot Lifter button	
Presser foot/Needle exchange key5	
Pre-tension disk	
Print and stitch	vii, 215, 304

Q

Quilting	99
free motion	
with satin stitches	104

R

Race	
Repeated patterns	
Retrieving	
character/decorative stitch patterns	176
computer	
embroidery patterns	
machine's memory	
stitch settings	
USB media	
utility stitches	
Reverse/Reinforcement Stitch button	
Reverse/Reinforcement stitches	
Rotate key	

S

Satin stitches	
Saving	
character/decorative stitches	

computer	
embroidery patterns	
machine's memory	
stitch settings	
USB media	
utility stitches	
Scallop stitches	
Screen saver	
Settings	
automatic reinforcement stitching	69
automatic thread cutting	
display language	
embroidery settings	24
general settings	
machine setting mode key	22, 229, 277
sewing settings	
stitch length	
stitch width	
thread tension	
thread trimming	
Sewing key	
Sewing machine help key	
Sewing speed controller (speed control slide)	
Sewing type selection key	
Shelltuck stitches	
Side cutter	
Single/Repeat sewing key	
Size key	
Size selection key	
Smocking stitches	
Soft cover case	
Speaker	23
Specifications	
Spool cap	
Spool net	
spool pin	
Spool stand	
stabilizer	
Start/Stop button	
Starting point key	
Step stitch patterns	
Stitch setting chart	
Straight stitch foot	
Straight stitch needle plate	
Straight stitches	
Supplemental spool pin	
	, ,

т

Tape attaching	
Tape or elastic attaching	
Thread	
fabric/thread/needle combinations	
thread tension	
Thread color display	
Thread cutter	
Thread Cutter button	
Thread density key	
Thread guide	
Thread guide plate	
Thread marks	
Thread palette key	
Top cover	
Top stitching	
Touch pen	
holder	
Trial key	
Troubleshooting	
Twin needle	

U

Uninterrupted embroidering241
Upgrading
Upper threading

twin needle mode	. 49
using the "Automatic Threading" button	. 46
using the spool net	. 53
USB cable19, 175, 218, 244, 248, 252, 307,	332
USB media	
recalling177,	250
saving	247
usable	242
USB mouse	, 25
USB port connector	
for computer1, 175,	248
for media1, 173,	247
Utility stitches	
key functions	. 16
pattern explanation key	. 35
retrieving	
saving	
selecting	. 78
sewing type selection key	
stitch selection screens	
stitch setting chart	335

V _____

Vertical stitch alignment foot "V"	
------------------------------------	--

W

Walking foot		55
--------------	--	----

Ζ

Ζ
Zigzag stitches
Zipper insertion
centered
side



From Inspiration to Reality



FOR THE LOVE OF SEWING

English 882-W03 XE5021-101③ Printed in Taiwan