baby lock®

Quilter's Choice™ Professional

Model BLQP

Instruction and Reference Guide

Downloaded from www.Manualslib.com manuals search engine

“IMPORTANT SAFETY INSTRUCTIONS”

“Read all instructions before using.”
When using a sewing machine, basic safety precautions should always be taken,
including the following:

DANGER – To reduce the risk of electric shock:

- The sewing machine should never be left unattended while plugged in. Always unplug the sewing machine from the electrical outlet immediately after using and before cleaning.
- Always unplug before changing the light bulb. Replace bulb with same type rated 120V 15 watts for 120V model or rated 240V 15 watts for 220-240V model.

WARNING – To reduce the risk of burns, fire, electric shock, or injury:

- Do not allow this sewing machine to be used as a toy. Close attention is necessary when the sewing machine is used by or near children.
- Use this sewing machine only for its intended use as described in this manual. Use only accessories recommended by the manufacturer as contained in this manual.
- Never operate this sewing machine if it has a damaged cord or plug, if it is not working properly, if it has been dropped or damaged, or dropped into water. Return the sewing machine to the nearest authorized dealer or service center for examination, repair, electrical or mechanical adjustment.
- Never operate the sewing machine with any air openings blocked. Keep ventilation openings of the sewing machine and foot control free from the accumulation of lint, dust, and loose cloth.
- Never drop or insert any object into any opening.
- Do not use outdoors.
- Do not operate where aerosol (spray) products are being used or where oxygen is being administered.
- To disconnect, turn the main switch to the symbol “O” position which represents off, then remove plug from outlet.
- Do not unplug by pulling on cord. To unplug, grasp the plug, not the cord.
- Keep fingers away from all moving parts. Special care is required around the sewing machine needle.
- Always use the proper needle plate. The wrong plate can cause the needle to break.
- Do not use bent needles.
- Do not pull or push fabric while stitching. It may deflect the needle causing it to break.
- Turn off power to the machine by flipping the ON/OFF switch to the symbol “O” before making any adjustments in the needle area, such as threading the needle, changing the needle, threading the bobbin or changing the presser foot etc.
- Always unplug the sewing machine from the electrical outlet when removing covers, lubricating, or when making any other user servicing adjustments mentioned in the instruction manual.
- This sewing machine is not intended for use by young children or infirm persons without supervision.
- Young children should be supervised to ensure that they do not play with this sewing machine.

CAUTION For U.S.A. only– This appliance has a polarized plug (one blade wider than the other) to reduce the risk of electric shock, this plug is intended to fit in a polarized outlet only one way.
If the plug does not fit fully in the outlet, reverse the plug.
If it still does not fit, contact a qualified electrician to install the proper outlet.
Do not modify the plug in any way.

“SAVE THESE INSTRUCTIONS”

“This sewing machine is intended for household use.”

Downloaded from www.Manualslib.com manuals search engine

FOR USERS IN THE UK, EIRE, MALTA AND CYPRUS ONLY

If your sewing machine is fitted with a three-pin non-rewireable BS plug then please read the following.

IMPORTANT

If the available socket outlet is not suitable for the plug supplied with this equipment, it should be cut off and an appropriate three-pin plug fitted. With alternative plugs an approved fuse must be fitted in the plug.

NOTE

The plug served from the main lead must be destroyed as a plug with bared flexible cords is hazardous if engaged in a live socket outlet. In the event of replacing the plug fuse, use a fuse approved by ASTA to BS 1362, i.e. carrying the  mark, rating as marked on plug.

Always replace the fuse cover, never use plugs with the fuse cover omitted.

WARNING

DO NOT CONNECT EITHER WIRE TO THE EARTH TERMINAL WHICH IS MARKED WITH THE LETTER 'E', BY THE EARTH SYMBOL ⏚ OR COLOURED GREEN OR GREEN AND YELLOW.

The wires in this main lead are coloured in accordance with the following code:

Blue	Neutral
Brown	Live

As the colours of the wiring in the main lead of this appliance may not correspond with the coloured markings identifying the terminals in your plug, proceed as follows.

The wire which is coloured blue must be connected to the terminal which is marked with the letter 'N' or coloured black or blue.

The wire which is coloured brown must be connected to the terminal which is marked with the letter 'L' or coloured red or brown.

Downloaded from www.Manualslib.com manuals search engine

CONGRATULATIONS ON CHOOSING A BABY LOCK SEWING MACHINE

Your machine is one of the finest sewing machines available for home use.
To fully enjoy all the features incorporated into it, we suggest that you study this booklet.

PLEASE READ BEFORE USING YOUR SEWING MACHINE

For safe operation

- Be sure to watch the placement of your hands in relation to the needle while sewing. Do not touch moving parts such as the balance wheel, thread take-up or needle while the machine is operating.
- Remember to turn off the power switch and unplug the cord when:
  - Operation is completed
  - Replacing or removing the needle or any other parts
  - A power failure occurs during use
  - Maintaining the machine
  - Leaving the machine unattended
- Do not place anything on the foot controller.
- Plug the machine directly into the wall outlet. Do not use extension cords.

For a longer service life

- When storing your sewing machine, avoid direct sunlight and high humidity locations. Do not store the sewing machine beside a space heater, iron, or other hot objects.
- Use only neutral soaps or detergents to clean the case. Benzene, thinner, and scouring powders can damage the case and machine, and should never be used.
- Do not drop or hit the machine.
- Always consult the operation manual when replacing any accessories, including: the presser feet, needle or other parts to assure correct installation.

For repair or adjustment

In the event that a malfunction occurs or adjustment is required, first follow the troubleshooting table in the back of the operation manual to inspect and adjust the machine yourself. If the problem persists, please consult your nearest authorized Baby Lock service center.
For additional product information and update, or to find your nearest Baby Lock dealer, visit our website at www.babylock.com


Downloaded from www.Manualslib.com manuals search engine

CONTENTS

Accessories **1**
Machine Features **2**
Before You Begin **3**
Power Cord and Foot Controller 3
Power Switch 3
Thread Tension Dial 3
Hand Wheel 3
Stitch Length Regulator 3
Reverse Stitch Lever 3
Presser Foot Lift Lever 4
Knee Lift 4
Presser Foot Pressure Adjustment Dial 4
Fabric Extension Table 4
Thread Cutter Button 5
Needle Stop Position Button 5
Light Switch 5
Feed Dog Adjustment Knob 5
Changing Needles and Light Bulb **6**
Changing the Needle 6
Changing the Feed Pin 6
Changing Light Bulbs 6
Threading **7**
Bobbin Winding 7
Bobbin Insertion 9
Upper Threading 10
Using the Needle Threader 10
Using the Spool Net 11
Stitch Samples and Needle Chart **12**
Stitch Samples 12
Thread Tension 12
Changing Presser Feet **13**
Changing Presser Feet (Zipper Foot) 13
Presser Feet 13
Basic Sewing **14**
Basic Sewing 14
Pin Feeding (for hard-to-handle fabrics) 14
Rolled Hem Foot 15
Zipper Foot 16
Invisible Zipper Foot 17
1/4” Foot 17
Quilting Foot 18
Walking Foot 18
Seam Guide 19
Caring for Your Machine **20**
Cleaning the Machine 20
Lubrication Points 20
Trouble Shooting **21**

Downloaded from www.Manualslib.com manuals search engine

Accessories




No.	Part Name	Part Code
1	Cover	XA0917-052
2	Medium Screwdriver	125877-001
3	Small Screwdriver	125878-001
4	Cleaning Brush	XA4527-001
5	Knee Lift	XA0830-051
6	Needles and Case 1 Size 9 (ORGAN HLX5) 2 Size 11 1 Size 14 1 Size 16 1 Ballpoint Needle	X80805-001
7	Feed Pin	138483-001
8	Feed Pin Changer	XC1407-051
9	General Purpose Foot	XA1425-001
10	Bobbin (5)	SA159
11	Spool Cap	XA2111-000
12	Flex Reaction Foot (on machine)	136021-001
13	Rolled Hem Foot	X57138-001
14	Zipper Foot	112797-001
15	Invisible Zipper Foot	148475-001
16	1/4” Foot	XA7258-001
17	Quilting Foot	XA7255-201
18	Walking Foot	XA7253-001
19	Seam Guide	XA7256-001
20	Foot Controller	XC1220-051
21	Fabric Extension Table	XC1387-051
22	Spool Cone Holder (on machine)	XA0679-050
23	Spool Net	XA5523-050

Note
Foot controller: Model P
This foot controller is used for sewing machine model BLQP.

Downloaded from www.Manualslib.com manuals search engine

Machine Features



Downloaded from www.Manualslib.com manuals search engine


Before You Begin (1)

Power Cord and Foot Controller

⚠Note
Please use common household current.


- Plug in cord.
- Plug foot controller into machine.

Note
Foot controller: Model P
This foot controller is used for sewing machine model BLQP.




Power Switch

- Flip power switch to “I” position to turn on.
- To switch power off, flip switch to “O” position.



Thread Tension Dial


- When tighter thread tension is desired, turn the tension dial to the right. Upper and bobbin threads will meet on right side of the fabric.
- When looser thread tension is desired, turn tension dial to the left. Upper and lower threads will then meet on wrong side of fabric.



Hand Wheel


- Position needle using hand wheel.

✻ Always turn hand wheel towards you.



Stitch Length Regulator


- Adjust desired stitch length using stitch length regulator dial.



Reverse Stitch Lever

- Sewing in reverse is possible when the reverse stitch lever is in the lowered position.

✻ Make sure to push the lever all the way down when reverse sewing is desired.
✻ When the feed adjustment dial is set between 5-7mm, the reverse stitch length is always 5 mm.




Downloaded from www.Manualslib.com manuals search engine

Presser Foot Lift Lever

● Lowering the presser foot lift lever lowers the sewing foot down onto the fabric and engages the thread tension function.


✻ When working with heavy fabrics or other fabrics that don't slide easily under the foot, raise the presser foot lever to position the fabric.



Knee Lift


● Using the convenient knee lift to lift and lower the presser foot easily, leaving both your hands free.


Setting up the knee lift.



✻ Push the knee lift bar all the way into the socket.

✻ When knee lift is not in use, it can rest at the bottom of the fabric extension table.





Presser Foot Pressure Adjustment Dial


● Turning the pressure adjustment dial raises and lowers the pressure indicator needle as the amount of pressure on the presser foot changes.

See also: "Feed Dog Adjustment Knob" on page 5.

✻ See "Thread Tension" on page 12.


✻ Coordinate the color coding for proper foot pressure and feed dog settings.

Presser Foot Pressure Adjustment Dial



Fabric Extension Table

● Lower table feet and attach fabric extension table as shown in the below diagram.




Downloaded from www.Manualslib.com manuals search engine

Before You Begin (2)

Thread Cutter Button

⚠Note
When the machine stops due to jammed threads and so forth, do not step on the foot controller, turn the power off and move the needle with the hand wheel, check the situation. Otherwise broken needles could result.

- The thread cutter trims upper and bobbin threads at the end of seams.




Thread Cutter Button

✻ Press with the presser lever down.

Needle Stop Position Button


- When indicator lamp is lit up, the machine will stop sewing with the needle lowered through the fabric.
- When indicator lamp is off, the needle position when sewing stops, will be random.
- If the safety mechanism is activated, for example if the thread becomes tangled, the red lamp flashes.



Needle Stop Position Button


Light Switch

- Push light switch to turn the light over the sewing area on and off.




Feed Dog Adjustment Knob

- Height of feed dogs can be adjusted to coincide with fabric weights.



Feed Dog Adjustment Knob

Foot Pressure and Feed Dog Position



Select one of four feed dog positions according to your needs.

Note


✻ If a setting other than is selected, the pin feed mechanism will not operate.
✻ Coordinate the color coding for proper foot pressure and feed dog settings.

Downloaded from www.Manualslib.com manuals search engine

Changing Needles and Light Bulb

⚠Note
Please make sure power is off before carrying out the following operations. There is a chance of injury if the machine accidentally starts running during this operation.

Changing the Needle




① Turn the sewing machine off. Raise needle to highest position using hand wheel, and lower presser foot.
② Loosen screw with screwdriver, and remove needle.
③ Hold the needle with the flat side to the right, and insert the needle as far as it will go. Make sure needle is screwed in tightly.

✻ If the needle is not adequately inserted or the screw is loose, this may break the needle or cause a breakdown and the needle threader will not work.
✻ Check needles on a flat surface to make sure they are not bent.

Note
HLX5 needles should be used; however, Schmetz 130/705H may also be used under normal circumstances.


Changing the Feed Pin



① Set the feed dogs to "velvet" position. (See page 5.)
② Remove needle, presser foot and needle plate.
③ Lower presser foot and turn hand wheel until feed pin is in its highest position.
④ Insert small screwdriver (included) as shown in diagram.
⑤ While holding spring with fingertip, lower the feed pin changer onto the needle to pick it up.
⑥ Attach new feed pin to feed pin changer, lower and attach while holding spring with fingertip.
⑦ Remove screwdriver.
⑧ Re-attach needle plate, needle and presser foot.

⚠Note
Please make sure power is off before carrying out the following operation. The glass plate over the light bulb will be hot immediately after using the machine, therefore it is advisable to wait until the light bulb has had a chance to cool down before changing bulbs.

Changing Light Bulbs




① Turn off power.
② Remove screw from head.
③ Remove bulb housing.
④ Unscrew bulb and remove.
⑤ Screw in new bulb.
Sewing Light:
See page 20.
⑥ Re-attach bulb housing and tighten screw.

Downloaded from www.Manualslib.com manuals search engine


Threading (1)

Bobbin Winding

⚠Note
Do not move bobbin winding clutch while machine is running.




⑤ - ⑩: See the following illustrations.




① Raise the thread guide bar all the way.
② Mount a spool thread on the spool pin.


✻1 Use spool cap when using parallel-wound thread.
✻2 Use spool cone holder to stabilize cone shaped spools of thread.




③ Pass the thread through the triangular hole.



④ Pass thread through bobbin winding thread guide as shown in drawing.




⑤ Run thread through top thread notch 1, and align bottom thread notch 2 of the bobbin with guide pin on bobbin winder shaft.




⑥ Press bobbin winding clutch up against empty bobbin. If the bobbin stop does not slide easily between the top and bottom of the bobbin, check that the bobbin is seated properly with the guide pin (⑤) inserted into the lower notch.

Downloaded from www.Manualslib.com manuals search engine




✻ Place the thread end so that it does not protrude from the bobbin.

⑦ While holding the end of the thread, step on the foot controller for a few seconds. Once enough thread has wound itself around the bobbin to hold itself in place, release the foot controller and trim the excess thread. Continue to wind the bobbin while pressing down on the foot controller.




⑧ Release the foot controller to stop winding process when bobbin is full.



Bobbin Winding Clutch

⑨ Manually move bobbin winding clutch back to original position.




⑩ Cut thread and remove bobbin.


Downloaded from www.Manualslib.com manuals search engine

Bobbin Insertion


⚠CAUTION – Moving parts –
To reduce risk of injury, switch power off before servicing. Open covers.



① Lift needle plate and open bobbin door.




⑤ Lower slide plate and close bobbin door, following numbers ❶ ❷ above in order.




② Put bobbin into the bobbin case.

✻ Run thread through thread notch and under latch spring, so that a length of thread is exposed.
✻ Always use the bobbin case that was supplied with this machine. A secondary bobbin case can be ordered from your dealer.



③ Pull the latch lever of the bobbin case out and push the bobbin case into the shuttle race and release the latch lever.


✻ If the latch lever is not set securely on the hook, it may fly off during sewing and cause lower thread breakage. Rotate the hand wheel one full rotation towards you to check that the bobbin case is set securely.



④ Pass the thread through the quick bobbin thread device in the order ❶ ❷, pull in the direction of the arrow ❸, then cut the thread.

★ Quick Bobbin Thread Device
This device cuts the bobbin thread end to an appropriate length after the bobbin has been replaced and holds it at that length, so the operation of pulling out the thread can not be skipped.

● **When the fabric extension table is set in place**




Open the bobbin thread setting cover beforehand, then set the bobbin thread in place. (You can set the bobbin thread in place without removing the fabric extension table.)


Downloaded from www.Manualslib.com manuals search engine

Threading (2)

⚠Note Please turn off the power before using needle threader. Accidentally stepping on the foot controller during this operation could cause bodily injury or damage to the machine.


Upper Threading






● Make sure thread take-up lever is in highest position and presser foot is up.


✻ When using polyester thread or thread that tangles or breaks, run the thread through all Three Hole of the thread guide.





✻ If the thread is still tangles or breaks, run the thread through the holes backwards as shown in diagram.




Using the Needle Threader







✻ Pull the thread to the left and check that it is caught on the hook.



① Rotate hand wheel towards you until needle is in the highest position, and lower presser foot.

② Take thread in your left hand, and gently pull it forward.

③ Lower needle threader.


✻ Pull thread along the right side of the pin.

✻ Do not force the needle threader lower than the eye of the needle. Be sure that the needle is in the highest position.

④ Turn the needle threader lever all the way in the direction of ❶ and when the hook extends from the needle hole, pull the thread in the direction of ❷ to catch it on the hook.

⑤ While holding the thread gently, return the needle threader lever to the right. As you do this the hook that has caught the thread will move as well, pulling a loop of thread through the eye of the needle.

Downloaded from www.Manualslib.com manuals search engine




⑥ Pull thread loop to the right.

Needle (HLX5)	Thread
#9	#20 #30 #50 #60
#11	#20 #30
#14	#20 #30
#16	#20

- The needle threader cannot be used with the thread-needle combinations illustrated in the chart to the left. Transparent nylon thread can be used regardless of the chart, providing the needle used is a #14 or #16.

Using the Spool Net



① Spool net
② Thread spool
③ Spool pin
④ Spool cap


If using transparent nylon thread, metallic thread, or other strong thread, place the included spool net over the spool before using.
If the spool net is too long, fold it once to match it to the spool size before placing it over the spool.

Downloaded from www.Manualslib.com manuals search engine


Stitch Samples and Needle Chart

Stitch Samples


① Set stitch length regulator to desired stitch length.
② Make sure approximately 15 cm of upper and bobbin threads are pulled out and laying behind presser foot. While needle is in raised position, insert a test strip from the garment fabric under the foot.



③ Lower presser foot.
④ Turn the hand wheel forward to lower the needle through the fabric, then step gently on the foot controller to begin.




⑤ Turn the hand wheel towards you to raise the needle and thread take-up lever to their highest positions.
⑥ Lift presser foot, remove fabric and then cut thread.



✻ When using thread cutter:
⑤ Press the thread cutter button while the presser foot lever in the down position.
⑥ Lift foot and remove fabric.

Thread Tension

✻ Bobbin thread should feed smoothly. Adjust bobbin thread to match that of upper thread. (If bobbin thread is too tight it may cause fabric to bunch up.)



● **Selecting the proper needle for use with the fabric and thread you are working with**

✻ The following chart applies to many different fabric, thread and needle combinations.

	Fabric - Thread - Needles			HLX5	Schmetz 130/705H
	Cloth	Thread	Needle (HLX5)		
Special fabric	Velvet	Silk, Polyester #30 – #50	#11 – #14	#9	#65
	Quilt	Polyester #20 – #50	#11 – #16	#11	#75
	Synthetic Suede	Polyester #20 – #50		#14	#90
	Knit	Polyester #20 – #50		#16	#100
	Coating	Polyester #50	#11 – #14	#18	#110
Light weight fabrics	Lawn	Cotton #80	#9		
	Tricot	Polyester #60			
	Silk Georgette	Silk #50			
	Wool Georgette	Silk, Polyester #50	#11		
Middle weight fabrics	Gingham	Cotton #60 – #80	#11 – #14		
	Lightweight Jersey	Polyester #60	#11		
	Gabardine, Flannel	Silk #50			
Heavy weight fabrics	Denim	Cotton #20 – #50	#14 – #18		
	Jersey	Polyester #20 – #50	#11 – #16		
	Tweed	Silk #20 – #50			

✻ HLX5 needles are recommended; however, Schmetz 130/705H needles may also be used under normal sewing conditions.
✻ Adjust the pressure adjustment dial and the feed dog adjustment knob according to the chart on the sewing machine.
✻ When sewing on knit fabrics such as jersey or tricot, use a ballpoint needle or a needle designed for use with knit fabrics.
✻ For best results when using metallic threads, sew with a good quality thread, set upper tension on 2, and use metallic needle.


Downloaded from www.Manualslib.com manuals search engine

Changing Presser Feet

⚠Note Make sure the power is off before changing presser feet.


Changing Presser Feet (Zipper Foot)

① Raise presser foot, and raise needle to highest position.
② Loosen and remove screw using screwdriver.




③ Attach zipper foot and tighten screw.

✻ Use the same method to attach the other feet that come with your BLQP.
✻ See page 18 for directions on attaching the “Walking Foot”.




✻ Use the position knob on back of the zipper foot to adjust position of foot in relation to needle.
✻ Only the zipper foot has a position knob. You can begin sewing with all other presser feet immediately after attaching.




Presser Feet

✻ Use only feet supplied with your BLQP. Each foot is specially designed for this machine and has clearance for the pin at the rear of each foot. Use of other presser feet may damage or break the pin feed mechanism.


- **Flex Reaction Foot**
  For perfect stitching on otherwise difficult fabrics like velvet, leather and suede.




- **Rolled Hem Foot**
  Use on the edge of fabric, such as on hems of dress shirts, to fold the edge of the fabric in three while sewing.




- **Invisible Zipper Foot**
  Use to attach concealed fasteners.



- **Quilting Foot**
  Spring action foot for darning, quilting or free-motion embroidery.




- **General purpose Foot**
  This foot is used for most sewing. (Can also be used for sewing thick fabrics or seams.)




✻ When sewing thick seams, lightly guide the fabric with your hand on the downward side of the seam.
✻ Can also be used with pin feeding.


- **Zipper Foot**
  Use to attach fasteners other than concealed fasteners.



- **1/4” Foot**
  For quilt and patchwork piecing with 1/4” or 1/8” seam allowance.




- **Walking Foot**
  For sewing or quilting on fabrics which stick or tend to slip Useful for sewing multiple layers as in quilting.



Downloaded from www.Manualslib.com manuals search engine

Basic Sewing (1)

Basic Sewing



① Lift foot, pull about 15 cm of upper and bobbin thread under and behind foot, and position fabric under foot.

② Lower presser foot lever to lower foot.
③ Turn the hand wheel forward you to lower the needle through the fabric, then step gently on the foot controller to begin.

✻ At the beginning and end of a seam, press down the reverse stitch lever and backstitch about 1 cm.


④ Raise needle to highest position.
⑤ Lift foot, remove fabric and cut thread.
✻ When using thread trimmer:
④ Push thread trimmer button (this will cause the upper and bobbin threads to be cut automatically and the needle to stop in a raised position).
⑤ Lift presser foot and remove fabric.

① Make sure needle is pierced all the way through fabric.
② Lift presser foot, and turn fabric using needle as an axis.
③ Lower foot and continue sewing.

Pin Feeding (for hard-to-handle fabrics)

Velvet, quilt fabric, synthetic suede, knits and other fabrics can be joined evenly by activating the pin feed mechanism.

● Machine Set-up for Pin Feeding




① Move feed adjustmen knob to pin feeding position.

② Adjust pressure adjustment dial until indicator needle is in the right position in the matching color coded area.

③ Attach flex reaction presser foot for perfect stitching on difficult fabrics like velvet, leather and suede.


● Pin Feeding Mechanism



The feed pin passes up through all layers of fabric moving with the feed dog's motion to feed all layers of the fabric evenly.

✻ For safety, the feed pin is automatically lowered when presser foot is raised.

● Start to Sew



Gently pull thread until feed pin catches fabric and sew.

Downloaded from www.Manualslib.com manuals search engine


Basic Sewing (2)

⚠Note Make sure power is off before changing feet.


Rolled Hem Foot

① Attach rolled hem foot.
✻ Refer to page 13 for instructions on changing sewing feet.


② Insert needle approximately 0.5 cm from the edge of the fabric and sew 2 stitches.




③ Turn the hand wheel towards you to raise the needle, raise the presser foot, then pull the fabric forward.




④ Hold the 4 threads in your left hand.



⑤ With your right hand, put the edge of the rolled hem under the presser foot, from the spot where the threads come out. Insert the edge so that it lies directly under the needle. Lower the presser foot.



⑥ Pull gently on threads in left hand while sewing the first 3-4 stitches to hold them in place.
⑦ Fold hem over about 0.5 cm and continue feeding folded hem under foot while sewing towards the curved guide on the foot.



Downloaded from www.Manualslib.com manuals search engine


Basic Sewing (3)

⚠Note
- Make sure power is off before changing feet.
- When attaching zippers to stretch fabrics, use the pin feed method and adjust foot pressure accordingly.
- The zipper foot can also be used as a guide when attaching piping to fabric.

Zipper Foot

① Attach zipper foot.
✻ See “Changing Presser Feet (Zipper Foot)” on page 13.
② Turn the hand wheel towards you to lower the needle and adjust the position of the foot relative to the needle using the adjustment screw to slide the foot from left to right.
③ Line up zipper to the section of fabric it will be attached to, and mark the base of the opening on the fabric. It should be set approximately 0.5 cm below zipper stop. Sew from below the base of the opening.

④ Divide the seam margin. Fold the seam margin with the overlap of the zipper position facing down 0.2 cm on the outside of the mark.



⑤ Secure the zipper with basting and sew along the mark.


⚠ Make sure the needle does not strike the metal part of the zipper when sewing. The needle may break and cause injury.

⑥ Line up the folded hem on the opposite side with the stitches.

⑦ Change position of zipper foot.
⑧ Turn the hand wheel to lower the needle and position the presser foot.

⑨ With the fabric right side up, baste the zipper onto the fabric, then sew the edge of the basting.


✻ Reinforce base of opening by sewing over it twice.
✻ If the zipper slide gets in the way, lower the needle all the way through the fabric, lift the foot, and move the slider out of the way.




Downloaded from www.Manualslib.com manuals search engine

Invisible Zipper Foot

① Attach invisible zipper foot.
② Align zipper with fabric. Mark the base of the opening approximately 2 cm above the end of the zipper.
③ Baste the zipper position.




④ Separate the seam allowance.
⑤ With the zipper mounted, baste just the seam margin on one side of the zipper.
⑥ Close the zipper and baste the other side of the zipper.
⑦ Remove the basting at the zipper position.



⑧ Fit the zipper teeth into the presser foot groove, guide them to prevent them from falling over, and sew to the base of the opening.


✻ When sewing with the teeth to the right, the left side of the foot should line up with the left teeth of the zipper.




1/4” Foot

● Sewing machine settings:
Stitch length = 2 - 2.5


• Sew a consistent seam allowance (1/4”, 6.4 mm) when piecing together a quilt.



• Use guides (mark) to begin, end, or pivot 1/4” from edge of fabric.




• Accurately top stitch 1/8” from seam.



Downloaded from www.Manualslib.com manuals search engine

Quilting Foot

Reduce the foot pressure and turn the dial on the machine lowering the feed dogs for free motion quilting.




⚠Note

- If the foot is frequently used, be sure to apply a small amount of oil about once a month to the area indicated by the arrow. (If too much oil is applied, wipe off the excess with a cloth.)
- For best results when using metallic or monofilament threads for free-motion quilting, sew with a good quality thread, set upper tension 1-2, and use a metallic needle.

Walking Foot

⚠Note

- Do not press the foot controller all the way down.
  Try to keep the sewing speed low (500 r.p.m. or less).
- The fabric may not feed if you sew at high speeds.
- The feed dog for feeding the cloth may not move if the foot pressure on the fabric is too strong. Use the presser foot pressure adjustment dial to achieve the desired results.
- It is not advisable or necessary to use the Pin Feed mode with the walking foot.




① Insert the forked part of the operation lever while raised in an upright position onto the screw on the right side of the needle bar, as shown and then insert the capscrew.

② Tighten the screw securely with a screwdriver. Tightening adequately is important as the screw might loosen due to the foot and forked operation lever vibration.

Downloaded from www.Manualslib.com manuals search engine


Seam Guide

① Tighten the screw securely with a screwdriver since it might otherwise loosen due to vibration.



Installation

To be able to adjust the position of the foot towards the arrow.



Adjustment


Downloaded from www.Manualslib.com manuals search engine

Caring for Your Machine

Cleaning the Machine


⚠Note
Make sure power is off before cleaning sewing machine.

① Turn machine off.
② Remove foot.
③ Remove needle plate.




④ Clean out dust and thread scraps.

✻ Thread scraps can be swept out through the bobbin door.



⑤ When the area under the needle plate is cleaned out, oil* hook of bobbin case with sewing machine oil.
✻ Use a cloth to clean the machine of any excess oil.
★ Use only fine sewing machine oil.


⑥ Attach needle plate and foot.



Lubrication Points


● When using the sewing machine every day, apply a few drops of oil* to each location indicated twice a month.

✻ Use a cloth to wipe the machine clean of any oil spilled near the lubrication points.
★ Use only fine sewing machine oil.



■ **Keep Your Sewing Machine Clean**
Please use a soft, dry cloth to wipe off light dirt and dust. If sewing machine is very dirty, wipe with a cloth soaked in warm water, or in warm water containing a neutral detergent. Then wipe off any detergent residue, and wipe off water with a dry cloth.

■ **Precautions**
Please keep sewing machine away from heat sources such as irons and space heaters. Do not use chemicals like benzine or thinner to clean your machine. When machine is not in use, please keep machine out of direct sunlight.



Item	Specification
Sewing Speed (maximum)	1,500 stitches per minute
Stitch Length (pitch)	0 – 7 mm
Stroke of Needle	34.1 mm
Stroke of Thread Take-Up Lever	64.7 mm
Foot Height	Foot Lift: One 6 mm, Two 9 mm Knee control: Over 10 mm

Item	Specification
Height of feed dog	0.7 mm 1.1 mm
Height of lower needle	3 mm – 3.5 mm
Needles that may be used	HLX5#9 – #18 SCHMETZ 130/705H #65 – #110
Bed dimensions	439 mm × 178 mm
Total weight	11 kg
Sewing Light	120V model: 120V/15W Parts code: X53061-050 220-240V model: 240V/15W Parts code: 205336-050
Sewing area	595 mm × 285 mm

Downloaded from www.Manualslib.com manuals search engine

Trouble Shooting

✻ Before taking your sewing machine in for service, check the following chart.

Thread Breakage	Upper threading is not threaded correctly. Re-thread machine properly. 10	Thread is getting tangled. Rethread machine. Clean bobbin case and under needle plate. Oil the machine. 9-11.20	Upper thread tension is too high. Reduce tension. 12	Improper fabric/needle/ thread combination. See chart on p.12 for the right needle to use with your fabric and thread. 12	Bobbin case is scratched. Remove needle plate and check bobbin case.
Bobbin Thread Breakage	Bobbin thread is not passing correctly from bobbin case. Reinsert bobbin properly. 9	Thread is getting tangled. Rethread machine. Clean bobbin case and under needle plate. 9-11.20	Bobbin tension is too high. Reduce tension. 12	Bobbin case is scratched. Remove needle plate and check bobbin case.	
Skipped Stitches	Needle is not inserted correctly. Reinsert. 6	Wrong needle. See chart on p.12 to choose the needle that best fits your fabric-thread combination. 12	Needle is bent, or tip is dulled. Change needles. 6	Area under needle plate needs to be cleaned. Clean feed dog and bobbin case. Oil the machine. 20	Machine is not threaded properly. Rethread machine. 9-11
Fabric Puckers	Threading is incorrect. Rethread machine. 9-11	Wrong needle for the fabric and thread you are using. See chart on p.12 to choose the needle that best fits your fabric-thread combination. 12	Upper thread tension is too high. Reduce tension. 12	Bobbin tension is too high. Reduce tension. 12	You're sewing a lightweight fabric with feed dogs in heavyweight position. Adjust feed dogs. 5
Fabric Won't Feed Properly or Irregular Stitches	Stitch length is too short. Adjust stitch length. 3	Pressure of sewing foot is too weak. Increase foot pressure. 4	Sewing heavyweight fabric with feed dogs in lightweight fabric position. Adjust feed dogs. 5	Thread is getting tangled. Rethread machine. Clean needle plate and bobbin case. 9-11.20	
Loop in Seam	Upper threading is incorrect. Re-thread machine properly. 10	Thread is not passing through bobbin case correctly. Reset bobbin case. 9	Improper fabric/needle/ thread combination. See chart on p.12 for the right needle to use with your fabric and thread. 12		
Needle Breakage	Needle is not attached correctly. Reattach. 6	Wrong needle. Change needles. 6	Improper fabric/needle/ thread combination. See chart on p.12 for the right needle to use with your fabric and thread. 12	You're pulling the fabric too hard. Pull the fabric more gently. 14-17	
Sewing Machine Doesn't Run	The power isn't on. Turn the power on. 3	Machine's not plugged in. Check to make sure the machine's plugged in. 3	The foot controller has come unplugged. Reattach foot controller. 3	Machine is out of oil. Clean and oil the machine. 20	The automatic safety device has operated.
Machine is Noisy	The area under the needle plate needs to be cleaned. Clean feed dog and bobbin case. 20	Machine is out of oil. Oil the machine. 20			
Automatic Needle Threader Doesn't Work	Needle is not raised all the way up. Turn hand wheel to raise needle. 3	Wrong needle for the thread you're using. See chart on p.12. 12	Hook of needle threader doesn't pass through eye of needle. Check to make sure the hook isn't bent.	Using the automatic needle threader incorrectly. Check the use of the automatic needle threader. 10	
Thread Cutter Doesn't Work	Needle is not properly inserted. Reinsert. 6	Wrong needle. See chart on p.12 to choose the needle that best fits your fabric-thread combination. 12	Needle is bent, or tip is dulled. Change needles. 6	Area under needle plate needs to be cleaned. Clean feed dog and bobbin case. 20	Upper threading is incorrect. Rethread. 10

● If you still cannot find the problem, please take your sewing machine into the shop where you purchased it, or your nearest Baby Lock dealer for repair.

Downloaded from www.Manualslib.com manuals search engine

NOUS VOUS REMERCIONS D'AVOIR CHOISI LA MACHINE A COUDRE ELECTRONIQUE BABY LOCK.

Cette machine à coudre est une des meilleures disponibles actuellement pour l'usage domestique.
Cependant, nous vous conseillons la lecture de ce fascicule afin de profiter pleinement de toutes les fonctions intégrées.

RECOMMENDATIONS AVANT D'UTILISER VOTRE MACHINE A COUDRE BABY LOCK

Précautions d'utilisation

- Toujours bien vérifier la position de vos mains par rapport à l'aiguille pendant la couture. Ne pas toucher le volant, le releveur de fil, l'aiguille ou les autres parties en mouvement.
- Se rappeler qu'il faut éteindre la machine et débrancher le cordon secteur quand:
  - l'utilisation est terminée
  - vous remplacez ou échangez l'aiguille ou toutes autres pièces
  - une panne de courant se produit en cours d'utilisation
  - vous faites l'entretien et la lubrification de la machine
  - vous laissez la machine sans surveillance
- Ne rien poser sur la pédale de commande.
- Brancher la machine directement dans une prise secteur. Ne pas utiliser de rallonge électrique.

Pour une vie prolongée de votre machine

- Ne pas ranger votre machine dans des endroits exposés au soleil et très humides. Ne pas ranger votre machine à coudre à proximité d'un appareil de chauffage, d'un fer à repasser, ou de tout autre appareil dégageant de la chaleur.
- Utiliser seulement des savons ou des détergents neutres pour nettoyer le coffret de la machine. Ne jamais utiliser de benzine, de diluants, de décapants, car ces produits risquent endommager la coffret et la machine.
- Ne pas laisser tomber ou heurter la machine.
- Toujours consulter le manuel d'utilisation lors de la mise en place du pied-de-biche, de l'aiguille ou d'autres éléments accessoires pour s'assurer de les installer correctement.

Pour la réparation et le réglage

Dans le cas d'une anomalie ou lorsqu'un réglage est nécessaire, se rapporter au chapitre "Résolution des problèmes" afin d'inspecter et de régler vous-même la machine.
Si le problème persiste, consultez votre revendeur Baby Lock.
Pour obtenir d'autres informations sur le produit et les mises à jour, ou pour connaître le revendeur Baby Lock le plus proche, visiter le site www.babylock.com


Downloaded from www.Manualslib.com manuals search engine

TABLE DES MATIÈRES

Accessoires 24
Fonctions de la machine 25
Avant de commencer 26
Cordon d'alimentation et pédale 26
Interrupteur d'alimentation 26
Disque sélecteur de tension du fil 26
Volant 26
Sélecteur de longueur de point 26
Levier de point arrière 26
Levier du pied-de-biche 27
Levier de levage au genou 27
Disque sélecteur de réglage de la pression du pied-de-biche ... 27
Table de rallonge pour tissu 27
Bouton de ciseaux 28
Bouton de position d'arrêt d'aiguille 28
Interrupteur de lampe 28
Bouton de réglage des griffes d'entraînement 28
Remplacement de l'aiguille et de l'ampoule de lampe ... 29
Remplacement de l'aiguille 29
Remplacement de l'ergot d'entraînement 29
Remplacement de l'ampoule 29
Enfilage 30
Remplissage de la canette 30
Insertion de la canette 32
Mise en place du fil supérieur 33
Utilisation de l'enfileur 33
Utilisation du filet de la bobine 34
Points d'essai et tableau d'aiguilles 35
Points d'essai 35
Tension des fils 35
Changement du pied-de-biche 36
Changement du pied-de-biche
(Pied pour fermeture à glissière) 36
Les différents pied-de-biche 36
Couture de base 37
Couture de base 37
Entaînement par ergot
(pour les tissus difficiles à manipuler) 37
Pied pour ourlet rouleauté 38
Pied pour fermeture à glissière 39
Pied pour fermeture à glissière invisible 40
Pied 1/4" 40
Pied transparent pour ouatinage/matelassage 41
Pied double-entrainement 41
Guide de couture 42
Entretien de la machine à coudre 43
Nettoyage de la machine 43
Points de graissage 43
Dépannage 44

Downloaded from www.Manualslib.com manuals search engine

Accessoires





No. de pièce	Désignation	Code de pièce
1	Couvercle	XA0917-052
2	Tournevis moyen	125877-001
3	Petit tournevis	125878-001
4	Brosse de nettoyage	XA4527-001
5	Levier de levage au genou	XA0830-051
6	Aiguilles et boîte 1 Taille 9 (ORGAN HLX5) 2 Taille 11 1 Taille 14 1 Taille 16 1 aiguille à pointe-bille	X80805-001
7	Axe d'avance	138483-001
8	Extracteur d'axe d'avance	XC1407-051
9	Pied à usage général	XA1425-001
10	Canette (5)	SA159
11	Capuchon de bobine	XA2111-000
12	Pied à réaction souple (sur la machine)	136021-001
13	Pied pour ourlet rouleauté	X57138-001
14	Pied pour fermeture à glissière	112797-001
15	Pied pour fermeture à glissière invisible	148475-001
16	Pied 1/4"	XA7258-001
17	Pied transparent pour ouatinage/matelassage	XA7255-201
18	Pied double-entrainement	XA7253-001
19	Guide de couture	XA7256-001
20	Pédale du rhéostat	XC1220-051
21	Table de rallonge pour tissu	XC1387-051
22	Broche porte-bobine conique (sur la machine)	XA0679-050
23	Filet de la bobine	XA5523-050

Remarque
Pédale du rhéostat: Modèle P
Cette pédale sert pour le modèle de machine à coudre BLQP.

Downloaded from www.Manualslib.com manuals search engine

Fonctions de la machine





Downloaded from www.Manualslib.com manuals search engine


Avant de commencer (1)

Cordon d'alimentation et pédale

⚠Remarque
Utiliser un courant secteur domestique ordinaire.


- Brancher le cordon.
- Brancher la pédale sur la machine.

Remarque
Pédale de rhéostat: Modèle P
Cette pédale sert pour le modèle de machine à coudre BLQP.




Interrupteur d'alimentation

- Basculer l'interrupteur sur la position "I" pour allumer la machine à coudre.
- Pour éteindre la machine, basculer l'interrupteur sur la position "O".



Disque sélecteur de tension du fil


- Pour augmenter la tension du fil, tourner le sélecteur de tension vers la droite. Le fil supérieur et le fil de la canette se rejoignent sur le bon côté du tissu.
- Pour diminuer la tension du fil, tourner le sélecteur de tension vers la gauche. Le fil supérieur et le fil de la canette se rejoignent sur le mauvais côté du tissu.



Volant


- Positionner l'aiguille à l'aide du volant.

✻ Toujours tourner le volant vers soi.



Sélecteur de longueur de point


- Régler la longueur de point à l'aide du sélecteur de longueur de point.



Levier de point arrière

- Pour coudre en marche arrière, abaisser le levier de point arrière.

✻ Bien abaisser le levier de point arrière à fond pour coudre en marche arrière.
✻ Lorsque le sélecteur de réglage de l'entraînement est réglé entre 5-7mm, la longueur du point arrière est toujours de 5 mm.




Downloaded from www.Manualslib.com manuals search engine

Levier du pied-de-biche

● Abaisser le levier du pied-de-biche pour abaisser le pied sur le tissu et activer la fonction de tension du fil.


✻ Pour travailler dans du tissu lourd et des tissus qui ne glissent pas facilement sous le pied, relever le levier du pied-de-biche pour placer le tissu.



Levier de levage au genou

● Le levier de levage au genou est pratique pour soulever et abaisser le pied-de-biche en gardant les mains libres.

Installation du levier de levage au genou.



✻ Enfoncer la barre du levier de levage au genou à fond dans la prise.

✻ Lorsqu'on ne se sert pas du levier de levage au genou, on pourra le laisser sur l'envers de la table de rallonge pour tissu.





Table de rallonge pour tissu



Disque sélecteur de réglage de la pression du pied-de-biche

● Tourner le sélecteur de pression pour faire monter ou descendre l'aiguille de l'indicateur de pression à mesure que la pression du pied-de-biche change.

Voir également: "Bouton de réglage des griffes d'entraînement", page 28.

✻ Voir "Tension des fils" à la page 35.

✻ Coordonner le code de couleur pour obtenir un réglage correct de la pression du pied et des griffes d'entraînement.

Disque sélecteur de réglage de la pression du pied-de-biche





Table de rallonge pour tissu

● Abaisser les pieds de table et fixer la table de rallonge pour tissu comme indiqué sur le schéma ci-dessous.




Downloaded from www.Manualslib.com manuals search engine

Avant de commencer (2)

Bouton de ciseaux

⚠Remarque
Si la machine s'arrête, notamment en cas de bourrage de fils, etc., ne pas appuyer sur la pédale; mette la machine hors tension, déplacer l'aiguille avec le volant à main, puis vérifier la situation. Sinon, l'aiguille risque de casser.

- Les ciseaux coupent le fil supérieur et le fil de la canette à la fin des coutures.




Bouton de ciseaux

✻ Appuyer avec le levier du pied-de-biche abaissé.

Bouton de position d'arrêt d'aiguille


- Quand le voyant est allumé, la machine arrêtera la couture lorsque l'aiguille sera abaissée et enfoncée dans le tissu.
- Si le voyant est éteint, la position de l'aiguille au moment de l'arrêt de la couture sera aléatoire.
- Si le mécanisme de sécurité s'est déclenché, par exemple si le fil est emmêlé, le voyant rouge clignote.



Bouton de position d'arrêt d'aiguille


Interrupteur de la lampe

- Appuyer sur l'interrupteur pour allumer et éteindre la lampe sur la section de couture.




Bouton de réglage des griffes d'entraînement

- Il est possible de régler la hauteur des griffes d'entraînement en fonction du poids du tissu.



Bouton de réglage des griffes d'entraînement

Pression du pied-de-biche et position des griffes d'entraînement



Sélectionner l'une des quatre positions de griffes d'entraînement, en fonction des besoins.

Remarque


✻ Si on sélectionne un réglage autre que ▲▲▲, le mécanisme d'entraînement par ergot ne fonctionnera pas.
✻ Coordonner le code de couleur pour obtenir un réglage correct de la pression du pied et des griffes d'entraînement.

Downloaded from www.Manualslib.com manuals search engine


Remplacement de l’aiguille et de l’ampoule de lampe

⚠Remarque
Bien éteindre la machine à coudre avant d’effectuer les opérations suivantes. Sinon, la machine risque de se mettre en marche accidentellement et de provoquer des blessures.


Remplacement de l’aiguille



① Eteindre la machine. Relever l’aiguille sur la position de levage maximal à l’aide du volant, et abaisser le pied-de-biche.
② Desserrer la vis avec un tournevis et retirer l’aiguille.
③ Tenir l’aiguille avec la section plate sur la droite, et insérer l’aiguille à fond. Bien s’assurer qu’elle est vissée à fond.




✻ Si l’aiguille n’est pas insérée correctement ou si la vis est trop lâche, l’aiguille risque de se casser ou la machine risque de tomber en panne et l’enfileur ne fonctionnera pas.
✻ Vérifier les aiguilles sur une surface plane pour s’assurer qu’elles ne sont pas tordues.




Remarque
Utiliser des aiguilles HLX5; toutefois, on pourra également utiliser des aiguilles Schmetz 130/705H dans des circonstances normales d’utilisation.


Remplacement de l’ergot d’entraînement




① Régler les griffes d’entraînement sur la position “velours”. (Voir page 28.)
② Retirer l’aiguille, le pied-de-biche et la plaque à aiguille.
③ Abaisser le pied-de-biche et tourner le volant jusqu’à ce que l’ergot d’entraînement soit à la position de levage maximale.
④ Insérer le petit tournevis (fourni) comme indiqué sur le schéme.



⑤ Tout en tenant le ressort du bout des doigts, abaisser le changeur d’ergot d’entraînement sur l’aiguille pour relever la tige.




⑥ Fixer un nouvel ergot d’entraînement au changeur d’ergot d’entraînement, abaisser et fixer tout en tenant le ressort du bout des doigts.
⑦ Retirer le tournevis.
⑧ Remonter la plaque à aiguille et le pied-de-biche.




⚠Remarque
Veiller à ce que la machine à coudre soit hors tension avant d’effectuer les opérations suivantes. La plaque de verre qui abrite l’ampoule de la lampe est chaude immédiatement après l’utilisation de la machine; nous conseillons dès lors d’attendre que l’ampoule ait refroidi avant de changer cette dernière.


Remplacement de l’ampoule



① Eteindre la machine.
② Retirer la vis de la tête.
③ Retirer le logement de l’ampoule.



④ Dévisser l’ampoule et la retirer.
⑤ Visser une nouvelle ampoule. Lampe de couture : voir page 43.
⑥ Remonter le logement de l’ampoule et visser à fond.




Downloaded from www.Manualslib.com manuals search engine


Enfilage (1)

Remplissage de la canette

⚠Remarque
Ne pas déplacer la butée de canette pendant que la machine fonctionne.




⑤ - ⑩: Voir les illustrations suivantes.




① Relever la barre de guidage du fil au maximum.
② Placer une bobine de fil sur le porte-bobine.


✻1 Avec un fil enroulé parallèlement, utiliser le capuchon de bobine.
✻2 Utiliser la broche porte-bobine conique pour stabiliser les bobines de fil en forme de cône.




③ Passer le fil par l'orifice triangulaire.



④ Passer le fil par le guide-fil de bobinage de la canette comme illustré sur le schéma.




⑤ Faire passer le fil dans l'encoche supérieure 1 puis aligner l'encoche inférieure 2 sur la tige de guidage de l'axe du dévidoir.




⑥ Pousser la butée de canette contre la canette vide. Si la butée de canette ne glisse pas facilement entre les côtés supérieur et inférieur de la canette, vérifier si la canette est installée correctement, avec la tige de guidage (⑤) insérée dans l'encoche inférieure.

Downloaded from www.Manualslib.com manuals search engine




✻ Placer l'extrémité du fil de façon qu'il ne ressorte pas de la


⑦ Tout en tenant l'extrémité du fil, appuyer sur la pédale pendant quelques secondes. Quand il s'est enroulé suffisamment de fil sur la canette pour que le fil reste en place, relâcher la pédale et couper l'excédent de fil. Continuer à remplir la canette en appuyant sur la pédale.



⑧ Relâcher la pédale pour arrêter le bobinage lorsque la canette est pleine.



⑨ A la main, ramener la butée de canette à sa position d'origine.




⑩ Couper le fil et enlever la canette.


Downloaded from www.Manualslib.com manuals search engine

Insertion de la canette


⚠Attention – Déplacement des pièces –
Pour éviter tout risque de blessure, toujours éteindre la machine avant toute intervention technique. Ouvrir les couvercles.



① Soulever la plaque à aiguille et ouvrir le volet de la canette.




⑤ Abaisser la plaque coulissante et refermer le volet de la canette en suivant l'ordre ❶ ❷ ci-dessus.



② Mettre la canette dans le boîtier de la canette.


✻ Faire passer le fil dans l'encoche prévue et sous le ressort de verrouillage de manière à laisser sortir quelques cm de fil.

✻ Toujours utiliser le boîtier de canette livré avec la machine. Un deuxième boîtier peut également être commandé auprès du revendeur.



③ Tirer sur le levier de verrouillage du boîtier de la canette, enfoncer le boîtier de la canette dans la coursière de navette et relâcher le levier de verrouillage.


✻ Si le levier de verrouillage n'est pas placé correctement sur le crochet, le boîtier risque d'être éjecté pendant la couture et de provoquer des ruptures du fil inférieur. Tourner le volant à main un tour complet vers soi pour s'assurer que le boîtier de la canette est bien en place.



④ Passer le fil dans le dispositif de remontée rapide du fil de la canette dans l'ordre ❶ ❷, tirer dans le sens de la flèche ❸ puis couper le fil.

★ Dispositif de remontée rapide du fil de la canette
Ce dispositif coupe le fil de la canette à une longueur appropriée après le remplacement de la canette et le garde à cette longueur; de cette manière, on ne peut pas omettre l'opération de remontée du fil.

● **Lorsque la table de rallonge pour tissu est en place**




Ouvrir au préalable le couvercle de mise en place du fil de la canette puis mettre le fil de la canette en place. (Vous pouvez mettre le fil de la canette en place sans ôter la table de rallonge pour tissu.)


Downloaded from www.Manualslib.com manuals search engine

Enfilage (2)

⚠Remarque Toujours mettre la machine hors tension avant d'utiliser l'enfileur. Une pression accidentelle sur la pédale du rhéostat pendant cette opération pourrait provoquer des blessures ou endommager la machine.


Mise en place du fil supérieur






● Vérifier que le levier de relevage du fil se trouve sur la position de levage maximale et que le pied-de-biche est relevé.


✻ Lorsqu'on utilise du polyester ou du fil qui se torsade ou se casse, faire passer le fil dans les trois orifices du guide-fils.





✻ Si le fil est encore torsadé ou cassé faire passer le fil dans les orifices arrière, comme indiqué sur le schéma.




Utilisation de l'enfileur







✻ Tirer le fil vers la gauche et s'assurer qu'il est bien pris sur le crochet.



① Tourner le volant à main vers soi jusqu'à ce que l'aiguille soit complètement relevée puis abaisser le pied-de-biche.

② Prendre le fil dans la main gauche et le tirer doucement vers l'avant.

③ Abaisser l'enfileur automatique.


✻ Tirer le fil sur la droite de l'axe.

✻ Ne pas abaisser de force l'enfileur plus bas que le chas de l'aiguille qui est sur la position de levage maximum.

④ Tourner le levier de l'enfileur à fond dans le sens ❶ et, lorsque le crochet passe par l'orifice de l'aiguille, tirer le fil dans le sens ❷ pour l'attraper sur le crochet.

⑤ Tenir doucement le fil et replacer le levier de l'enfileur vers la droite. Pendant cette opération, le crochet qui a attrapé le fil se déplace également et tire une boucle de fil par le chas de l'aiguille.

Downloaded from www.Manualslib.com manuals search engine




⑥ Tirer la boucle de fil vers la droite.

Aiguille (HLX5)	Fil
#9	#20 #30 #50 #60
#11	#20 #30
#14	#20 #30
#16	#20

- Certaines combinaisons de fil et d'aiguille ne permettent pas d'utiliser l'enfileur, comme indiqué sur le tableau de gauche. Un fil de nylon transparent pourra être utilisé indépendamment des indications du taleau, à condition d'utiliser une aiguille #14 ou #16.

Utilisation du filet de la bobine



① Filet de la bobine
② Bobine de fil
③ Porte-bobine
④ Couvercle de bobine


Lorsque vous utilisez des fils en nylon transparent, métalliques ou autres fils épais, placez le filet de la bobine inclus sur la bobine avant de coudre.
Si le filet de la bobine est trop long, pliez-le une fois pour qu'il soit de la même taille que la bobine avant de le placer sur la bobine.

Downloaded from www.Manualslib.com manuals search engine


Points d’essai et tableau d’aiguilles

Points d’essai

① Régler le sélecteur de longueur de point sur la longueur de point voulue.
② Vérifier qu’il y a environ 15 cm de fil supérieur et de fil de canette de sortis, et qu’ils sont placés derrière le pied-de-biche. L’aiguille étant en position relevée, mettre un morceau de tissu sous le pied-de-biche pour faire un essai.




③ Abaisser le pied-de-biche.
④ Tourner le volant à main vers l’avant pour abaisser l’aiguille et la piquer dans le tissu puis appuyer doucement sur la pédale pour commencer à coudre.




⑤ Tourner le volant à main vers soi pour relever complètement l’aiguille et le levier d’enfilage.
⑥ Relever le pied-de-biche, enlever le tissu et couper le fil.

✻ Si l’on utilise les ciseaux:
⑤ Appuyer sur le bouton du coupe-fil pendant que le levier du pied-de-biche est abaissé.
⑥ Relever le pied et enlever le tissu.



Tension des fils

✻ Le fil de canette doit être alimenté régulièrement. Régler le fil de canette en fonction de la tension du fil supérieur. (Si le fil de canette est trop serré, le tissu risque de se plisser.)



Une mauvaise tension des fils peut donner des résultats non souhaités comme des points irréguliers, des coutures froncées ou provoquer la rupture des fils.

● **Sélectionner l’aiguille qui convient pour le tissu et le fil**

✻ Le tableau ci-dessous concerne différentes combinaisons de tissus, de fils et d’aiguilles.

	Combinaisons tissu-fil-aiguille			HLX5	Schmetz 130/705H
	Tissu	Fil	Aiguille (HLX5)		
Tissu spécial	Velours	Soie, polyester #30 – #50	#11 – #14	#9	#65
	Matelassage	Polyester #20 – #50	#11 – #16	#11	#75
	Daim synthétique	Polyester #20 – #50		#14	#90
	Jersey	Polyester #20 – #50		#16	#100
	Revêtement	Polyester #50	#11 – #14	#18	#110
Tissu léger	Batiste	Coton #80	#9		
	Tricot	Polyester #60			
	Soie Georgette	Soie #50			
	Laine Georgette	Soie, poyester #50	#11		
Tissu moyen	Vichy	Coton #60 – #80	#11 – #14		
	Tricot léger, jersey	Polyester #60	#11		
	Gabardine, flanelle	Soie #50			
Tissu lourd	Jeans	Coton #20 – #50	#14 – #18		
	Jersey	Polyester #20 – #50	#11 – #16		
	Tweed	Soie #20 – #50			

✻ Il est recommandé d’utiliser des aiguilles HLX; toutefois, on pourra également utiliser des aiguilles Schmetz 130/705H dans des conditions normales d’utilisation.
✻ Régler le sélecteur de pression et le bouton des griffes d’entraînement en fonction du tableau repris sur la machine à coudre.
✻ Avec des tissus comme du jersey ou des tricots, utiliser une aiguille à bille ou toute autre aiguille spécialement conçue pour les tricots.
✻ Pour obtenir les meilleurs résultats avec des fils métalliques, utiliser un fil de bonne qualité, régler la tension supérieure sur 2, et utiliser une aiguille métallique.


Downloaded from www.Manualslib.com manuals search engine

Changement du pied-de-biche


⚠Remarque Bien éteindre la machine avant de changer le pied-de-biche.

Changement du pied-de-biche (Pied pour fermeture à glissière)

① Relever le pied-de-biche et relever l'aiguille à la position maximale.
② Desserrer la vis à l'aide d'un tournevis et la retirer.




③ Fixer le pied pour fermeture à glissière et resserrer la vis.



✻ Procéder de la même façon pour fixer l'autre pied livré avec la BLQP.
✻ Pour le sens de fixation du pied intérieur, voir page 41.


✻ Utiliser le bouton de position au dos du pied pour fermeture à glissière pour régler la position du pied par rapport à l'aiguille.
✻ Seul le pied pour fermeture à glissière possède un bouton de position. On peut commencer à coudre avec tous les autres pieds-de-biche dès que le pied est fixé.



Les différents pied-de-biche

✻ Utiliser uniquement les pieds fournis avec la BLQP. Chaque pied a été spécialement conçu pour cette machine et possède au dos l'espace nécessaire pour la tige. L'utilisation d'autres pieds-de-biche risque d'endommager ou de casser le mécanisme d'entraînement par ergot.


- **Pied à réaction souple**
  Pour obtenir des points parfaits sur des tissus difficiles comme le velours, le cuir et le daim.




- **Pied pour ourlet rouleauté**
  S'utilise sur les bords du tissu, comme sur les ourlets de chemises de soirée, pour plier le bord en trois pendant la couture.



- **Pied pour fermeture à glissière invisible**
  Permet de fixer des fermetures à glissière dissimulées.




- **Pied transparent pour ouatinage/ matelassage**
  Pour réaliser des surpiqures parfaites (couette, coussin, ...).




- **Pied à usage général**
  Ce pied convien pour la plupart des travaux de couture. (Sert également pour les tissus lourds et les coutures.)


✻ Lors de la couture d'ourlets épais, guider légèrement le tissu en plaçant la main à l'envers de la couture.
✻ Peut également être utilisé avec un entraînement par ergot.




- **Pied pour fermeture à glissière**
  Permet de fixer des fermetures à glissière autres que les fermetures dissimulées.



- **Pied 1/4"**
  Pour coudre du quilting et du patchwork avec un déplacement de 1/4" et 1/8".




- **Pied double-entrainement**
  Entraîne le tissu fin ou épais pour éviter le froncage. Très utile pour le quilting.



Downloaded from www.Manualslib.com manuals search engine

Couture de base (1)

Couture de base



① Relever le pied-de-biche, sortir environ 15 cm de fil supérieur et de fil de canette et les faire passer derrière le pied-de-biche, puis placer le tissu sous le pied-de-biche.

② Abaisser le levier pour abaisser le pied-de-biche.
③ Tourner le volant à main vers soi pour abaisser l'aiguille et la piquer dans le tissu puis appuyer légèrement sur la pédale pour commencer à coudre.

✻ Au début et à la fin d'une couture, appuyer sur le levier de point arrière et coudre en marche arrière sur environ 1 cm.


④ Relever l'aiguille au maximum.
⑤ Relever le pied-de-biche, retirer le tissu et couper le fil.
✻ Si l'on utilise le coupe-fil:
④ Appuyer sur le bouton du coupe-fil (le fil supérieur et le fil de canette se coupent automatiquement et l'aiguille s'arrête en position relevée).
⑤ Relever le pied-de-biche et retirer le tissu.

① S'assurer que l'aiguille a complètement traversé le tissu.
② Relever le pied-de-biche et tourner le tissu en utilisant l'aiguille comme axe.
③ Abaisser le pied-de-biche et continuer à coudre.

Entraînement par ergot (pour les tissus difficiles à manipuler)

Il est possible de parfaitement raccorder des tissus comme le velours, le tissu pour matelassage, le daim synthétique, les jerseys, etc. en activant le mécanisme d'entraînement par ergot.

● Configuration de la machine pour l'entraînement par ergot




① Mettre le bouton de réglage d'entraînement sur la position d'entraînement par ergot.

② Régler le sélecteur de pression jusqu'à ce que l'indicateur d'aiguille se trouve sur la position correcte dans la zone codée de correspondance des couleurs.

③ Fixer le pied-de-biche à réaction souple pour obtenir des points de couture parfaits sur des tissus comme le velours, le cuir et le daim.


● Mécanisme d'entraînement par ergot



L'ergot d'entraînement remonte de façon à traverser toutes les épaisseurs de tissu et il se déplace sous l'effet du mouvement des griffes d'entraînement de manière à entraîner le tissu de façon uniforme.

✻ Pour des raisons de sécurité, l'ergot d'entraînement s'abaisse automatiquement quand on relève le pied-de-biche.

● Commencer à coudre



Tirer délicatement sur le fil jusqu'à ce que l'ergot d'entraînement attrape le tissu, et coudre.

Downloaded from www.Manualslib.com manuals search engine


Couture de base (2)

⚠Remarque Bien éteindre la machine avant de changer le pied-de-biche.


Pied pour ourlet rouleauté

① Fixer le pied pour ourlet rouleauté.
✻ Pour le changement des pieds-de-biche, voir page 36.


② Insérer l'aiguille à environ 0,5 cm du bord du tissu et coudre 2 points.




③ Tourner le volant à main vers soi pour relever l'aiguille, relever le pied-de-biche puis tirer le tissu vers l'avant.




④ Tenir les 4 fils de la main gauche.



⑤ De la main droite, placer le bord de l'ourlet roulotté sous le pied-de-biche, au point où les fils ressortent. Puis insérer le bord de façon qu'il se trouve juste sous l'aiguille. Abaisser le pied-de-biche.



⑥ Tirer délicatement sur les fils de la main gauche pendant que l'on coud les 3 ou 4 premiers points de façon qu'ils restent en place.
⑦ Replier l'ourlet sur environ 0,5 cm et continuer à faire avancer l'ourlet replié sous le pied tout en cousant vers le guide recourbé du pied.



Downloaded from www.Manualslib.com manuals search engine


Couture de base (3)

⚠Remarque
- Bien éteindre la machine avant de changer le pied-de-biche.
- Pour coudre une fermeture à glissière sur un tissu extensible, utiliser la méthode d'entraînement par ergots, et régler la pression du pied en conséquence.
- Le pied pour fermeture à glissière peut également servir de guide lors de la fixation de rouleaux au tissu.

Pied pour fermeture à glissière

① Fixer le pied pour fermeture à glissière.
✻ Voir "Changement du pied-de-biche (Pied pour fermetures à glissière)" à la page 36.
② Tourner le volant à main vers soi pour abaisser l'aiguille et régler la position du pied par rapport à l'aiguille; utiliser la vis de réglage pour faire glisser le pied de la gauche vers la droite.

③ Placer la fermeture à glissière à l'endroit du tissu où elle doit être cousue, et marquer la base de l'ouverture sur le tissu. Elle devra se trouver à environ 0,5 cm en dessous de l'arrêt de la fermeture à glissière. Coudre à partir du dessous de la base de l'ouverture.
④ Diviser la marge de la couture. Plier la marge de la couture avec la partie superposée de la fermeture à glissière au-dessous, à 0,2 cm de l'extérieur du trait.



⑤ Faufiler la fermeture à glissière pour la fixer puis coudre le long du trait.


⚠ Veiller à ce que l'aiguille ne heurte pas la section métallique de la fermeture à glissière pendant la couture. L'aiguille pourrait se casser et provoquer des blessures.

⑥ Aligner l'ourlet replié à l'envers sur les points.

⑦ Changer la position du pied pour fermeture à glissière.
⑧ Tourner le volant à main pour abaisser l'aiguille et mettre le pied-de-biche en place.

⑨ Tourner l'endroit du tissu vers le haut, faufiler la fermeture à glissière sur le tissu puis coudre le bord du faufilage.


✻ Renforcer la base de l'ouverture en la cousant deux fois.
✻ Si la languette de la fermeture à glissière gêne la couture, enfoncer l'aiguille au maximum dans le tissu, relever le pied et déplacer la fermeture à glissière sur le côté.




Downloaded from www.Manualslib.com manuals search engine

Pied pour fermeture à glissière invisible

① Fixer le pied pour fermeture à glissière invisible.
② Disposer la fermeture à glissière sur le tissu. Marquer la base de l'ouverture à environ 2 cm audessus de l'extrémité de la fermeture à glissière.
③ Faufiler l'emplacement de la fermeture à glissière.




④ Séparer l'espace de la couture.
⑤ Lorsque la fermeture à glissière est en place, faufiler uniquement la marge de la couture d'un côté de la fermeture à glissière.
⑥ Remonter la fermeture à glissière pour la fermer et faufiler l'autre côté.
⑦ Retirer le faufilage à l'emplacement de la fermeture à glissière.



⑧ Placer les dents de la fermeture à glissière dans la rainure du pied-de-biche, les guider pour éviter qu'elles ne tombent puis coudre jusqu'à la base de l'ouverture.


✻ Si l'on effectue la couture avec les dents de la fermeture sur la droite, le côté gauche du pied devra être aligné sur les dents gauches de la fermeture à glissière.




Pied 1/4"

● Réglages de la machine à coudre: Longueur de point = 2 - 2,5


• Vous pouves piquer un rentré constant (1/4", 6,4 mm) quand vous cousez ensemble une ouate.



• Utiliser les repères de guidage pour commencer, terminer ou pivoter de 6,4 mm (1/4") du bord du tissus.




• Vous pouvez effectuer une deuxième couture droite à 3,2 mm (1/8") de la couture.



Downloaded from www.Manualslib.com manuals search engine

Pied transparent pour ouatinage/matelassage

Réduire la pression du pied-de-biche et tourner le sélecteur sur la machine en abaissant les griffes d'entraînement pour le matelassage en bras libre.




⚠Remarque

- Si l'on utilise fréquemment le pied, bien appliquer une petite quantité d'huile environ une fois par mois à l'endroit indiqué par la flèche. (Si l'on a mis trop d'huile, essuyer l'excédent avec un chiffon.)
- Pour obtenir les meilleurs résultats avec des fils métalliques ou monofilament pour un matelassage à dessin libre, utiliser un fil de bonne qualité, régler la tension supérieure sur 1-2, et utiliser une aiguille métallique.

Pied double-entrainement

⚠Remarque

- Ne pas appuyer à fond sur la pédale. Essayer de conserver une vitesse de couture lente (500t/mn ou moins).
- Le tissu risque de ne pas être entraîné si la vitesse de couture est trop élevée.
- Les griffes d'entraînement qui font avancer le tissu risquent de ne pas avancer si la pression du pied sur le tissu est trop forte. Utiliser le sélecteur de pression du pied-de-biche pour obtenir les résultats souhaités.
- Il n'est pas recommandé ni nécessaire d'utiliser le mode d'entraînement par ergots avec le pied intérieur.




① Lorsque le levier de commande est relevé à la verticale, insérer sa partie fourchue dans la vis située à droite de la barre à aiguille, comme illustré, puis insérer la vis.

② Serrer la vis avec un tournevis sinon elle pourrait se desserrer en raison des vibrations du pied et du levier de commande.

Downloaded from www.Manualslib.com manuals search engine


Guide de couture

① Serrer la vis avec un tournevis sinon elle pourrait se desserrer en raison des vibrations.



Installation

Pour pouvoir ajuster la position du pied dans le sens de la flèche.


Réglage


Downloaded from www.Manualslib.com manuals search engine

Entretien de la machine à coudre

Nettoyage de la machine


⚠Remarque
Bien éteindre la machine avant de procéder au nettoyage de la machine à coudre.

① Eteindre la machine.
② Retirer le pied-de-biche.
③ Retirer la plaque à aiguille.




④ Enlever la poussière et les restes de fil.

✻ Il est possible d'enlever les restes de fil par le volet de la canette.



⑤ Lorsque la section sous la plaque à aiguille est nettoyée, graisser le crochet du boîtier de la canette avec de l'huile* de machine à coudre.
✻ Utiliser un chiffon pour essuyer l'excédent d'huile sur la machine.
★ Utiliser exclusivement une huile de machine à coudre de qualité supérieure.




⑥ Remettre la plaque à aiguille et le pied-de-biche en place.

Points de graissage


● Lors d'un usage journalier de la machine, appliquer quelques gouttes d'huile* à chaque emplacement indiqué, deux fois par mois.

✻ Utiliser un chiffon pour essuyer toute l'huile renversée sur la machine aux alentours des points de graissage.
★ Utiliser exclusivement une huile de machine à coudre de qualité supérieure.



■ **Maintenir la machine à coudre constamment propre**
Enlever la saleté légère et la poussière avec un chiffon doux et sec. Si la machine est très sale, l'essuyer avec un chiffon trempé dans de l'eau tiède, ou de l'eau tiède contenant un détergent neutre. Puis, enlever tout reste de détergent et essuyer avec un chiffon sec.

■ **Précautions**
Eloigner la machine à coudre des sources de chaleur telles que fer à repasser et appareil de chauffage. Ne pas utiliser de produits chimiques tels que benzine ou diluant pour nettoyer la machine. Quand on ne se sert pas de la machine, la ranger à l'abri des rayons du soleil.




Elément	Spécification
Vitesse de couture (maximum)	1.500 points par minute
Longueur de points (pas)	0 – 7 mm
Course de l'aiguille	34,1 mm
Course du levier de relevage du fil	64,7 mm
Hauteur du pied-de-biche	Levage du pied-de-biche Un 6 mm Deux 9 mm Commande au genou Plus de 10 mm

Elément	Spécification
Hauteur des griffes d'entraînement	0,7 mm 1,1 mm
Hauteur d'aiguille inférieure	3 mm – 3,5 mm
Aiguilles qu'il est possible d'utiliser	HLX5#9 – #18 SCHMETZ 130/705H #65 – #110
Dimensions du lit	439 mm × 178 mm
Poids total	11 kg
Lampe de couture	Modèle 120V: 120V/15W Code de pièces: X53061-050 Modèle 220-240V: 240V/15W Code de pièces: 205336-050
Surface de couture	595 mm × 285 mm

Downloaded from www.Manualslib.com manuals search engine

Dépannage

✻ Avant de porter la machine à coudre à réparer, vérifier le tableau suivant.



Downloaded from www.Manualslib.com manuals search engine

Downloaded from www.Manualslib.com manuals search engine

ENGLISH
FRENCH
884-639
XC5228-051
Printed in Taiwan

Downloaded from www.Manualslib.com manuals search engine